



BACKWASHING FILTERS

INSTALLATION GUIDE & OWNER'S MANUAL

FOR MODELS

- EQA-1054
- EN-1044
- EQB-1054
- EN-1054
- EQC-1054
- EN-1354
- EQA-1354
- EQB-1354
- EQC-1354

INDEX

Valve Settings— For Users3
Bypass Valve Operation4
Bypass Valve Diagrams	
Installation Instructions5
Pre-Installation Checklist	
Installation Diagrams	
Post-Installation Checklist	
Valve Settings— For Installers7
Access Programming	
Regeneration Mode	
Manual Regeneration	
Replenish Media— Acid Neutralizers.9
Error Codes and In-Field Resolution Guide	10
Replacement Parts	13
System Specifications	19

YOUR SYSTEM:

Installation Date: _____
Installer: _____
City/State: _____
Phone: _____
Model: _____
Serial #: _____

YOUR WATER RESULTS:

Total Hardness: _____ gpg
Iron (Fe): _____ ppm
Acidity (pH): _____
Total Dissolved Solids (TDS): _____ ppm
Total Compensated Hardness: _____ gpg

PRODUCT WARRANTY

In the unlikely event that your system has defects in material or assembly, the manufacturer will proudly stand behind our products and support the original owner for the following:

5 YEARS
on Mineral Tank

5 YEARS
on Brine Tank

5 Years
on All Parts

System must be installed in accordance with specifications outlined in this manual and local plumbing codes to qualify for the factory warranty. Warranty coverage is limited and will not cover damaged due to accident, fire, flood, freezing, any other "Act of God," change in water conditions, misapplication, neglect, vacuum, lack of maintenance, or equipment installed on a non-potable water source.




VALVE SETTINGS— USER

DISPLAY SETTINGS

When the system is operating, one of several displays may be shown. The displays constantly scroll by default. Press **NEXT** to pause on the current display for 5 minutes.



Continue to press **NEXT** to alternate between the displays:

- **Current Time of Day Screen**— Be sure this is accurate for proper operation of the system.
- **Days Remaining**— Number of days left before the system regenerates.
- **Capacity Remaining**— Volume of water that will be treated before the system regenerates. Press ∇ button while on the Capacity Remaining display to decrease the volume in 10 gallon increments.
- **Flow Indicator**— If a water meter is installed, the flow indicator flashes on the display to show the rate at which water is flowing through the system.
- **Flow Rate**— Show the current speed treated water is flowing through the system in gallons per minute.






SERVICE REMINDER

Regular maintenance will prolong the life of your system. The unit will let you know when it's time to schedule a check-up. To clear this reminder and see your regular screens, press the Δ and ∇ buttons together while the scrolling message is displayed.




SET TIME OF DAY

Besides the initial start up, time of day should only need to be set if the battery has been depleted due of extended power outages or for daylight saving time. If an extended power outage occurs, the time of day will flash, which indicates the time of day should be reset and the non-rechargeable battery replaced.



Use to adjust value



Use to adjust value

Return to operating display screens

1. Access Time of Day— Press **SET CLOCK**.

2. Set Hour— Use the Δ or ∇ button to select the current hours of the day. The AM/PM designation will change as you scroll past 12. Press **NEXT**.

3. Set Minutes— Use the Δ or ∇ button to select the current minute of the hour. Press **NEXT** to exit the Time of Day settings.

— or —
Press **REGEN** to return to previous step.

BYPASS VALVE OPERATION

FIG. 1

OPERATING POSITION




FIG. 2

BYPASS POSITION




FIG. 3

FILL POSITION




FIG. 4

DIAGNOSTIC POSITION





FIG. 5

SHUT OFF POSITION



The bypass valve is used to isolate the system's operation from the plumbing system's water pressure in order to perform repairs or maintenance. The bypass provided with your Varsity water system is uniquely designed to be versatile with many advanced features. The 1" full flow valve incorporates four positions, including a diagnostic position that allows service personnel to work on a pressurized system while still providing untreated water to the building. It's completely non-metallic design allows for easy serviceability without the needs for tools.

The bypass body and rotors are glass-filled Noryl while the nuts and caps are glass-filled polypropylene. All seals are self-lubricating EPDM to help prevent seizing after long periods of non-use. Internal O-rings can easily be replaced if maintenance is required.

The bypass consists of two interchangeable plug valves that are operated independently by red arrow-shaped handles. The handles will point in the direction of the water flow in any given position. The plug valves enable the bypass valve to operate in multiple positions. See diagrams for details.

- 1. Normal Operating Position**— Inlet handle is turned to have the arrow pointing toward the unit. Water flows through the control valve during normal operation. This position also allows the control valve to isolate the media bed during the regeneration cycle. The outlet handle is pointed away from the unit to allow the flow of treated water to leave the system and enter the building's plumbing system. (See Fig. 1 below)
- 2. Bypass Position**— The inlet and outlet handles point towards each other. This isolates the control valve from the water pressure contained in the plumbing system. Any water drawn from the building while the system is in this position will receive untreated water directly from the source. (See Fig. 2 below)
- 3. Fill Position**— During initial start up, the media tank will need to be filled with water. Slowly open the inlet handle to be partially open; handle arrow should point at a 30°-45° angle from the closed position. The outlet handle should remain closed, pointing toward the center of the bypass. (See Fig. 3 below)
- 4. Diagnostic Position**— The inlet handle arrow points toward the unit to allow water pressure to flow into the control valve. The outlet handle remains closed, pointed toward the center of the bypass. (See Fig. 4 below) This is helpful to have water run through the system without it affecting the rest of the building.
- 5. Shut Off Position**— The inlet handle is closed with the arrow pointing toward the center of the bypass. The outlet handle should point away from the unit. (See Fig. 5 below) This will stop all water flow to the building. If water is still available to the plumbing system in this position, this indicates a plumbing connection somewhere that is going around the unit.

INSTALLATION INSTRUCTIONS

PRE-INSTALLATION CHECKLIST

Plumbing Connections— All plumbing materials and the installation must adhere to State and Local Plumbing Codes.

Water Pressure— Proper operation of the equipment requires:

- A minimum of 25 pounds water pressure.
- A maximum of 100 pounds water pressure.
- A minimum flow rate of 3 gallons per minute.



Electrical Requirements— A continuous 110 volt 60 hertz AC current is needed for power supply. Ensure power is not on a switched outlet or interrupted in any other way.

Temperature— Equipment must not be installed where it will be exposed to temperatures below 40° F or above 100° F.

Drainage Information— The unit should be installed as close to the drain and water supply as possible. The connections for inlet and outlet are 1" Sweat copper or 1" NPT made adapter. The drain connector is 3/4" NPT male. Construct the drain outlet to include an air gap of 2 pipe diameters or 1" (whichever is larger).


Bypass Valve— The system includes a bypass valve. If the existing plumbing already has a bypass, the one provided may be removed. If you used the bypass provided, a full port ball valve should be installed on the inlet side. The equipment is designed to accommodate minor plumbing misalignments, but is not able to support the weight of the system or plumbing.

INSTALLATION DIAGRAM



MULTI-SYSTEM INSTALLATION DIAGRAM

When installing a backwashing filter or acid neutralizer in conjunction with a water softener, ensure the water travels through the filter first to protect the softening system.



**Drain outlet should be installed with connection to the sanitary waste system through an air gap of 2 pipe diameters or 1 inch, whichever is larger.*

Post-INSTALLATION CHECKLIST



IMPORTANT—







Do not plug the transformer into an outlet until instructed in the steps below.

- 1. Flush System—** After installation is complete, rotate the bypass valve handles to the bypass position shown in **Fig. 2** on page 4. With water pressure turned on, open a cold water faucet and allow water to clear pipes of debris which may occur during installation. Close cold water faucet.
- 2. Start Up Instructions—**
 - Press and hold **REGEN** button until motor starts. When motor stops, valve will be in **BACKWASH** cycle of regeneration process. **Unplug** power cord from 120/60 outlet.
 - **Slowly** rotate the inlet side of the bypass to the **FILL POSITION** shown in **Fig. 3** on page 4. Allow water to flow into the system until it exits out the drain line and becomes a gray-ish color.

- **Plug** transformer into a 120/60 outlet. Continue to let the water flow out to the drain for several minutes until it turns from gray to clear.
- Press the **REGEN** button to advance the system into **FILTERING** mode and the Time of Day display is showing on the screen.
- **Rotate** the bypass handles to the **OPERATING POSITION** as in **Fig. 1** on page 4. The system is now processing the water supply and providing treated water to the building.

3. Set Time of Day— Plug power cord into a 120/60 uninterrupted power source. Press and hold **SET CLOCK** button until hour number is flashing. Use the Δ and ∇ buttons to set correct hour of day (cycle past 12 to change AM/PM). Press the **NEXT** button to advance to the minutes value and use the Δ or ∇ button to set current minute of the hour. Press **NEXT** to exit and save the current time. See page 3.

VALVE SETTINGS— INSTALLER



1. Access Programming— Press and hold **NEXT** and the Δ button simultaneously for 3 seconds.

2. Water Hardness— Use the Δ and ∇ buttons to set the grains of hardness as CaCO_3 per gallon. The grains per gallon can be increased if soluble iron needs to be reduced.

- **Range:** 1-150 grains
- This display will only appear if **Volume Capacity** is set to **AUTO** in advanced programming (see Varsity Water Technician's Guide).



3. Day Override— If **Volume Capacity** is set to **OFF**, this setting will control the number of days between regenerations. If **Volume Capacity** is set to **AUTO** or a specific number, this will set the **maximum** number of days between regenerations. Use the Δ or ∇ button to select one of the following options:

- **Days Value:** Set a number (1-28) of days to trigger a regeneration, even if sufficient volume of water has not been used.
- **OFF:** System will only trigger a regeneration based on volume used.

4. Regeneration Time— Use the Δ or ∇ button to set the hour of the day regeneration should begin. The AM/PM designation will change as you scroll past 12. Press **NEXT** to change the minutes value.

- The ideal time will vary based on the owner's water usage habits. Set a regeneration time when treated water is not necessary.
- This display will not appear if **Regeneration Time Option** is set to **IMMEDIATE REGENERATION**.

.....➔ Process continued on next page



- 5. Energy Saver**— Use the Δ or ∇ button to select one of the following options:
- **ON:** The control will automatically turn off the display screen light after 5 minutes of keypad inactivity.
 - **OFF:** The display screen light will always be illuminated.


Press **NEXT** to exit Installer Display Settings. — or — Press **REGEN** to return to previous step.

.....➔ Return to regular operating display screens

REGENERATION MODE

A system is usually set to regenerate at a time of low water usage (*i.e. when a household is asleep*). If there is a demand for water when the system is regenerating, untreated water will be used.

When the system starts regeneration, the screen information will display the current cycle that is in process and the time remaining for that step to be completed. The system performs each cycle automatically and will return to the operating mode once all regeneration cycles are complete.




MANUAL REGENERATION

Occasionally, you may need to manually regenerate the system before the programming calls for it, such as after increased water usage due to guests or a heavy laundry day.

To start a manual regeneration, press and release the **REGEN** button. **REGEN TODAY** will flash on the display to indicate that the system will regenerate at the preset delayed regeneration time (*default is 2:00 AM*).

- Press **REGEN** again to cancel the request.

NOTE: If the **Regeneration Time Option** is set to **IMMEDIATE REGENERATION**, there is no delayed regeneration time designated in the programming. Therefore **REGEN TODAY** will not activate if **REGEN** is pressed. To initiate a manual regeneration immediately, press and hold **REGEN** for **3 seconds**. The system will begin to regenerate immediately. The request cannot be canceled.



REPLENISH MEDIA— ACID NEUTRALIZERS

Our acid neutralizers use a sacrificial mineral that dissolves in order to raise the pH of the water. Therefore the media inside will need to be replaced every 6-12 months, or when the media tank has reduced to half-full. Complete the following process to add more minerals.

PLEASE NOTE: When replenishing the mineral, you must use the same blend as was initially installed. Depending on the pH of the source water, the system may be equipped with straight calcite media or a blend of calcite + corosex. Ensure you have the correct mineral ratio before proceeding.




CAUTION—
Never unscrew the valve or top fill port unless pressure is fully released from system. Serious injury and/or flooding can occur.

- 1. Check Media Height—** Shine a flashlight through the tank to see the height of the mineral. If the level is not visible, proceed to Step 2 to open the tank and measure manually with a ruler.
- 2. Depressurized System—** Turn off the incoming water source and open a tap inside that house that is using filtered water to release the pressure inside of the tank. Place the unit into bypass mode (See Fig. 2 on Page 4). Unscrew the top fill port or the valve head.
- 3. Remove Water—** Siphon out water from the tank in order to create room for the media without causing an overflow.
- 4. Add Media—** Pour in the mineral until it reached the recommended fill height, approximately 2/3 of the tank.
DO NOT OVERFILL.

If needed, siphon out more water as needed as media added displaces remaining water.

- 5. Close Tank—** Replace the valve head or top fill port. Grease the O-ring seals using silicone grease, if necessary. (Never use petroleum-based grease, like Vaseline.) Ensure everything is tighten appropriately.
- 6. Return To Service—** Leaving the valve in the Bypass position, turn on the water source. Refer to the start up instructions on Page 6 to complete the procedure. For tanks with a top fill port, double check for leaks around the plug.



ERROR CODES AND DESCRIPTIONS

Error Code Number	Definition	Description
101	Unable to start	Valve does not sense any movement with motor engaged
102	Motor stalled	Valve is not able to find the next cycle position
103	Motor ran too long	Valve is not able to find the next cycle position
104	Valve homing	Valve is not able to find the "Home" position
106	MAV 1 ran too long	MAV 1 was not able to find proper park position
107	MAV 1 stalled	MAV 1 motor ran too short and was not able to find proper park position
109	Invalid motor state	Control detected incorrect motor state and can no longer operate properly
116	MAV 2 ran too long	MAV 2 was not able to find proper park position
117	MAV 2 stalled	MAV 2 motor ran too short and was not able to find proper park position
201	Invalid regen step	Internal software issue regarding regeneration cycle steps causing controller to malfunction
204	Leak detected	Occurs when dP input is active for "ALARM" and the input is closed.
402	Power down memory	Check sum error for operational data and status section of EEPROM memory—specific type of memory error.
403	Program memory	Check sum error for operational data and status section of EEPROM memory—specific type of memory error.
404	Diagnostic memory	Check sum error for operational data and status section of EEPROM memory—specific type of memory error.
405	History memory	Check sum error for operational data and status section of EEPROM memory—specific type of memory error.
406	Contact memory	Check sum error for operational data and status section of EEPROM memory—specific type of memory error.
407	Status RAM memory failure	Control can no longer operate properly due to corrupted data detected in the Operational Data and Status Section of RAM memory. Once generated, the Error Mode is not entered nor an error displayed, instead previously stored data (<6 hours old) is used to maintain control operation.
408	Diagnostic RAM memory failure	Control can no longer operate properly due to corrupted data detected in the Operational Data and Status Section of RAM memory. Once generated, the Error Mode is not entered nor an error displayed, instead previously stored data (<6 hours old) is used to maintain control operation.
410	Config download	Configuration file downloaded to the control was not originally uploaded from another control with the identical software revision.

Press and hold **NEXT** and **REGEN** simultaneously for 3 seconds to perform a soft reset and clear an error.

IN-FIELD RESOLUTION GUIDE

Service Issue	Recommended Solution
Display is flashing Time of Day	Likely caused by a power outage. Reset Time of Day by following instructions in product's Installer & Owner's Manual. If system included a battery back up, replace it following instructions on Page 3.
Display is showing the wrong Time of Day	Unit has irregular access to power. Check to make sure product is not plugged into an outlet controlled by a light switch or a breaker/GFI was triggered. If no issues found with power source, replace the PC board.
There is nothing shown on display	The unit may have no access to power. Ensure adapter is plugged into an active outlet and cord is fully connected to PC board. If no issues found with power source, you have the option to replace the power adapter and/or the PC board.
Display does not show Flow Indicator icon while processing water	A flow meter may not be installed. Other possibilities include the unit being in Bypass position, the flow meter is not properly connected to the PC board, or something is lodged inside prohibiting turning of the blades. If no issues are found with the flow meter, it may be defective and should be replaced.
Unit is regenerating at wrong time of day	Ensure the Time of Day is correct and reset as needed by following instructions in product's Installer & Owner's Manual. Check the Time of Regeneration is set correctly and/or that programming setting has DELAYED regeneration selected. <i>(Immediate Regeneration will activate at random times.)</i>
Unit is not regenerating automatically when holding down the REGEN button	The valve cover may not be positioned correctly. Remove and reattach in proper position. Other reasons include a broken piston rod, broken drive gear, or broken drive cap assembly. If all components appear intact, replace the PC board.
Unit is not regenerating according to the system programming, but <i>will</i> while holding down the REGEN button	The unit may be in the Bypass position or the regeneration settings are not programmed correctly. Other possibilities include the flow meter is not connected to the PC board or something is lodged inside prohibiting turning of the blades. If no issues are found in the items above, you have the option to replace the flow meter and/or the PC board.
Water is running to the drain	Please review all of the following scenarios: <ul style="list-style-type: none"> ▪ After a power outage, the system will resume an interrupted regeneration process. If system included a battery back up, replace it following instructions on Page 3. ▪ Seal, stack assembly, or piston assembly may be damaged and needs to be replaced. ▪ Ensure drive cap assembly is tightened properly.



Additional common troubleshooting recommendations continue on next page

IN-FIELD RESOLUTION GUIDE



Service Issue	Recommended Solution
System is using too much regenerant	<p>Check the valve programming for REFILL setting, water quality setting, and regen frequency to ensure it matches the job site needs.</p> <p>Also ensure there are no leaking fixtures drawing water causing the unit to regenerate more often.</p>
Regenerant is present in treated water	<p>This could be caused by low water pressure entering the system. Ensure there is a minimum of 25 psi at all times. Also check for an incompatible, damaged, or plugged injector, and that the drain line is free from debris.</p>
Unfiltered or hard water is present after passing through the unit	<p>Please review all of the following scenarios:</p> <ul style="list-style-type: none"> ▪ Ensure the bypass is in the closed position. ▪ Check flow meter to ensure nothing is lodged inside. ▪ Media could be exhausted from unusually high water usage or changes in water quality. Test the water and adjust program settings as needed. ▪ Regenerant is available during regen cycles. Ensure brine tank has salt and system is able to draw in regenerant. <i>(See Service Issue below for details.)</i> ▪ Check seals, piston, and stack assembly for damage. ▪ Ensure the control valve type and piston type are compatible. ▪ The media may be fouled and needs to be replaced.
Unit does not draw in regenerant	<p>Please review all of the following scenarios:</p> <ul style="list-style-type: none"> ▪ Injector is plugged. Remove and replace part. ▪ The regenerant piston may be broken. Remove and replace part. ▪ Check the regenerant line for air leaks. ▪ Check the drain line for material restricting flow and causing excess back pressure. ▪ Drain line is too long or too high for proper drainage. ▪ Check incoming water pressure to ensure it maintains a minimum of 25 psi.
There is excessive water in the brine tank	<p>Please review all of the following scenarios:</p> <ul style="list-style-type: none"> ▪ Brine line is not fully inserted into connector elbow inside brine tank. ▪ Injector is plugged. Remove and replace part. ▪ The seal, stack assembly, or piston may be damaged. ▪ Check the REFILL setting in programming. ▪ Ensure drive cap assembly is tightened properly. ▪ Check the drain line for restrictions from debris or kinks in the line. ▪ Backwash flow controller is plugged. Remove and replace part. ▪ Refill flow controller is missing; replace part.

REPLACEMENT PARTS

Front Cover & Drive Assembly			
Drawing #	Part Number	Description	Quantity
1	V4576-01	VARSITY FRONT COVER ASSEMBLY BLACK	1
2	V3107-01	MOTOR ASSEMBLY	1
3	V3002	DRIVE BRACKET ASY W/ MOTOR	1
4	V4630CP-BOARD	WS1 THRU 2 CP PCB REPL	1
5	V3110	DRIVE REDUCING GEAR 12x36	3
6	V3109	DRIVE GEAR COVER	1
Not Shown	V3186-06	POWER SUPPLY US 15VDC HOCP	1
	V3186AUS-05OD	POWER SUPPLY AUS 15VDC VI OUTDOOR	
	V3186EU-06	POWER SUPPLY EU 15VDC HOCP	
	V3186UK-06	POWER SUPPLY UK 15VDC HOCP	
	V3186-01	POWER CORD ONLY	
Not Shown	V3946	BACKPLATE MIDSIZE	1




Battery replacement is 3 volt lithium coin cell type 2032.




DRIVE CAP ASSEMBLY, PISTONS, & STACK ASSEMBLY			
DRAWING #	PART #	DESCRIPTION	QTY
1	V3005	WS1 Spacer Stack Assembly	1
2	V3004	Drive Cap Assembly	1
3	V3178	WS1 Drive Back Plate	1
4a	V3011*	WS1 Piston Downflow Assembly	1
4b	V3011-01*	WS1 Piston Upflow Assembly	1
5	V3174	WS1 Regenerant Piston	1
6	V3135	O-Ring 228	1
7	V3180	O-Ring 337	1
8	V3105	O-Ring 215 (Distributor Tube)	1

*V3011 is labeled with DN and V3011-01 is labeled with UP
 NOTE: The regenerant piston is not used in backwash only applications.




INJECTOR PARTS			
DRAWING #	PART #	DESCRIPTION	QTY
1	V3176	Injector Cap	1
2	V3152	O-Ring 135	1
3	V3177	Injector Screen	1
4	V3010-1Z	WS1 Injector Assembly Z Plug	1
5	V3010-1A	WS1 Injector Assembly A: Black	1
	V3010-1B	WS1 Injector Assembly B: Brown	
	V3010-1C	WS1 Injector Assembly C: Violet	
	V3010-1D	WS1 Injector Assembly D: Red	
	V3010-1E	WS1 Injector Assembly E: White	
	V3010-1F	WS1 Injector Assembly F: Blue	
	V3010-1G	WS1 Injector Assembly G: Yellow	
	V3010-1H	WS1 Injector Assembly H: Green	
	V3010-1I	WS1 Injector Assembly I: Orange	
	V3010-1J	WS1 Injector Assembly J: Light Blue	
V3010-1K	WS1 Injector Assembly K: Light Green		
Not Shown	V3170	O-Ring 011	*
Not Shown	V3171	O-Ring 013	*



*Injector plug and injectors each contain one 011 (lower) and one 013 (upper) o-ring.
 NOTE: For upflow position, injector is located in the up hole and injector plug in the down hole. For a filter that only backwashes, injector plugs are located in both holes.

WATER METER & METER PLUG			
DRAWING #	PART #	DESCRIPTION	QTY
1	V3151	WS1 Nut 1" QC	1
2	V3003*	WS1 Meter Assembly	1
3	V3118-01	WS1 Turbine Assembly	1
4	V3105	O-Ring 215	1
5	V3003-01	WS1 Meter Plug Assembly	1


*Order number V3003 includes V3118-01 and V3105



REFILL FLOW CONTROL & PORT PLUG			
DRAWING #	PART #	DESCRIPTION	QTY
1	V3195-01	WS1 Refill Port Plug Assembly*	1
2	H4615	Elbow Locking Clip	1
3	JCP-P-6	Polytube Insert 3/8	1
4	JCPG-6PBLK	Nut 3/8	1
5	H4613	Elbow Cap 3/8	1
6	V3163	O-Ring 019	1
7	V3165-01**	WS1 RFC Retainer Assembly	1
8	V3182	WS1 RFC	1
Not Shown	H4650	Elbow 1/2" with Nut and Insert	Option


*This part is required for backwash only systems

**Assembly includes WS1 RFC



DRAIN LINE — 3/4"			
DRAWING #	PART #	DESCRIPTION	QTY
1	H4615	Elbow Locking Clip	1
2	PKP10TS8-BULK	Polytube Insert 5/8	Option
3	V3192	WS1 Nut 3/4 Drain Elbow	Option
4	V3158-01	WS1 Drain Elbow 1/4 Male Assembly	1
5	V3163	O-Ring 019	1
6	V3159-01	WS1 DLFC Retainer Assembly	1
7	V3162-007	WS1 DLFC 0.7 gpm for 3/4	One DLFC must be used if 3/4" fitting is used
	V3162-010	WS1 DLFC 1.0 gpm for 3/4	
	V3162-013	WS1 DLFC 1.3 gpm for 3/4	
	V3162-017	WS1 DLFC 1.7 gpm for 3/4	
	V3162-022	WS1 DLFC 2.2 gpm for 3/4	
	V3162-027	WS1 DLFC 2.7 gpm for 3/4	
	V3162-032	WS1 DLFC 3.2 gpm for 3/4	
	V3162-042	WS1 DLFC 4.2 gpm for 3/4	
	V3162-053	WS1 DLFC 5.3 gpm for 3/4	
	V3162-065	WS1 DLFC 6.5 gpm for 3/4	
	V3162-075	WS1 DLFC 7.5 gpm for 3/4	
	V3162-090	WS1 DLFC 9.0 gpm for 3/4	
	V3162-100	WS1 DLFC 10.0 gpm for 3/4	

Valves are shipped without drain line flow control (DLFC) — install DLFC before using. Valves are shipped without 3/4" nut for drain elbow (polytube installation only) and 5/8" polytube insert (polytube installation only).




BYPASS VALVE


DRAWING #	PART #	DESCRIPTION	QTY
1	V3151	WS1 Nut 1" Quick Connect	2
2	V3150	WS1 Split Ring	2
3	V3105	O-Ring 215	2
4	V3145	WS1 Bypass 1" Rotor	2
5	V3146	WS1 Bypass Cap	2
6	V3147	WS1 Bypass handle	2
7	V3148	WS1 Bypass Rotor Seal Retainer	2
8	V3152	O-Ring 135	2
9	V3155	O-Ring 112	2
10	V3156	O-Ring 214	2

BYPASS VERTICAL ADAPTER

DRAWING #	PART #	DESCRIPTION	QTY
Not Shown	V3191-01	WS1 Bypass Vertical Adapter Assembly	2
Not Shown	V3151	WS1 Nut 1" Quick Connect	2
Not Shown	V3150	WS1 Split Ring	2
Not Shown	V3105	O-Ring 215	2



DRAIN LINE – 1"			
DRAWING #	PART #	DESCRIPTION	QTY
1	H4615	Elbow Locking Clip	1
2	V3008-02	WS1 Drain FTG 1 Straight	1
3*	V3166	WS1 Drain FTG Body1	1
4*	V3167	WS1 Drain FTG Adapter	1
5*	V3163	O-Ring 019	1
6*	V3150	WS1 Split Ring	1
7*	V3151	WS1 Nut 1" QC	1
8*	V3105	O-Ring 215	1
9	V3190-090	WS1 DLFC 9.0 gpm for 1	One DLFC must be used if 1" fitting is used
	V3190-100	WS1 DLFC 10.0 gpm for 1	
	V3190-110	WS1 DLFC 11.0 gpm for 1	
	V3190-130	WS1 DLFC 13.0 gpm for 1	
	V3190-150	WS1 DLFC 15.0 gpm for 1	
	V3190-170	WS1 DLFC 17.0 gpm for 1	
	V3190-200	WS1 DLFC 20.0 gpm for 1	
	V3190-250	WS1 DLFC 25.0 gpm for 1	



SPECIFICATIONS

ACID NEUTRALIZER CAPABILITIES						
Model:	EQA-1054	EQB-1054	EQC-1054	EQA-1354	EQB-1354	EQC-1354
Media Included (Cu. Ft.)	Calcite 1.5	Calcite / Corosex 1.1 / 0.4	Calcite / Corosex 0.75 / 0.75	Calcite 2.5	Calcite / Corosex 1.75 / 0.75	Calcite / Corosex 1.25 / 1.25
Gravel (Lbs.)	20	20	20	25	25	25
pH Range	6.0-6.9	5.6-6.0	5.5 or less	6.0-6.9	5.6-6.0	5.5 or less
Max. Service Flow (GPM)	5	5	5	7	7	7
Min.-Max. Operating Pressure (PSI)	25-100	25-100	25-100	25-100	25-100	25-100
Min.-Max. Operating Temp. (°F)	40-100	40-100	40-100	40-100	40-100	40-100
Plumbing Size:	1"	1"	1"	1"	1"	1"
Total Dimensions: • Valve & Media Tank (Width x Height)	10"x64"	10"x64"	10"x64"	13"x64"	13"x64"	13"x64"

CARBON FILTER CAPABILITIES			
Model:	EN-1044	EN-1054	EN-1354
Media Included (Cu. Ft.)	Granular Activated Carbon 1.0	Granular Activated Carbon 1.3	Granular Activated Carbon 2.0
Gravel (Lbs.)	15	20	25
pH Range	4.0-10	4.0-10	4.0-10
Max. Service Flow (GPM)	4	6	8
Min.-Max. Operating Pressure (PSI)	25-100	25-100	25-100
Min.-Max. Operating Temp. (°F)	40-100	40-100	40-100
Plumbing Size:	1"	1"	1"
Total Dimensions: • Valve & Media Tank (Width x Height)	10"x64"	10"x64"	13"x64"

