

# MISTRAL

Ultrasonic humidifiers  
of small size and capacity



## **WARNING**

Read and fully understand user manual before using this device.

**Failure to follow these instructions can result in**



# CONTENTS

<b>IMPORTANT INFORMATION</b> .....	<b>7</b>
<b>IMPORTANT SAFETY INFORMATION</b> .....	<b>8</b>
<b>SAFETY INFORMATION RELATING TO THE PRODUCT</b> .....	<b>9</b>
<b>SAFETY INFORMATION RELATED TO HEALTH AND HYGIENE</b> .....	<b>10</b>
<b>1. INTRODUCTION</b> .....	<b>11</b>
<b>1.1 Description</b> .....	<b>11</b>
<b>1.2 Product overview</b> .....	<b>11</b>
<b>1.3 Available models</b> .....	<b>11</b>
<b>1.4 Applications</b> .....	<b>11</b>
<b>1.5 Main features</b> .....	<b>12</b>
<b>1.5.1 Electronic control features</b> .....	<b>12</b>
<b>1.5.2 I/O specifications</b> .....	<b>12</b>
<b>1.6 Accessories</b> .....	<b>12</b>
<b>1.6.1 Reverse osmosis system (example)</b> .....	<b>13</b>
<b>2. TECHNICAL DATA</b> .....	<b>14</b>
<b>2.1 Humidifier technical specifications</b> .....	<b>14</b>
<b>2.1.1 I/O specifications</b> .....	<b>15</b>
<b>2.2 Power supply technical specifications</b> .....	<b>15</b>
<b>3. RECEIVING THE PRODUCT</b> .....	<b>16</b>
<b>3.1 Checking the packaging</b> .....	<b>16</b>
<b>3.1.1 Opening the packaging</b> .....	<b>16</b>
<b>3.1.2 Checking the packaging contents</b> .....	<b>16</b>
<b>4. MECHANICAL ASSEMBLY</b> .....	<b>17</b>
<b>4.1 Before you start</b> .....	<b>17</b>
<b>4.2 Information concerning installation and the surrounding environment</b> .....	<b>17</b>
<b>4.3 Dimensions</b> .....	<b>18</b>
<b>4.3.1 Dimensions of Mistral</b> .....	<b>18</b>
<b>4.3.2 Dimensions of Mistral with box</b> .....	<b>18</b>
<b>4.3.3 Dimensions of Mistral with support bracket</b> .....	<b>19</b>
<b>4.4 Minimum installation distances</b> .....	<b>20</b>
<b>4.4.1 Enclosed space</b> .....	<b>20</b>
<b>4.5 Support bracket</b> .....	<b>21</b>
<b>4.5.1 Support bracket dimensions</b> .....	<b>21</b>
<b>4.5.2 Precautions for mounting with a support bracket</b> .....	<b>21</b>
<b>4.6 Method of mounting with a support bracket</b> .....	<b>22</b>
<b>4.7 Metal box</b> .....	<b>23</b>
<b>4.7.1 Dimensions of metal box</b> .....	<b>23</b>
<b>4.7.2 Precautions for mounting with metal box</b> .....	<b>23</b>
<b>4.8 Method of mounting with box</b> .....	<b>24</b>



# CONTENTS

4.8.1 Installation on a wall.....	24
4.8.2 Installation on a supporting base.....	25
4.9 Installing the power supply unit .....	25
<b>5. INSTALLING THE PLUMBING .....</b>	<b>26</b>
5.1 Humidifier composition .....	26
5.1.1 Top and front.....	26
5.1.2 Bottom .....	26
5.2 Installing the plumbing .....	26
5.2.1 Water specifications.....	26
5.3 Water drainage system .....	27
5.3.1 Connection specifications.....	27
5.3.2 Drain water .....	28
5.4 Atomised water distribution .....	28
5.4.1 Vertical distribution kit.....	28
5.4.2 Intake conveyor .....	29
5.4.3 Pipe installation example.....	31
<b>6. ELECTRICAL CONNECTIONS.....</b>	<b>32</b>
6.1 Before you start .....	32
6.2 Connection best practice .....	32
6.2.1 Wiring best practices.....	32
6.2.2 Wiring guidelines.....	33
6.2.3 Guidelines for screw terminal blocks .....	33
6.2.4 Permitted cable lengths.....	33
6.3 Wiring diagram .....	34
6.4 Configurations.....	35
6.4.1 Resistive humidity sensor connection .....	35
6.4.2 Humidity sensor connection 4...20 mA.....	35
6.4.3 Humidity sensor connection 0...10 V .....	36
6.4.4 External proportional humidistat connection with signal 0...10 V.....	36
6.4.5 ON/OFF connection with humidistat or external contact .....	36
<b>7. USER INTERFACE .....</b>	<b>37</b>
7.1 Mistral user interface .....	37
7.1.1 LED .....	37
7.1.2 Keys .....	37
7.2 EV3K user interface .....	38
7.2.1 Icons.....	38
7.2.2 Touch keys .....	38
7.2.3 Main view .....	39
7.2.4 Setting and changing the setpoint .....	39
7.2.5 Maintenance menu .....	40
7.2.6 Maintenance engineer parameters .....	40



# CONTENTS

7.2.7	Accessing the parameters menu.....	41
7.2.8	Changing fan speed.....	42
7.2.9	Maximum humidity production configuration.....	42
<b>8.</b>	<b>POWER-UP AND START-UP.....</b>	<b>43</b>
8.1	Before you start .....	43
8.2	Start-up instructions.....	44
8.3	Instructions for seasonal or long-term shut-down .....	44
8.4	Checks to be carried out each time the humidifier is switched on .....	45
<b>9.</b>	<b>OPERATION.....</b>	<b>46</b>
9.1	Draining water / washing reservoir .....	46
9.2	Operating mode configuration.....	46
9.3	Fan speed configuration.....	48
9.4	Humidity setpoint configuration .....	49
9.4.1	Examples of humidity setpoint configuration.....	49
9.5	Maximum steam production configuration.....	51
9.6	Temperature sensor .....	51
9.7	Humidity adjustment .....	52
9.7.1	ON/OFF regulator.....	52
9.7.2	External proportional regulator with 0...10 V input .....	53
9.7.3	Regulator with humidity sensor.....	54
9.8	Recording hours of operation.....	54
9.8.1	Mist-maker operating hours: partial number .....	54
9.8.2	Fan operating hours: partial number.....	54
9.9	Parallel operation .....	55
<b>10.</b>	<b>MASTER/SLAVE CONFIGURATION.....</b>	<b>56</b>
10.1	Introduction .....	56
10.2	Operating modes .....	56
10.2.1	Master/Slave   Independent Mistral operation .....	57
10.2.2	Master/Slave   Parallel Mistral operation.....	57
10.2.3	Master/Slave   Rotational Mistral operation .....	57
10.2.4	Master/Slave   Balancing Mistral operation .....	57
10.2.5	Master/Slave   Mistral in maintenance.....	57
10.3	EPJC user interface .....	58
10.3.1	Humidifier grid view.....	58
10.3.2	Viewing the screen for a single Mistral .....	59
10.3.3	Setting and changing the setpoint.....	59
10.3.4	Changing the maximum humidity production.....	59
10.3.5	Changing fan speed.....	59
10.4	EPJC general menu .....	60
10.5	EPJC user menu .....	61



# CONTENTS

10.5.1	Humidifier connection .....	62
10.5.2	Setting master/slave operating mode.....	63
10.5.3	Selecting the master humidifier .....	64
10.6	EPJC maintenance menu .....	65
10.6.1	Changing the parameters.....	65
10.6.2	Humidifier maintenance .....	66
10.7	Changing the date and time.....	66
10.8	Single Mistral screen .....	67
10.8.1	Mistral in alarm mode.....	67
10.8.2	Operating hours .....	68
10.8.3	List of alarms in progress .....	68
10.8.4	Alarm history .....	69
10.9	Single Mistral menu .....	69
10.10	Single Mistral user menu.....	69
10.11	Single Mistral maintenance menu .....	70
10.11.1	Maintenance engineer parameters.....	71
10.11.2	Displaying/resetting the operating hours .....	71
10.11.3	Resetting the alarm history .....	71
10.11.4	Testing of outputs .....	72
10.11.5	Restoring factory settings .....	72
10.12	Lost connection.....	72
10.13	Master/Slave connection procedure.....	72
11	MAINTENANCE.....	73
11.1	Introduction .....	73
11.2	Periodically checking the status of the humidifier .....	73
11.3	Cleaning the Reservoir .....	74
11.4	Guidelines for cleaning and detergents.....	75
11.4.1	Permitted products and detergents.....	75
11.5	Replacing mist-maker ceramic discs .....	76
12	SPARE PARTS .....	77
13	ADJUSTMENT PARAMETERS .....	78
13.1	Table of Mistral adjustment parameters.....	78
13.2	EPJC configuration parameters table (master/slave).....	80
14	MODBUS RTU FUNCTIONS AND RESOURCES.....	81
14.1	Introduction .....	81
14.2	Modbus message structure.....	81
14.3	Modbus functions and registers .....	81
14.3.1	Available Modbus commands and data areas .....	82
14.4	Address configuration.....	82



# CONTENTS

<b>14.5</b>	<b>Connections</b>	<b>82</b>
<b>14.6</b>	<b>Modbus tables content</b>	<b>82</b>
<b>14.7</b>	<b>Mistral modbus addresses</b>	<b>83</b>
14.7.1	Modbus address table	83
14.7.2	Modbus resource table	84
<b>14.8</b>	<b>EPJC modbus addresses (master/slave)</b>	<b>86</b>
14.8.1	Modbus address table	86
<b>15. DIAGNOSTICS</b>		<b>87</b>
<b>15.1</b>	<b>Alarms table (LED interface)</b>	<b>87</b>
15.1.1	Warnings	87
15.1.2	Alarms	87
15.1.3	High or low humidity alarm	88
15.1.4	Level sensor alarm	88
15.1.5	Water alarm	88
<b>15.2</b>	<b>Alarms table (EV3K interface)</b>	<b>88</b>
<b>16. WIRING DIAGRAM</b>		<b>91</b>

# IMPORTANT INFORMATION

## Liability and residual risks

ELSTEAM assumes no liability for any damage caused by the following (by way of example; this is not an exhaustive list):

- Installation/use for purposes other than those specified and, in particular, not adhering to the safety provisions set out by current regulations in the country in which the product is installed and/or contained in this manual;
- Use in appliances that do not guarantee sufficient protection against electric shocks, water and dust within the installation conditions created;
- Use in appliances that allow access to hazardous parts without the use of a keyed or tooled locking mechanism when accessing the instrument;
- Tampering and/or modifying the product;
- Installation/use in appliances which do not comply with current regulations in the country in which the product is installed.

The customer/manufacturer is responsible for ensuring their machine complies with these regulations.

ELSTEAM's responsibility is limited to the correct and professional use of the product in accordance with regulations and the instructions contained in this manual and other product support documents.

To comply with EMC standards, observe all the electrical connection instructions. As it depends on the wiring configuration as well as the load and the installation type, compliance must be verified for the final machine as specified by the relevant product standard.

## Disclaimer

This document is the exclusive property of ELSTEAM. It contains a general description and/or a description of the technical specifications for the services offered by the products listed herein. This document should not be used to determine the suitability or reliability of these products in relation to specific user applications. Each user or integration specialist should conduct their own complete and appropriate risk analysis, in addition to carrying out a product evaluation and test in relation to its specific application or use. Users can send us comments and suggestions on how to improve or correct this publication.

Neither ELSTEAM nor any of its associates or subsidiaries shall be held responsible or liable for improper use of the information contained herein.

ELSTEAM has a policy of continuous development; therefore, ELSTEAM reserves the right to make changes and improvements to any product described in this document without prior notice.

The images in this document and other documentation supplied with the product are provided for illustrative purposes only and may differ from the product itself.

The technical data in this manual is subject to change without prior notice.

## Terms and Conditions of use

### Permitted use

The device should only be used for humidification.

The device must be installed and used in accordance with the instructions provided and, in particular, hazardous live parts must not be accessible under normal conditions.

The device must be suitably protected from water and dust with regard to its application and must also only be accessible with the aid of a tool.


Only qualified personnel may install the product or perform technical support procedures on it.

The customer must only use the product as described in the documentation relating to that product.

### Prohibited use

Any use other than those described in the "**Permitted use**" section and in the product support documentation is prohibited.

## Disposal



The device must be disposed of in accordance with local regulations regarding the collection of electrical and electronic appliances.

## Consider the environment



The company works towards protecting the environment, while taking account of customer requirements, technological innovations in materials and the expectations of the community to which we belong. ELSTEAM places great importance on respecting the environment, encouraging all associates to become involved with company values and guaranteeing safe, healthy and functional working conditions and workplaces.

**Please consider the environment before printing this document.**

# IMPORTANT SAFETY INFORMATION

Please read this document carefully before installation; study all the warnings before using the device. Only use the device in accordance with the methods described in this document. The following safety messages may be repeated several times in the document, to provide information regarding potential hazards or to attract attention to information which may be useful in explaining or clarifying a procedure.

## SYMBOLS



This symbol is used to indicate a risk of electric shock.  
It is a safety indication and as such, should be observed to avoid potential accidents or fatalities.



This symbol is used to indicate a risk of serious personal injury.  
It is a safety indication and as such, should be observed to avoid potential accidents or fatalities.



This symbol is used to indicate a serious risk of exposure to biological agents.  
It is a safety indication and as such, should be observed to avoid potential accidents or fatalities.

## SAFETY MESSAGES

### **DANGER**

**DANGER** indicates a situation of imminent danger which, if not avoided, **will lead to death or serious injury**.

### **WARNING**

**WARNING** indicates a situation of imminent danger which, if not avoided, **may lead to death or serious injury**.

### **CAUTION**

**CAUTION** indicates a potentially hazardous situation which, if not avoided, **could cause minor or moderate injury**.

### **NOTICE**

**NOTICE** indicates a situation not related to physical injuries but which, if not avoided, could damage the equipment.

**NOTE:** the maintenance, repair, installation and use of the equipment must only be entrusted to qualified personnel.

## QUALIFIED PERSONNEL

Only suitably trained and experienced personnel capable of understanding the content of this manual and all documentation regarding the product are authorised to work on and with this equipment. Furthermore, the personnel must have completed courses in safety and must be able to recognise and prevent the implied dangers. The personnel must have suitable training, knowledge and experience at a technical level, and be capable of anticipating and detecting potential risks caused by using the product, as well as changing the settings and modifying the mechanical, electric and electronic equipment for the entire system in which the product is used. All personnel working on and with the product must be entirely familiar with the relevant standards and directives, as well as safety regulations.

The unit must **not** be used by persons (including children) with reduced physical, sensory or mental capabilities or persons with no experience or knowledge.

# SAFETY INFORMATION RELATING TO THE PRODUCT

Before carrying out any work on the equipment, read these instructions carefully, making sure you understand everything.

## **DANGER**

### **RISK OF ELECTRIC SHOCK OR ELECTRIC ARC**

- Only use electrically insulated measuring devices and equipment.
- Do not install the equipment while the power supply is connected.
- Cut off the power supply to all equipment, including any connected devices, and remove the power fuses before removing any covers or hatches, or before installing/uninstalling accessories, hardware, cables or wires.
- Always use a properly calibrated Voltmeter to make sure the system is powered off.
- The maintenance, repair, installation and use of the equipment must only be entrusted to qualified personnel.
- Do not touch the unshielded components or the terminals while they are live.
- Do not modify the product.
- Do not expose the equipment to liquids or chemicals.
- Make sure there is an effective earth connection; if there is not, earth the equipment.
- Before powering up the equipment, check all the wiring connections.

## **DANGER**

### **RISK OF ELECTRIC SHOCK AND FIRE**

- Do not use the device with loads greater than those indicated in the technical data section.
- Do not exceed the temperature and humidity ranges indicated in the technical data section.
- Provide safety interlocks (isolators for all "undervoltage category 3" poles) of a suitable size between the power supply and the humidifier.
- Only use cables with a suitable cross-section as indicated in the section "Wiring best practices".

## **DANGER**

### **RISK OF ELECTRIC SHOCK, EXPLOSION OR FIRE**

- Install the humidifier away from electronic equipment.
- Do not install the humidifier above electronic equipment.

## **WARNING**

### **MALFUNCTIONING OF THE EQUIPMENT**

- Perform the wiring carefully, in compliance with electromagnetic compatibility and safety requirements.
- Make sure the wiring is correct for the end application.
- Minimise the length of the connections as much as possible, to avoid winding the cables around electrically connected parts.
- Before applying the power supply, check all the wiring connections.
- Do not connect wires to unused terminals and/or terminals marked with the text "No connection" ("N.C").

## **WARNING**

### **REGULATORY INCOMPATIBILITY**

Make sure all the equipment used and systems designed conform to current local, regional and national standards.

# SAFETY INFORMATION RELATED TO HEALTH AND HYGIENE

## HEALTH AND HYGIENE

The Mistral humidifier features:

- Automatic draining for inactivity;
- Periodic automatic cleaning;
- Plastic material on whose surface bacterial colonies do not proliferate.

Inadequate use and/or poor maintenance of the humidifier can damage your health.



**WARNING**

### BIOLOGICAL RISK

- In the event of inadequate use and/or poor maintenance it is possible that microorganisms (including the bacterium that causes Legionellosis) may proliferate and be transferred into the air treatment system or the surrounding environment.
- The humidifier must be used properly and be maintained and cleaned properly at prescribed intervals, as described in chapter "**11. MAINTENANCE**" ON PAGE 73.

# 1. INTRODUCTION


## 1.1 Description

The **Mistral** humidifier is the ELSTEAM solution for compact ultrasonic adiabatic humidification systems.

The **Mistral** humidifier generates humidity by breaking up the molecules of the water contained in the reservoir and producing mist through the energy transferred by ultrasonic ceramic transducers.

The water is atomised by oscillating the surface of the transducers in contact with the water using a high frequency signal which generates a column of water above the transducers. During the negative amplitude of the transducer (the surface of the transducer oscillates at high speed), water bubbles are produced that collide with each other during the positive amplitude phase, resulting in water mist that is introduced into the room by the air flow generated by the fan. The mist (humidity) is introduced into the room via a rigid tube.

## 1.2 Product overview



Reference	Description
①	Atomised water outlet
②	Suction fan
③	LED user interface
④	Switching power supply unit 230 Vac - 24 Vac/dc
⑤	Water reservoir
⑥	Box for mounting on a wall or on the base (optional)
⑦	Water outlet solenoid valve
⑧	Water inlet solenoid valve
⑨	Outlet manifold

Fig. 1. Overview of **Mistral** humidifier with box

## 1.3 Available models

Code	Description
EHUC001M2	Mistral - production capacity 1 kg/h

## 1.4 Applications

**Mistral** is mainly used in applications including:

- Storage rooms:
  - Display of fresh produce;
- Food stores;
- Cold rooms and units for temperature, humidity and maturation;
- Wine cellars;
- Air-conditioning with fan convectors.

## 1.5 Main features

- Adiabatic humidifier with low energy consumption;
- Constant and efficient production;
- Small footprint fits in small spaces (1 kg/h unit);
- Electronic control:
  - Via external signal ON/OFF, 0...10 V;
  - Incorporated via 4...20 mA, 0...10 V sensor or resistive;
- Water leakage protection system.

### 1.5.1 Electronic control features

- Proportional control of production of humidity:
  - High efficiency;
  - Rapid response to changes in requirements;
  - Precise production control.
- Protection against no inlet water;
- Automatic draining:
  - Removes scale build-up in the reservoir;
- Signals operating status via LED interface:
  - Continuous monitoring of the operating status;
  - Viewing alarms.

### 1.5.2 I/O specifications

- Analogue/digital input: configurable by **CFG** parameter;
- Digital input: manages enabling operation from an external signal;
- Digital output: manages an alarm or is a command for parallel configuration;
- RS-485 serial: serial link for communicating with remote user interface (see **"1.6 ACCESSORIES" ON PAGE 12**).


## 1.6 Accessories

The following accessories are available for the **Mistral** range of ultrasonic humidifiers:

P/n	Description
<b>EHUK007</b>	Mistral metal support bracket
<b>EHUK008</b>	Mistral metal box
<b>EHUK009</b>	Intake kit
<b>EHUK011</b>	Drain kit
<b>UHFK02</b>	Vertical distribution kit Ø50 mm Mistral
<b>EHR0012</b>	Reverse osmosis system 12 l/h
<b>EVHTP520</b>	Humidity and temperature sensor, proprietary signal
<b>EVHP523</b>	Humidity sensor with 4...20 mA output
<b>0031000043</b>	Inlet tube 8 mm (per metre)
<b>EV3K61XLESRB</b>	Remote user interface 74x32 mm, 4 touch keys, two-line LED display, 24 Vdc power supply
<b>EHR0012</b>	Reverse osmosis water treatment system, 12 l/h
<b>EHR0020</b>	Reverse osmosis water treatment system, 20 l/h

### 1.6.1 Reverse osmosis system (example)

The image is provided for illustrative purposes only and may differ from the product itself.



*Fig. 2. Reverse osmosis system (example)*

## 2. TECHNICAL DATA

### 2.1 Humidifier technical specifications

TYPE	MU	DESCRIPTION/VALUE
<b>HUMIDITY PRODUCTION</b>		
Production capacity:	kg/h	0.20...1.0
Connection outside diameter:	mm (in.)	50 (1.97)
Maximum air flow rate:	m <sup>3</sup> /h	50
Maximum pressure:	Pa	1...90
Mist distribution:	---	See accessory <b>UHFk02</b>
<b>ELECTRICAL PROPERTIES</b>		
Power supply:	V, Hz	85...264 Vac, 50/60 Hz
Power absorbed:	W	108 W
Current draw:	A	4.5 A
Auxiliary power supply:	V	24 Vdc
<b>Hydraulic properties</b>		
Supply water quality:	---	Reverse osmosis treated water or drinking water <b>SEE "5.2.1 WATER SPECIFICATIONS" ON PAGE 26</b>
Supply water conductivity:	µS/cm	<ul style="list-style-type: none"> <li>• 0...100 (low maintenance)</li> <li>• 0...1250 (general operation)</li> </ul>
Supply water hardness:	°f	<ul style="list-style-type: none"> <li>• 0...5 (low maintenance)</li> <li>• 0...40 (general operation)</li> </ul>
Supply water pressure:	MPa (bar)	0.02...1 (0.2...10)
Minimum supply flow rate	L/m	1
Supply water connection:	---	JG 8 mm
Drain water connection:	---	Ø10-12 mm
Supply water temperature:	°C/°F	1...40 °C (33.8...104 °F)
Drain water temperature:	°C/°F	1...60 °C (33.8...140 °F)
<b>General specifications</b>		
Ambient operating conditions:	°C/°F, %	1...50 °C (33.8...122 °F) 10 ... 90 % non-condensing
Transportation and storage conditions:	°C/°F, %	10...60 °C (50...140 °F) 10 ... 90 % non-condensing
Dimensions:	mm (in.)	<b>SEE "4.3 DIMENSIONS" ON PAGE 18</b>
Weight:	kg	~1.4
IP protection degree for the humidifier body (not including power supply unit):	---	IP30 (once plumbing is complete)
<b>Regulation</b>		
Control type:	---	Integrated
Control signal:	---	<ul style="list-style-type: none"> <li>• ON/OFF</li> <li>• 0...10 V (or proportional)</li> <li>• 4...20 mA</li> </ul>
<b>Communication serial port</b>		
Serial port:	---	1 RS-485 Modbus RTU serial port
<b>COMPLIANCE</b>		
CE certification:	---	√

### 2.1.1 I/O specifications

Type	Description
Analogue input:	1 configurable analogue input (CFG = 1...4 or CFG = 6...9)
Digital input:	1 digital input with a potential-free contact for enabling humidification 1 configurable digital input (CFG = 0 or CFG = 5)
Digital output:	1 non-isolated low-voltage relay output

#### Analogue input specifications

	Default	Resistive RH	Current 4...20 mA	Voltage 0...10 V	Digital input
IA1	Temperature alarm sensor	•	•	•	•
Range	---	-40...105 °C (-40...220 °F)	1% full scale	1% full scale	---
Solution	---	0.1 °C (1 °F)	0.1	0.1	---
Input impedance	---	10 kΩ	100 Ω	24 kΩ	---

#### Digital output specifications

	Default	Description	Load (at 30 Vdc)	Load type
Out1	Alarm or command for parallel operation	SPDT	1 A	Resistive

## 2.2 Power supply technical specifications

Type	Description
The product complies with the following harmonised standards:	IEC/EN 60335-1 and IEC/EN61558-1, EN61558-2-16
Device construction:	Incorporated electronic device
Overvoltage category:	III
Power supply input:	85...264 Vac, 50/60 Hz
Power supply output:	21.6...28.8 Vdc, 4.5 A maximum (Default: 28 Vdc)
Nominal output power:	108 W
Ambient operating conditions:	-30 ... 70 °C (-22 ... 158 °F) 20 ... 90 % RH non-condensing
Transportation and storage conditions:	-40 ... 85 °C (-40 ... 185 °F) 10 ... 95 % RH non-condensing
Maximum operating temperature in an enclosed space:	70 °C (158 °F) without forced ventilation

## 3. RECEIVING THE PRODUCT

### CAUTION

#### IMPROPER HANDLING

- Use all necessary personal protective equipment (PPE), such as safety gloves and shoes, while handling packaging and unpacking.
- Follow the handling instructions given in this manual and any other documentation associated with the product.
- Handle and store the product in its original packaging.
- Do not handle or store the product if the packaging is or seems to be damaged.
- Take all necessary measures to avoid damaging the product and prevent other hazards while handling or opening the packaging.

### NOTICE

#### UNEXPECTED EQUIPMENT OPERATION

- Droppages and shocks can damage the humidifier beyond repair.
- Tampering with or removing the identification stickers invalidates the warranty.

### 3.1 Checking the packaging

- Make sure the packaging is intact;
- Make sure the humidifier is intact upon delivery and inform the courier immediately, in writing, of any problems caused by careless or improper transportation (accept the package conditionally).

#### 3.1.1 Opening the packaging

- Take the package to the humidifier installation site;
- Open the cardboard packaging;
- Remove the humidifier from the die-cut separator.

#### 3.1.2 Checking the packaging contents

The standard product package contains:

- **Mistral** ultrasonic humidifier;
- Instruction sheet for:
  - Mechanical assembly;
  - Electrical connections;
  - Start-up instructions;
- Switching power supply unit 85...264 Vac / 21.6...28.8 Vdc 108 W, and wiring.

## 4. MECHANICAL ASSEMBLY

### 4.1 Before you start

Read this manual carefully before installing the system.

In particular, the safety instructions, electrical requirements and current regulations for the machine or the process in which this device is involved must be observed. The use and application of the information contained herein requires experience in the design and programming of automated control systems. Only the user, integrator or manufacturer of the machine can be familiar with all the conditions and factors which arise during installation and configuration, operation and maintenance of the machine or the process, and as such can identify the relevant automation equipment and the corresponding interlocks and safety systems which can be used effectively and appropriately. When selecting automation and control equipment and other connected equipment and software, for a particular application, you must consider all applicable local, regional and national standards and/or regulations.

#### **WARNING**

##### **REGULATORY INCOMPATIBILITY**

Make sure all the equipment used and the systems conform to all applicable local, regional and national regulations and standards.

### 4.2 Information concerning installation and the surrounding environment

Before carrying out any work on the equipment, read these instructions carefully, making sure you understand everything.

#### **DANGER**

##### **RISK OF ELECTRIC SHOCK OR ELECTRIC ARC**

- Only use electrically insulated measuring devices and equipment.
- Do not install the equipment while the power supply is connected.
- Cut off the power supply to all equipment, including any connected devices, and remove the power fuses before removing any covers or hatches, or before installing/uninstalling accessories, hardware, cables or wires.
- Always use a properly calibrated Voltmeter to make sure the system is powered off.
- The maintenance, repair, installation and use of the equipment must only be entrusted to qualified personnel.
- Do not touch the unshielded components or the terminals while they are live.
- Do not modify the product.
- Do not expose the equipment to liquids or chemicals.
- Make sure there is an effective earth connection; if there is not, earth the equipment.
- Before powering up the equipment, check all the wiring connections.

#### **WARNING**

##### **MALFUNCTIONING OF THE EQUIPMENT**

- Perform the wiring carefully, in compliance with electromagnetic compatibility and safety requirements.
- Make sure the wiring is correct for the end application.
- Minimise the length of the connections as much as possible, to avoid winding the cables around electrically connected parts.
- Before applying the power supply, check all the wiring connections.
- Do not connect wires to unused terminals and/or terminals marked with the text "No connection" (N.C.).

### 4.3 Dimensions

#### 4.3.1 Dimensions of Mistral




Fig. 3. Dimensions of Mistral

#### 4.3.2 Dimensions of Mistral with box





Fig. 4. Dimensions of Mistral with box

### 4.3.3 Dimensions of Mistral with support bracket



**Fig. 5.** Dimensions of **Mistral** with support bracket

#### 4.4 Minimum installation distances

When installing the **Mistral** humidifier in enclosed spaces, observe the minimum distance of 500 mm (19.68 in.) on each side, so as to guarantee adequate ventilation and aeration of the system.


### ⚠ WARNING

#### MALFUNCTIONING OF THE EQUIPMENT

- Install the equipment in a position which ensures the minimum distances from all adjacent structures and equipment as indicated in this document.
- Install all equipment in compliance with the technical specifications indicated in the relevant documentation.

#### 4.4.1 Enclosed space

In the case of an installation in an enclosed space (e.g. fan convector or integration in a technical product) ensure that there is sufficient air circulation to avoid overheating and condensation.



**Fig. 6.** Minimum installation distances

## 4.5 Support bracket

The **Mistral** humidifier can be installed on a wall with the aid of a support bracket supplied as an accessory (see “**1.6 ACCESSORIES**” ON PAGE 12).

### 4.5.1 Support bracket dimensions

The following illustration shows the dimensions of the optional support bracket to be used for wall mounting:




Fig. 7. Support bracket dimensions

### 4.5.2 Precautions for mounting with a support bracket

**⚡ ⚠ DANGER**

**RISK OF ELECTRIC SHOCK, EXPLOSION OR FIRE**

- Install the humidifier away from electronic equipment.
- Do not install the humidifier above electronic equipment.

**⚡ ⚠ DANGER**

**RISK OF ELECTRIC SHOCK**

Make sure there is an effective earth connection.

## 4.6 Method of mounting with a support bracket




Fig. 8. Instructions for mounting with a support bracket

### Instructions

- Secure the support bracket to the wall following the instructions given in the picture **"FIG. 8. INSTRUCTIONS FOR MOUNTING WITH A SUPPORT BRACKET"** ON PAGE 22 and the dimensions of the holes and bracket given in the subsection **"4.5.1 SUPPORT BRACKET DIMENSIONS"** ON PAGE 21 (1);
- Attach the **Mistral** humidifier to the bracket, making sure it is secure (2);
- Make provision for an earthing connection via eyelet terminals between the support bracket and the humidifier;
- Secure the humidifier to the wall, where the support bracket is mounted, and the earthing connection using an **M4** flat-head screw, which is appropriate for the fixing wall (3).

## 4.7 Metal box

The **Mistral** humidifier can be installed on a wall or on a supporting base with the aid of the metal box supplied as an accessory (see “1.6 ACCESSORIES” ON PAGE 12).

### 4.7.1 Dimensions of metal box

The following illustration shows the dimensions of the optional metal box to be used for mounting on a wall or on a supporting base:




Fig. 9. Dimensions of metal box

### 4.7.2 Precautions for mounting with metal box

**⚡ ⚠ DANGER**

**RISK OF ELECTRIC SHOCK, EXPLOSION OR FIRE**

- Install the humidifier away from electronic equipment.
- Do not install the humidifier above electronic equipment.

**⚡ ⚠ DANGER**

**RISK OF ELECTRIC SHOCK**

Make sure there is an effective earth connection.

## 4.8 Method of mounting with box

The **Mistral** humidifier can be installed on a wall or on a supporting base with the aid of the box supplied as an accessory (see “1.6 ACCESSORIES” ON PAGE 12)

### 4.8.1 Installation on a wall




Fig. 10. Instructions for mounting the box on a wall

#### Instructions

- Secure the box to the wall following the instructions given in the picture “**FIG. 10. INSTRUCTIONS FOR MOUNTING THE BOX ON A WALL**” ON PAGE 24 and the dimensions of the holes and box given in the subsection “**4.3.2 DIMENSIONS OF MISTRAL WITH BOX**” ON PAGE 18 **(1)**;
- Attach the **Mistral** humidifier to the box, making sure it is secure **(2)**;
- Secure the humidifier to the wall where it is mounted using an M4 flat-head screw and a washer suitable for the fixing wall **(3)**.

## 4.8.2 Installation on a supporting base




Fig. 11. Instructions for mounting the box on a supporting base

### Instructions

- Secure the box to the base following the instructions given in the picture **“FIG. 11. INSTRUCTIONS FOR MOUNTING THE BOX ON A SUPPORTING BASE” ON PAGE 25** and the dimensions of the holes and box given in the subsection **“4.3.2 DIMENSIONS OF MISTRAL WITH BOX” ON PAGE 18 (1)**;
- Attach the **Mistral** humidifier to the box, making sure it is secure **(2)**.

## 4.9 Installing the power supply unit

The power supply unit must be installed in an electrical cabinet that is fully protected from water and dust, and should only be accessible to qualified personnel equipped with a suitable tool.

## 5. INSTALLING THE PLUMBING

### 5.1 Humidifier composition

#### 5.1.1 Top and front

The top and front of the **Mistral** humidifier consists of:

- Humidity outlet;
- Fair air intake;
- LED user interface.

#### 5.1.2 Bottom

The bottom of the **Mistral** humidifier consists of

- Water outlet solenoid valve;
- Water inlet solenoid valve;
- Electrical connections.

### 5.2 Installing the plumbing

For proper hydraulic installation and optimal operation of the humidifier, make provision for:

- A shut-off tap;
- A pressure reducer (if the mains pressure exceeds 1 MPa (10 bar)).

**NOTE:** if using a pressure reducer, make sure it is effective and does not cause any drastic pressure drops when the mains pressure is very low.

#### NOTICE

##### MALFUNCTIONING OF THE EQUIPMENT

The water supply must have a minimum pressure of 0.02 MPa (0.2 bar).

#### 5.2.1 Water specifications

#### NOTICE

##### MALFUNCTIONING OF THE EQUIPMENT

- Only use inlet water supplied from a reverse osmosis treatment system, or drinking water fit for human consumption.
- No other type of water may be used in the Mistral humidifier.

#### Optimal operating characteristics

- Water pressure of 0.02...1 MPa (0.2...10 bar) with an assured minimum flow rate of 1 l/min;
- Inlet water temperature between 1...40 °C (33.8...104 °F) inclusive;
- Conductivity between 0...100 µS/cm inclusive;
- Maximum water hardness between 0...5 °f.

**NOTE:** using inlet water with the above characteristics supports reduced maintenance frequency.

#### General operating characteristics

- Water pressure of 0.02...1 MPa (0.2...10 bar) with an assured minimum flow rate of 1 l/min;
- Inlet water temperature between 1...40 °C (33.8...104 °F) inclusive;
- Conductivity between 0...1250 µS/cm inclusive;
- Maximum water hardness between 0...40 °f.

**NOTE:** higher water hardness or a higher level of organic matter does not preclude proper equipment operation, nevertheless these factors mean that more frequent maintenance will be required.

#### What should you do?

- Let the water flow through the drain for a few hours before making the final connection.
- Periodically check the state of repair of the JG connection of the inlet solenoid valve (see "**11.2 PERIODICALLY CHECKING THE STATUS OF THE HUMIDIFIER**" ON PAGE 73).

#### What should you **NOT** do?

- Do not use well water or water with a hardness greater than 40 °f;

## NOTICE

### MALFUNCTIONING OF THE EQUIPMENT

- Do not use well water.
- Once the humidifier has been installed, let the remaining water in the pipes flow out to prevent the inlet solenoid valve from becoming clogged.
- Make sure the humidifier parts are perfectly intact.
- If any of the humidifier parts are not intact, do not proceed with installation.

**NOTE:** in the case of particularly hard water, you can purchase the optional demineralisation KIT **EHRO012**.

## 5.3 Water drainage system


## NOTICE

### MALFUNCTIONING OF THE EQUIPMENT

Size the drain pipe correctly in order to prevent blockages and clogging during automatic cleaning.

#### 5.3.1 Connection specifications

- Minimum diameter 10...12 mm (0.39...0.47 in.);
- A minimum average slope of 45° and no siphons.



**Fig. 12.** Outlet and drain pipe characteristics

To eliminate any debris and/or residues/process substances, flush out the water supply lines.

## NOTICE

### MALFUNCTIONING OF THE EQUIPMENT

After installation, flush out the water supply line, directing the water directly into the outlet without introducing it into the humidifier.

#### 5.3.2 Drain water


As the drain water is non-toxic and non-contaminated, it can be drained into the clean water collection system, as defined by local, regional and national regulations and standards in force.

### 5.4 Atomised water distribution

The atomised water can be distributed via:

- Vertical distribution kit;
- Conveyor.


#### 5.4.1 Vertical distribution kit



**Fig. 13.** Vertical distribution kit


## 5.4.2 Intake conveyor

With fan




**Fig. 14.** Conveyor with fan

	Air flow rate for bypass
Intake conveyor with fan	10...60 m <sup>3</sup> /h



**Fig. 15.** Conveyor without fan

### 5.4.3 Pipe installation example



**Fig. 16.** Pipe installation example

## 6. ELECTRICAL CONNECTIONS

### 6.1 Before you start

Read this manual carefully before installing the equipment.

In particular, the safety instructions, electrical requirements and current regulations for the machine or the process in which this device is involved must be observed.

The use and application of the information contained herein requires experience in the design and installation of humidification systems. Only the user, integrator or manufacturer of the machine can be familiar with all the conditions and factors which arise during installation and configuration, operation and maintenance of the machine or the process, and as such can identify the relevant automation equipment and the corresponding interlocks and safety systems which can be used effectively and appropriately. When selecting automation and control equipment and other connected equipment and software, for a particular application, you must consider all applicable local, regional and national standards and/or regulations.

#### **DANGER**

##### **RISK OF ELECTRIC SHOCK OR ELECTRIC ARC**

- Only use electrically insulated measuring devices and equipment.
- Do not install the equipment while the power supply is connected.
- Cut off the power supply to all equipment, including any connected devices, and remove the power fuses before removing any covers or hatches, or before installing/uninstalling accessories, hardware, cables or wires.
- Always use a properly calibrated Voltmeter to make sure the system is powered off.
- The maintenance, repair, installation and use of the equipment must only be entrusted to qualified personnel.
- Do not touch the unshielded components or the terminals while they are live.
- Do not modify the product.
- Do not expose the equipment to liquids or chemicals.
- Make sure there is an effective earth connection; if there is not, earth the equipment.
- Before powering up the equipment, check all the wiring connections.

#### **WARNING**

##### **MALFUNCTIONING OF THE EQUIPMENT**

Only use the switching power supply unit supplied to power the humidifier.

#### **WARNING**

##### **REGULATORY INCOMPATIBILITY**

Make sure all the equipment used and systems designed conform to current local, regional and national standards.

### 6.2 Connection best practice

#### 6.2.1 Wiring best practices

#### **DANGER**

##### **RISK OF ELECTRIC SHOCK AND FIRE**

- Do not use the device with loads greater than those indicated in the technical data section.
- Do not exceed the temperature and humidity ranges indicated in the technical data section.
- Provide safety interlocks (isolators for all "undervoltage category 3" poles) of a suitable size between the power supply and the humidifier.
- Only use cables with a suitable cross-section as indicated in the section "Wiring best practices".

When wiring the humidifiers, observe the following instructions:

- Make sure the operating environment and conditions fall within the specified values.
- Use cables of a cross-section suited to the voltage and current requirements.

#### **DANGER**

##### **LOOSE WIRING CAUSES ELECTRIC SHOCKS AND OVERHEATING**

Tighten the connections in compliance with the technical specifications relating to tightening torques.

#### **WARNING**

##### **REGULATORY INCOMPATIBILITY**

Make sure all the equipment used and systems designed conform to current local, regional and national standards.

### 6.2.2 Wiring guidelines

When wiring the controllers, observe the following standards:

- The I/O and communication wiring must be kept separate from the power supply wiring. These two types of wiring must be routed in separate ducts.
- Make sure the operating environment and conditions fall within the specified values.
- Use wires with the correct diameter, suited to the voltage and current requirements.
- Use copper conductors (compulsory).
- Use shielded twisted pair cables for analogue/digital I/O connections.

Use correctly earthed shielded cables for all analogue inputs and for communication connections. If shielded cables are not used for these connections, electromagnetic interference may cause signal degradation. Degraded signals can result in unpredictable operation of the controller or the modules and connected equipment.

### ⚠ WARNING

#### MALFUNCTIONING OF THE EQUIPMENT

- Perform the wiring carefully and in compliance with electromagnetic compatibility and safety requirements.
- Make sure the wiring is correct for the end application.
- Minimise the length of the connections as much as possible, to avoid winding the cables around electrically connected parts.
- Before applying the power supply, check all the wiring connections.
- Do not connect cables to unused terminals and/or terminals marked with the text "No connection" (N.C.).

### 6.2.3 Guidelines for screw terminal blocks

#### Suitable wiring for the power supply

### ⚡ ⚠ DANGER

#### RISK OF ELECTRIC SHOCK

- Cut off the power supply to all equipment, including any connected devices, before removing any covers or hatches, or before installing/uninstalling accessories, hardware, fuses, cables or wires.
- Always use a properly calibrated Voltmeter to make sure the system is powered off.

#### Step 5.08 mm (0.199 in.)

									 Ø 3.5 mm (0.14 in.)	 Nm 0.5...0.6 lb-in. 4.42...5.31
	mm <sup>2</sup>	1.5...2.5	1.5...2.5	1.5...2.5	1.5...2.5	2x0.75...1	2x0.75...1.5	2x0.75...1		
AWG	16...14	16...14	16...14	16...14	2x18...17	2x18...16	2x18...17	2x18...16		

Fig. 17. Suitable wiring for the power supply

#### Suitable wiring for I/O SELV

#### Step 3.5 mm (0.137 in.)

									 Ø 3.5 mm (0.14 in.)	 Nm 0.5...0.6 lb-in. 4.42...5.31
	mm <sup>2</sup>	0.14...1.5	0.14...1.5	0.25...1.5	0.25...0.5	2x0.08...0.5	2x0.08...0.5	2x0.25...0.34		
AWG	25...15	25...15	22...15	22...20	2x28...20	2x28...20	2x18...17	2x20		

Fig. 18. Suitable wiring for I/O SELV

### 6.2.4 Permitted cable lengths

### NOTICE

#### MALFUNCTIONING OF THE EQUIPMENT

- When connecting the power supply, use cables that are no longer than 10 m (32.80 ft).
- When connecting the sensors, digital inputs and analogue inputs, use cables that are no longer than 10 m (32.80 ft).
- When connecting the RS-485 serial line, use cables that are no longer than 1000 m (3280 ft).
- When connecting the digital outputs, use cables that are no longer than 10 m (32.80 ft).

### 6.3 Wiring diagram




Fig. 19. Mistral humidifier connections

TERMINALS			
L	Power supply unit supply phase input	4-5	Multifunction input <b>IA1/ID1</b>
N	Power supply unit supply neutral input	6-7	Serial communication input <b>RS-485</b>
⊥	Power supply unit supply earth input	8-9	Power supply input ( <b>28 Vdc</b> ) from power supply unit
-V	GND power supply unit output	10-11	Digital output <b>Out1</b>
+V	+28 Vdc power supply unit output	<b>DIP Switch</b>	Activation of RS-485 serial line termination resistor (120 Ω)
1-2	Digital input <b>ID2</b> (Ventilation consent)	<b>T1</b>	Reset button for partial Mist-maker operation hours
3	Auxiliary power supply <b>24 Vdc</b> (transducers)		

### WARNING

#### MALFUNCTIONING OF THE EQUIPMENT

Only use the switching power supply unit supplied to power the humidifier.


## 6.4 Configurations

Mistral can be configured in 11 different operating modes by setting the **CFG** parameter.

**NOTE:** in each mode of operation, **ID2** must be closed to allow Mistral to generate humidity.

### 6.4.1 Resistive humidity sensor connection


- Stand-alone configuration **CFG = 4**;
- Parallel configuration as master **CFG = 9**.



**Fig. 20.** Resistive humidity sensor connection

### 6.4.2 Humidity sensor connection 4...20 mA

- Stand-alone configuration **CFG = 2**;
- Parallel configuration as master **CFG = 7**.



**Fig. 21.** Humidity sensor connection 4...20 mA

### 6.4.3 Humidity sensor connection 0...10 V

- Stand-alone configuration **CFG = 3**;
- Parallel configuration as master **CFG = 8**.




Fig. 22. Humidity sensor connection 0...10 V

### 6.4.4 External proportional humidistat connection with signal 0...10 V

- Stand-alone configuration **CFG = 1**;
- Parallel configuration as master **CFG = 6**.




Fig. 23. External proportional regulator connection with signal 0...10 V

### 6.4.5 ON/OFF connection with humidistat or external contact

- Stand-alone configuration **CFG = 0**;
- Parallel configuration as master **CFG = 5**.




Fig. 24. ON/OFF connection with humidistat or external contact

## 7. USER INTERFACE

Make sure the humidifier and all the installed components are properly connected before start-up, in accordance with regulations, criteria and all applicable local, regional and national standards.

### 7.1 Mistral user interface




Fig. 25. LED user interface

#### 7.1.1 LED

LED	Function	Description
	Alarm LED	<p><b>Lit steadily:</b> level sensor board alarm</p> <p><b>Blinking:</b> indicates an alarm according to the number of blinks (see “15.1 ALARMS TABLE (LED INTERFACE)” ON PAGE 87)</p> <p><b>OFF:</b> in all other cases</p>
	High/low humidity LED	<p><b>Lit steadily:</b> analogue input in alarm status</p> <p><b>Blinking:</b> <b>0.5 s ON / 0.5 s OFF:</b> high humidity alarm if <b>CFG = 2, 3, 4, 7, 8, 9</b> <b>1 s ON / 1 s OFF:</b> low humidity alarm if <b>CFG = 2, 3, 4, 7, 8, 9</b></p> <p><b>OFF:</b> in all other cases</p>
	Level sensor Alarm LED	<p><b>Lit steadily:</b> level sensor alarm</p> <p><b>Blinking:</b> indicates a warning according to the number of blinks (see “15.1 ALARMS TABLE (LED INTERFACE)” ON PAGE 87)</p> <p><b>OFF:</b> in all other cases</p>
	Water Alarm LED	<p><b>Lit steadily:</b> filling procedure failed</p> <p><b>Blinking:</b> <b>3 s ON / 3 s OFF:</b> water below minimum level for activating mist-maker <b>0.5 s ON / 0.5 s OFF:</b> if, after draining, the sensors still detect water</p> <p><b>OFF:</b> in all other cases</p>
	Power Supply LED	<p><b>Lit steadily:</b> mist-maker ON and humidifier produces humidity</p> <p><b>Blinking:</b> <b>0.5 s ON / 0.5 s OFF:</b> humidity enable consent <b>ID2</b> not given <b>1 s ON / 3 s OFF:</b> Mistral produces no humidity</p> <p><b>OFF:</b> humidifier not powered</p>

#### 7.1.2 Keys

Keys	Tap and release to...	Tap and hold for at least 1 second to...	Tap and hold for at least 4 seconds to...
<b>FNC</b>	Change fan speed	During lamp test: enter the operating mode configuration menu	Start reservoir emptying
<b>SET</b>	---	Humidity setpoint setting	Change maximum humidity production

## 7.2 EV3K user interface

EV3K is available as an accessory completing the range of **Mistral** humidifiers (see “**1.6 ACCESSORIES**” ON PAGE 12).



Fig. 26. EV3K user interface

### 7.2.1 Icons

Icon	Lit steadily	OFF
1	Display shows the humidity sensor value on the top row	In all other cases
☁	Humidity production in progress	No humidity production
∧	Proportional operating mode (CFG = 1 or CFG = 6)	In all other cases
∟	ON/OFF operating mode (CFG = 0 or CFG = 5)	In all other cases
V	0...10 V sensor operating mode (CFG = 3 or CFG = 8)	In all other cases
I	4...20 mA sensor operating mode (CFG = 2 or CFG = 7)	In all other cases
R	Resistive sensor operating mode (CFG = 4 or CFG = 9)	In all other cases
°C	Display shows temperature in °C	In all other cases
%	Display shows humidity in %	In all other cases
⌚	Displayed value is operating hours (fan or mist-maker)	In all other cases
⚠	Alarm in progress	No alarm in progress
μS	Changing value of P1 in progress	In all other cases
⚠	Warning in progress	No warning in progress
🔗	ID2 closed (humidity consent present)	ID2 open (humidity consent not provided)
SP	Changing humidity setpoint in progress	In all other cases

### 7.2.2 Touch keys

The touch key functions are described below:

Keys...	Tap and release to...	Tap and hold for at least 3 seconds to...
🔒 SET	<ul style="list-style-type: none"> <li>Confirm the values on the display</li> <li>Set/change the humidity setpoint</li> </ul>	Enter the parameters menu
⏪	Go back a level	---
FNC ✓	<ul style="list-style-type: none"> <li>Scroll down through the values</li> <li>Navigate within the menu</li> </ul>	<ul style="list-style-type: none"> <li>Access the maintenance menu</li> <li>Reset operating hours</li> </ul>
⏩	<ul style="list-style-type: none"> <li>Scroll up through the values</li> <li>Navigate within the menu</li> </ul>	---

### 7.2.3 Main view

Depending on the chosen operating mode (CFG) the display has a different main view. The main screen displays according to the configured operating mode are shown below:

#### ON/OFF operating mode | CFG = 0 or CFG = 5



Fig. 27. ON/OFF operation - ID1 and ID2 open



Fig. 28. ON/OFF operation - ID1 and ID2 closed

#### Proportional operating mode | CFG = 1 or CFG = 6



Fig. 29. Proportional operation - ID1 and ID2 open



Fig. 30. Proportional operation - ID1 and ID2 closed

With ID2 closed, the top row of the display shows the read value of the 0...10 V input signal, while the bottom row is off.

#### Operation with sensor | CFG = 2, 3, 4 or CFG = 7, 8, 9.




Fig. 31. Proportional operation - ID1 and ID2 open



Fig. 32. Proportional operation - ID1 and ID2 closed

With ID2 closed, the top row of the display shows the value of the connected sensor, while the bottom row shows the setpoint value (SP).

In addition, depending on the type of sensor connected and therefore the operating mode with the chosen sensor, a corresponding icon will come on, as described in the subsection "7.2.1 ICONS" ON PAGE 38.

### 7.2.4 Setting and changing the setpoint

#### If CFG=0, 1, 5, 6, 10

Setpoint not configurable.

#### If CFG= 2, 3, 4, 7, 8, 9

In the main view, to change the setpoint, tap and release the **SET** key. The value on the bottom row of the display will blink to indicate that you can make the change by scrolling with the **FNC**  $\nabla$  or  $\wedge$  keys. Tap the **SET** key to confirm the desired value.

## 7.2.5 Maintenance menu

In the maintenance menu, you can view:

- The value read by the connected sensor;
- The value read by the on-board NTC sensor;
- The statuses of the digital inputs **ID1** and **ID2**;
- The fan speed;
- The operating hours of the mist-maker;
- The operating hours of the fan;
- The status of the outputs:
  - Mist-maker;
  - Fan;
  - Inlet solenoid valve;
  - Outlet solenoid valve;
  - Digital output **UD1**.
- Any alarms in progress.

## 7.2.6 Maintenance engineer parameters

The following is a table with the labels shown on the display and their description:

Top row	Bottom row	Description
Pb1 sensor value	<b>Pb1</b>	If sensor Pb1 is connected, the value read by the sensor is displayed.
Pb2 sensor value	<b>Pb2</b>	If sensor Pb2 is connected, the value read by the sensor is displayed.
Status <b>ID1</b>	<b>di1</b>	If connected, the status of the digital input <b>ID1</b> is displayed. <b>CLo = ID1</b> closed; <b>OPn = ID1</b> open.
Status <b>ID2</b>	<b>di2</b>	If connected, the status of the digital input <b>ID2</b> is displayed. <b>CLo = ID2</b> closed; <b>OPn = ID2</b> open.
Value <b>F0</b>	<b>FAn</b>	The <b>F0</b> (fan speed) parameter configuration value is displayed.
Value <b>r6</b>	<b>PrM</b>	The <b>r6</b> (maximum steam production) parameter configuration value is displayed.
Mist-maker hours	<b>MH</b>	The operating hours of the mist-maker are displayed if $\leq 9999$ h
Mist-maker hours	<b>MHH</b>	If the mist-maker operating hours are $> 9999$ , the operating hours data is divided according to the following logic: $(MHH \times 1000) + MHL$ . For example: <b>MHH = 1; MHL = 2956</b> $\rightarrow (1 \times 1000) + 2956 = 12956$ h
Mist-maker hours	<b>MHL</b>	If the mist-maker operating hours are $> 9999$ , the operating hours data is divided according to the following logic: $(MHH \times 1000) + MHL$ . For example: <b>MHH = 1; MHL = 2956</b> $\rightarrow (1 \times 1000) + 2956 = 12956$ h
0	<b>rMH</b>	Resets the mist-maker operating hours. Tap the <b>SET</b> key, enter the password value 149 using the <b>FNC</b> $\vee$ or $\wedge$ keys, tap <b>SET</b> to confirm the reset. On the top row, "—" blinks for 3 seconds after which 0 is displayed indicating that the reset has been accomplished.
Fan hours	<b>FH</b>	The operating hours of the fan are displayed if $\leq 9999$ h
Fan hours	<b>FHH</b>	If the fan operating hours are $> 9999$ , the operating hours data is divided according to the following logic: $(MHH \times 1000) + MHL$ . For example: <b>MHH = 1; MHL = 5894</b> $\rightarrow (1 \times 1000) + 5894 = 15894$ h
Fan hours	<b>FHL</b>	If the fan operating hours are $> 9999$ , the operating hours data is divided according to the following logic: $(MHH \times 1000) + MHL$ . For example: <b>MHH = 1; MHL = 5894</b> $\rightarrow (1 \times 1000) + 5894 = 15894$ h
0	<b>RFH</b>	Resets the fan operating hours. Tap the <b>SET</b> key, enter the password value 149 using the <b>FNC</b> $\vee$ or $\wedge$ keys, tap <b>SET</b> to confirm the reset. On the top row, "—" blinks for 3 seconds after which 0 is displayed indicating that the reset has been accomplished.
Mist-maker output status	<b>OM</b>	The mist-maker output status is displayed. <b>OFF</b> = Mist-maker output OFF; <b>ON</b> = Mist-maker output ON.
Fan output status	<b>oF</b>	The fan output status is displayed. <b>OFF</b> = Fan output OFF; <b>ON</b> = Fan output ON.

Top row	Bottom row	Description
Inlet solenoid valve status	oi	The inlet solenoid valve status is displayed. <b>OFF</b> = Inlet solenoid valve output OFF; <b>ON</b> = Inlet solenoid valve output ON.
Outlet solenoid valve status	od	The outlet solenoid valve status is displayed. <b>OFF</b> = Outlet solenoid valve output OFF; <b>ON</b> = Outlet solenoid valve output ON.
Digital output status <b>UD1</b>	or	The <b>UD1</b> digital output status is displayed. <b>OFF</b> = <b>UD1</b> digital output OFF; <b>ON</b> = <b>UD1</b> digital output ON.

### 7.2.7 Accessing the parameters menu

#### User parameters




Fig. 33. Accessing the user parameters menu

#### Maintenance engineer parameters




Fig. 34. Accessing the maintenance engineer parameters menu

### 7.2.8 Changing fan speed




Fig. 35. Changing fan speed

### 7.2.9 Maximum humidity production configuration




Fig. 36. Maximum humidity production configuration

## 8. POWER-UP AND START-UP

### 8.1 Before you start

#### **DANGER**

##### **RISK OF ELECTRIC SHOCK, EXPLOSION OR FIRE**

- Install the humidifier away from electronic equipment.
- Do not install the humidifier above electronic equipment.

#### **DANGER**

##### **RISK OF ELECTRIC SHOCK OR ELECTRIC ARC**

- Do not install the equipment while the power supply is connected.
- Cut off the power supply to all equipment, including any connected devices, and remove the power fuses before removing any covers or hatches, or before installing/uninstalling accessories, hardware, cables or wires.
- Always use a properly calibrated Voltmeter to make sure the system is powered off.
- Do not touch the unshielded components or the terminals while they are live.
- Make sure there is an effective earth connection; if there is not, earth the equipment.
- Before powering up the equipment, check all the wiring connections.

#### **WARNING**

##### **MALFUNCTIONING OF THE EQUIPMENT**

- Perform the wiring carefully, in compliance with electromagnetic compatibility and safety requirements.
- Make sure the wiring is correct for the end application.
- Minimise the length of the connections as much as possible, to avoid winding the cables around electrically connected parts.
- Before applying the power supply, check all the wiring connections.
- Do not connect wires to unused terminals and/or terminals marked with the text "No connection" ("N.C").

#### **NOTICE**

##### **MALFUNCTIONING OF THE EQUIPMENT**

- Make sure the water mains is correctly connected.
- Make sure there are no traps in the drainage duct.
- Make sure the humidity outlet closure clamps are properly tightened.
- Make sure there are no pockets of condensate or throttling in the mist (humidity) delivery channel.
- Make sure that the water quality and flow meets the technical requirements specified in the chapter **"5.2 INSTALLING THE PLUMBING" ON PAGE 26**

## 8.2 Start-up instructions

### NOTICE

#### MALFUNCTIONING OF THE EQUIPMENT

The configuration and self-test phase lasts approximately 5 minutes from the moment the humidifier is switched on, after which the humidifier is ready to generate humidity.

To start up the humidifier follow the instructions given in the table below.

Instructions	References
1. Perform the humidifier wiring according to the required configuration	"6.3 WIRING DIAGRAM" ON PAGE 34
2. Activate the isolator outside the humidifier and open the water supply source	"6. ELECTRICAL CONNECTIONS" ON PAGE 32
3. Open the water inlet shutoff cock upstream of the humidifier	"5.2 INSTALLING THE PLUMBING" ON PAGE 26
4. When powering on, the humidifier starts a configuration and self-test phase (*). This phase consists of the following automatic operations: <ul style="list-style-type: none"> <li>• Power on</li> <li>• Water drain cycle (draining off any residues)</li> <li>• Water fill cycle and configuration and self-test levels</li> <li>• Water drain cycle to complete configuration</li> <li>• Start of production</li> </ul>	"9. OPERATION" ON PAGE 46
5. Set the <b>CFG</b> parameter depending on the required operating mode	<ul style="list-style-type: none"> <li>• "9.2 OPERATING MODE CONFIGURATION" ON PAGE 46</li> <li>• "13.1 TABLE OF MISTRAL ADJUSTMENT PARAMETERS" ON PAGE 78</li> </ul>
6. Configure the machine parameters according to the characteristics of the water and usage of the humidifier	"13.1 TABLE OF MISTRAL ADJUSTMENT PARAMETERS" ON PAGE 78
7. Set the humidity setpoint to 100%	"9.4 HUMIDITY SETPOINT CONFIGURATION" ON PAGE 49
8. Check for humidity production	"9.7 HUMIDITY ADJUSTMENT" ON PAGE 52
9. Set the humidity setpoint to the desired value	"7.2.4 SETTING AND CHANGING THE SETPOINT" ON PAGE 39
10. The humidifier periodically (parameter <b>C1</b> ) fully drains the water and replaces it cyclically while performing the washing procedure, in order to maintain efficient humidifier operating conditions	"9.1 DRAINING WATER / WASHING RESERVOIR" ON PAGE 46

(\*) Mistral may discharge water in this phase.

Each time the instrument is connected to the power supply and then switched on, the configuration and self-test phase starts. The configuration and self-test phase lasts **approximately 5 minutes**, after which the humidifier is ready to generate humidity. If the configuration phase fails, it is repeated an additional two times, increasing the maximum time to 15 minutes. If the configuration fails at the third attempt, the humidifier signals **Water alarm**.

## 8.3 Instructions for seasonal or long-term shut-down

If you need to switch off the humidifier for long periods of time, you **must**:

- Manually drain the product using the manual drainage launch procedure;
- When draining is complete, deactivate the isolator installed outside the humidifier and open the water supply source;
- Clean the humidifier following the instructions provided in the chapter "**11. MAINTENANCE**" ON PAGE 73.

If the machine is suddenly loses power, for example in the event of a mains powercut or an inhibiting alarm which has forced the user to switch off the humidifier:

- Manually drain the product using the manual drainage launch procedure (\*);
- Clean the humidifier following the instructions provided in the chapter "**11. MAINTENANCE**" ON PAGE 73 within 72 hours of the moment it was switched off.

(\*) If the drainage procedure cannot be carried out via the user interface, manually empty the water from the reservoir.

Inadequate use and/or poor maintenance of the humidifier can damage your health.



### WARNING

#### BIOLOGICAL RISK

- In the event of inadequate use and/or poor maintenance it is possible that microorganisms (including the bacterium that causes Legionellosis) may proliferate and be transferred into the air treatment system or the surrounding environment.
- The humidifier must be used properly and be maintained and cleaned properly at prescribed intervals, as described in chapter "**11. MAINTENANCE**" ON PAGE 73.

## 8.4 Checks to be carried out each time the humidifier is switched on

Each time the humidifier is turned on, perform the following checks:

- Make sure the reservoir is properly clean as described in the chapter **“11. MAINTENANCE” ON PAGE 73** (carry out cleaning if necessary, using 20% citric acid and suitable biocides);
- Check that the mist delivery is consistent with the demand for humidity;
- Make sure there are no hydraulic leaks;
- Make sure that there are no alarms in progress (see **“15. DIAGNOSTICS” ON PAGE 87**).

## 9. OPERATION

### 9.1 Draining water / washing reservoir

The water reservoir is emptied in the following cases:

- When powering up;
- After an idle time determined by parameter **C0** (if **C0** ≠ 0);
- After an active time determined by parameter **C1** (if **C1** ≠ 0);
- In the case of the first high temperature alarm event (parameters **A1** and **A2**);
- In the case of maintenance, manual emptying is initiated by pressing and holding the **FNC** key for at least 4 seconds.

In the case of emptying the reservoir due to inactivity, the **Mistral** humidifier will run the fan for a time **F5** to dry the reservoir. If there is a demand for humidity, the humidifier will fill the reservoir.

At the end of each emptying phase, the drain valve is kept open for another 2 seconds.

**NOTE:** water drainage can be set to a frequency greater than 72 hours using only demineralised water.

### 9.2 Operating mode configuration

When powering up, while the LEDs are blinking, press the **FNC** key for at least 1 second to enter the analogue input configuration menu.

Press the **FNC** key again until the desired operating mode configuration is selected and press the **SET** key to confirm your choice.

Par.	Description	MU	Range
<b>CFG</b>	Operating mode. <b>0</b> = Stand-alone, ON/OFF operation, alarm relay; <b>1</b> = Stand-alone, proportional operation, alarm relay; <b>2</b> = Stand-alone, operation with 4...20 mA sensor, alarm relay; <b>3</b> = Stand-alone, operation with 0...10 V sensor, alarm relay; <b>4</b> = Stand-alone, operation with resistive humidity sensor, alarm relay; <b>5</b> = Master, ON/OFF operation; <b>6</b> = Master, proportional operation; <b>7</b> = Master, operation with 4...20 mA sensor; <b>8</b> = Master, operation with 0...10 V sensor; <b>9</b> = Master, operation with resistive humidity sensor; <b>10</b> = Slave.	---	0...10

Depending on the LED(s) on, one operating mode is chosen.

In the table on the next page, you can find the relation between **LED ON - OPERATING MODE**.

Relation between LED BLINKING - OPERATING MODE.

Mode 0 (CFG = 0)	Mode 1 (CFG = 1)	Mode 2 (CFG = 2)
<p>RH_T 50</p> <p>RH_V 30</p> <p>RH_I 20</p> <p>ON/OFF 10</p> <p>0-10V 5</p>	<p>RH_T 50</p> <p>RH_V 30</p> <p>RH_I 20</p> <p>ON/OFF 10</p> <p>0-10V 5</p>	<p>RH_T 50</p> <p>RH_V 30</p> <p>RH_I 20</p> <p>ON/OFF 10</p> <p>0-10V 5</p>

Mode 3 (CFG = 3)	Mode 4 (CFG = 4)	Mode 5 (CFG = 5)
<p>RH_T 50</p> <p>RH_V 30</p> <p>RH_I 20</p> <p>ON/OFF 10</p> <p>0-10V 5</p>	<p>RH_T 50</p> <p>RH_V 30</p> <p>RH_I 20</p> <p>ON/OFF 10</p> <p>0-10V 5</p>	<p>RH_T 50</p> <p>RH_V 30</p> <p>RH_I 20</p> <p>ON/OFF 10</p> <p>0-10V 5</p>

Mode 6 (CFG = 6)	Mode 7 (CFG = 7)	Mode 8 (CFG = 8)
<p>RH_T 50</p> <p>RH_V 30</p> <p>RH_I 20</p> <p>ON/OFF 10</p> <p>0-10V 5</p>	<p>RH_T 50</p> <p>RH_V 30</p> <p>RH_I 20</p> <p>ON/OFF 10</p> <p>0-10V 5</p>	<p>RH_T 50</p> <p>RH_V 30</p> <p>RH_I 20</p> <p>ON/OFF 10</p> <p>0-10V 5</p>

## Relation between LED BLINKING - OPERATING MODE.

Mode 9 (CFG = 9)	Mode 10 (CFG = 10)
 RHLT  50   RH_V  30   RHLI  20   ON/OFF  10   0-10V  5	 RHLT  50   RH_V  30   RHLI  20   ON/OFF  10   0-10V  5

### 9.3 Fan speed configuration

To configure the fan speed, during normal operating mode, press **FNC** until the LEDs  and  light up (release the key before the two lit LEDs cause manual drainage to begin).

Each time the **FNC** key is pressed, the value of parameter **F0** increments by 1.

Wait 5 seconds after last pressing the **FNC** key to exit the procedure and save the new value.

The **F0** parameter values corresponding to the lit LED are:

			
<b>F0 = 0 (OFF)</b>	---	---	---
<b>F0 = 1 (15%)</b>	---	---	ON
<b>F0 = 2 (30%)</b>	---	ON	---
<b>F0 = 3 (60%)</b>	ON	---	---
<b>F0 = 4 (80%)</b>	---	ON	ON

--- = LED off.

ON = LED lit.

**NOTE:** the  and  LEDs remain steadily lit during fan configuration.

## 9.4 Humidity setpoint configuration

Procedure available with **CFG = 2,3,4,7,8,9**.

During normal operation, to set the setpoint press the **SET** key.

During the phase of configuring the humidity setpoint **SP**, a LED corresponding to a set percentage value will light up. The humidity setpoint can vary within the range of values set by parameters **r1** and **r2**.

Each time the **SET** key is pressed, the humidity value is increased by 5%.


Wait 5 seconds after last pressing the **SET** key to exit the procedure and save the new value.

The humidity percentage values corresponding to the lit LEDs are:

LED					
Humidity value	50%	30%	20%	10%	5%

### 9.4.1 Examples of humidity setpoint configuration


**Example 25% Humidity Setpoint:**



**Fig. 37.** Example of humidity setpoint configuration at 25%

LED					
LED ON/OFF	OFF	OFF	ON	OFF	ON
Humidity value	---	---	20%	---	5%


**Example 50% Humidity Setpoint:**



**Fig. 38.** Example of humidity setpoint configuration at 50%

<b>LED</b>					
<b>LED ON/OFF</b>	ON	OFF	OFF	OFF	OFF
<b>Humidity value</b>	50%	---	---	---	---


**Example 75% Humidity Setpoint:**



**Fig. 39.** Example of humidity setpoint configuration at 75%

<b>LED</b>					
<b>LED ON/OFF</b>	ON	OFF	ON	OFF	ON
<b>Humidity value</b>	50%	---	20%	---	5%

**Example 100% Humidity Setpoint:**



**Fig. 40.** Example of humidity setpoint configuration at 100%

<b>LED</b>					
<b>LED ON/OFF</b>	ON	ON	ON	OFF	OFF
<b>Humidity value</b>	50%	30%	20%	---	---

**9.5 Maximum steam production configuration**

During normal operation, to configure the maximum steam production press the **SET** key for longer than 4 seconds.

Each time the **SET** key is pressed, the value of the maximum steam production is increased by 5%.

Wait 6 seconds after last pressing the **SET** key to exit the procedure and save the new value.

The humidity percentage values corresponding to the lit LEDs are:

<b>LED</b>					
<b>Humidity value</b>	50%	30%	20%	10%	5%

Example maximum production value at 50%:

<b>LED</b>					
<b>Humidity value</b>	50%	30%	20%	10%	5%

**9.6 Temperature sensor**

A sensor is installed on the board to measure the temperature of the water in the reservoir during normal operation.

The internal temperature sensor is used by the humidifier for any temperature alarms (see **“15.1 ALARMS TABLE (LED INTERFACE)” ON PAGE 87**).

If **A1** = 0, the high temperature alarm is disabled.

If **A1** > 0, **Mistral** generates the alarm when the temperature detected by the internal sensor exceeds threshold **A1** for a time **A2**. In this situation the humidifier empties the reservoir and fills it again.

If after emptying, the alarm occurs again within a time **A3**, a high temperature alarm is signalled.

If, instead, after a time **A3**, no alarm is generated, the previous event is cleared.

If **A3** = 0, no emptying is carried out and the alarm is generated immediately.

## 9.7 Humidity adjustment

### 9.7.1 ON/OFF regulator

Humidity adjustment in ON/OFF mode is made by setting:


- **CFG = 0** or **CFG = 5**.

The outlet starts to produce humidity (at parameter value **r6**) when both digital inputs are closed.

If the digital input **ID2** is open (consent not provided), the  LED will blink with a period of 0.5 s ON - 0.5 s OFF.

If consent is given, but the humidifier is not producing any humidity, the  LED will blink with a period of 1 s ON - 3 s OFF:

The following diagram explains the operating logic:



**Fig. 41.** Humidity adjustment - ON-OFF

### 9.7.2 External proportional regulator with 0...10 V input

The humidity adjustment in proportional mode with 0...10 V input is done by setting:


- **CFG = 1** or **CFG = 6**.

The outlet starts producing humidity in proportion to the input signal.

If the digital input **ID2** is open (consent not provided), the  LED will blink with a period of 0.5 s ON - 0.5 s OFF.

If consent is given, but the humidifier is not producing any humidity, the  LED will blink with a period of 1 s ON - 3 s OFF:


The following diagram explains the operating logic:



*Fig. 42. External proportional regulator with 0...10 input*

In order to produce humidity, **Mistral** must receive consent from the ventilation, so digital input **ID2** must be closed.

The proportional humidity function has a PWM type modulation which provides for a cycle time between two consecutive activations of the humidity production output (parameter **r3**).



*Fig. 43. External proportional regulator with 0...10 input - Consecutive activation delay*

### 9.7.3 Regulator with humidity sensor

Humidity adjustment via a humidity sensor is made by setting:

- **CFG = 2; CFG = 3; CFG =4** or
- **CFG = 7; CFG = 8; CFG = 9.**

The outlet produces humidity with the following logic:




Fig. 44. Adjustment with humidity sensor

- If the sensor reading is less than **SP-r0-r4**, then the humidity production is at its maximum;
- If the sensor reading is between **SP-r0-r4** and **SP-r0**, then the production is proportional between **r5** and **r6**;
- If the sensor reading is between **SP-r0** and **SP** then there is little or no production;
- **Mistral** does not produce humidity under any other conditions;
- **Mistral** does not produce any humidity with the sensor in error.

## 9.8 Recording hours of operation

The **Mistral** humidifier, among its functions, includes recording the operating hours, to monitor and alert you when to perform routine maintenance. Some of the recordings made include:

- Partial hours of mist-maker operation;
- Partial hours of fan operation.

The operating hours are stored in the internal memory.

This is referred to as partial hours, as the recorded operating hours can be reset to zero.

To view/reset the partial operating hours, you need to connect the remote user interface (see **"1.6 ACCESSORIES" ON PAGE 12**).

### 9.8.1 Mist-maker operating hours: partial number

If the mist-maker operating hours > **A10**, the **Mistral** humidifier will generate a warning. If **A10 = 0**, no warning is generated.

The data is considered partial because it can be reset by pressing and holding key **T1** for at least 4 seconds.

To view and reset the partial operating hours of the fan see **"7.2.5 MAINTENANCE MENU" ON PAGE 40**.

### 9.8.2 Fan operating hours: partial number

If the fan operating hours > **A13**, the **Mistral** humidifier will generate a warning. If **A13 = 0**, no warning is generated.

The data is considered partial because it can be reset by pressing and holding key **T1** for at least 4 seconds.

To view and reset the partial operating hours of the fan see **"7.2.5 MAINTENANCE MENU" ON PAGE 40**.

## 9.9 Parallel operation

Up to 5 humidifiers can be connected in parallel.

By configuring and setting the first humidifier only (MASTER), the others (SLAVES) will follow the operation of the first humidifier by replicating it precisely (parametrizations are not replicated if they are changed on the MASTER).

To activate this operating mode, you need to:

- Set one humidifier as Master, by setting **CFG = 5...9**;
- Set all the other humidifiers as Slave, by setting **CFG = 10** on each humidifier;
- Connect the analogue input **IA1** on the Master humidifier;
- Connect the digital output **Out1** of each humidifier to the digital input **ID2** of the next humidifier.




Fig. 45. Parallel operation

**NOTE:** in this operating mode, the digital output is used to propagate the operating signal.

**NOTE:** for humidifiers set to SLAVE, do not connect input **IA1**.

# 10. MASTER/SLAVE CONFIGURATION

## 10.1 Introduction

The Master/Slave configuration allows the user to increase the system's production capacity or to control the entire system remotely.

The cutting-edge **EPJC** user interface allows the connection of several humidifiers in an RS-485 network in order to enable different operating modes and allow maintenance on individual humidifiers without interrupting operation of the entire humidification system.

The configuration parameters for the master/slave RS-485 network are listed on the **EPJC** user interface and are as follows:

Par.	Description	MU	Range
<b>E0</b>	Number of humidifiers connected.	---	1...4
<b>E1</b>	Operating mode. 1 = Independent; 2 = Parallel; 3 = Rotation; 4 = Balancing.	---	1...4
<b>E2</b>	Rotation time.	hours	1...24
<b>BLE</b>	Enable EVconnect/EPoCA. 0 = Spare; 1 = Forced for EVconnect/EPoCA; 2...99 = EPoCA local network address.	---	0...99
<b>PA1</b>	User level EPoCA password.	---	-99...999
<b>PA2</b>	Administrator level EPoCA password.	---	-99...999
<b>LA1</b>	COM1 address (RS-485 Slave).	---	1...247
<b>LB1</b>	COM1 Baud rate (RS-485 Slave). 0 = 2400; 1 = 4800; 2 = 9600; 3 = 19200; 4 = 38400.	---	0...4
<b>LP1</b>	COM1 parity (RS-485 Slave). 0 = None; 1 = Odd; 2 = Even.	---	0...2

If a Mistral loses connection with the **EPJC**, after 15 seconds it will begin running in the mode set via **CFG** (parameter on Mistral).

## 10.2 Operating modes

The **EPJC** user interface can be used to configure parameter **E1** and set different operating modes for the **Mistral** master/slave RS-485 network.

The configuration parameters for the operating modes are:

Par.	Description	MU	Range
<b>E0</b>	Number of humidifiers connected in master/slave configuration.	---	1...4
<b>E1</b>	Humidifier operating mode in master/slave configuration. 1 = Independent; 2 = Parallel; 3 = Rotation; 4 = Balancing.	---	1...4
<b>E2</b>	Rotation time in master/slave configuration.	hours	1...120

### 10.2.1 Master/Slave | Independent Mistral operation

Each **Mistral** humidifier operates with its own parameters, **EPJC** is a display unit only.

If the master humidifier loses connection, the other instruments remain in slave mode with zero power.

### 10.2.2 Master/Slave | Parallel Mistral operation

Once the master humidifier has been set, it sets the demand for humidity for the slave humidifiers, making them all work simultaneously at the same request value.

Parallel operation means that the humidification capacity can be increased.

### 10.2.3 Master/Slave | Rotational Mistral operation

Once the master humidifier has been set, it sets the demand for humidity for the slave humidifiers, making each one work at the same request value.

Each Mistral produces an output based on the demand for humidity for a time period **E2**; once this time has elapsed, the next Mistral in the network begins to produce an output at the same requested value.

If, for example, the rotation time **E2** = 1 h and the connected Mistrals have addresses of 1, 2 and 4: Mistral 1 will produce an output in the first hour, then 2, then 4 and then 1, 2, 4 again cyclically.

Rotational operation makes it possible to normalise all operating hours for the various humidifiers in the network.

### 10.2.4 Master/Slave | Balancing Mistral operation

Once the master humidifier has been set, it sets the demand for humidity made to the slave humidifiers, making each one work at the same request value.

Each Mistral remains on based on how active its mist-maker has been, before passing control to the next Mistral. Rotation takes place according to the principle described in the subsection "**10.2.3 MASTER/SLAVE | ROTATIONAL MISTRAL OPERATION**" ON PAGE 57.

The rotation time is adjusted in line with the maximum output of the humidifier in production mode (parameter **r6** on Mistral).

If, for example, there are three instruments and a rotation time **E2** = 1 h, the role change takes place effectively when each instrument has produced a humidity value equal to **r6**.

- **Mistral 1** always works at 50% and **r6** = 100% -> rotation time = 2 h
- **Mistral 2** always works at 100% and **r6** = 100% -> rotation time = 1 h

Rotation takes place in a circular fashion, with the first device being the master: for example, if devices 1, 2, 4 are connected in the network and device 2 is the master, the order will be 2-4-1-2-4-etc.

Balancing operation makes it possible to normalise humidity production for the various humidifiers in the network.

### 10.2.5 Master/Slave | Mistral in maintenance

This mode cannot be selected via menu as the humidifiers not subject to maintenance must remain active to keep the humidification system running.

To switch to maintenance mode, see "**10.6.2 HUMIDIFIER MAINTENANCE**" ON PAGE 66.

## 10.3 EPJC user interface

### 10.3.1 Humidifier grid view

Depending on the chosen operating mode (**E1**) the display has a different main view. The main screen displays according to the configured operating mode are shown below:

#### Independent Mistral operating mode | **E1 = 1**




Fig. 46. Independent Mistral operating mode | **E1 = 1**

The grid view screen for humidifiers in independent **Mistral** mode (**E1 = 1**) shows the following information:

	SET	PRD	MAXPR	FAN
<b>Mistral 1</b>	<ul style="list-style-type: none"> <li>Setpoint (if regulation takes place with sensor)</li> <li>--- in all other cases</li> </ul>	Current production	Maximum production ( <b>r6</b> )	Fan speed
<b>Mistral 2</b>				<b>0</b> = Fan off;
<b>Mistral 3</b>				<b>1</b> = Speed at <b>15%</b> ;
<b>Mistral 4</b>				<b>2</b> = Speed at <b>30%</b> ;
				<b>3</b> = Speed at <b>60%</b> ;
				<b>4</b> = Speed at <b>80%</b> .

#### In all other cases




Fig. 47. Grid view in all other cases

In other cases the *humidifier grid view* screen shows the following information:

#### Screen 1

	RH %	ID2	ID1	STATUS
<b>Mistral 1</b>	<ul style="list-style-type: none"> <li>Sensor value (if present)</li> <li>--- in all other cases</li> </ul>	ON/OFF consent input status	<ul style="list-style-type: none"> <li>ON/OFF input status (if present)</li> <li>--- in all other cases</li> </ul>	<b>M</b> if master
<b>Mistral 2</b>				<b>R</b> if active in rotation
<b>Mistral 3</b>				<b>S</b> if in maintenance
<b>Mistral 4</b>				--- in all other cases

#### Screen 2

	SET	PRD	MAXPR	FAN
<b>Mistral 1</b>	<ul style="list-style-type: none"> <li>Setpoint (if regulation takes place with sensor)</li> <li>--- in all other cases</li> </ul>	Current production	Maximum production ( <b>r6</b> )	Fan speed
<b>Mistral 2</b>				<b>0</b> = Fan off;
<b>Mistral 3</b>				<b>1</b> = Speed at <b>15%</b> ;
<b>Mistral 4</b>				<b>2</b> = Speed at <b>30%</b> ;
				<b>3</b> = Speed at <b>60%</b> ;
				<b>4</b> = Speed at <b>80%</b> .

### 10.3.2 Viewing the screen for a single Mistral




Fig. 48. Viewing the screen for a single Mistral

### 10.3.3 Setting and changing the setpoint




Fig. 49. Changing the setpoint

### 10.3.4 Changing the maximum humidity production




Fig. 50. Changing the maximum humidity production

### 10.3.5 Changing fan speed




Fig. 51. Changing fan speed

## 10.4 EPJC general menu




Fig. 52. Accessing the general menu

Menu	Description
	Access the user menu
	Access the maintenance technician menu
	Access to change the date/time

## 10.5 EPJC user menu





Fig. 53. EPJC user menu

Menu option	Description
<b>Language</b>	Used to set the menu language (English set in the example)
<b>485 Connection</b>	Used to view the Mistral's connected in master/slave RS-485
<b>Operating mode</b>	Used to view and set the master/slave network operating mode
<b>Restore 485 configurations</b>	Used to disconnect all humidifiers connected in the master/slave network

### 10.5.1 Humidifier connection



**Fig. 54.** Humidifier connection

To carry out connection (for example, connect a Mistral in position 1):

- Connect the Mistral to the RS-485 network and power it up;
- From the EPJC, access the screen *Humidifier connection*;
- Press the  icon (reference position 1) to perform the connection;
- The screen showing connected humidifiers appears.

**Key**

	Icon	Number colour
Mistral connecting		Number in yellow
Mistral connected		Number in green
Mistral disconnected		Number in white

## 10.5.2 Setting master/slave operating mode





Fig. 55. Setting master/slave operating mode

### Key


Selected	Destination
Independent	Humidifier grid screen
Parallel	Master humidifier selection screen
Rotation	
Balancing	

### 10.5.3 Selecting the master humidifier



**Fig. 56.** Selecting the master humidifier


## 10.6 EPJC maintenance menu



**Fig. 57.** Maintenance menu


Menu option	Description
Parameters management	Used to access the list of parameters
Maintenance	Used to select the humidifier on which maintenance is to be carried out

### 10.6.1 Changing the parameters



**Fig. 58.** Changing the parameters


## 10.6.2 Humidifier maintenance



**Fig. 59.** Humidifier maintenance

- Select the humidifier on which maintenance is to be carried out;
- Press **Select**;
- The selected humidifier is set in maintenance mode.

## 10.7 Changing the date and time



**Fig. 60.** Changing the date and time

## 10.8 Single Mistral screen




Fig. 61. Single Mistral screen

### Icons

Icon	Lit steadily	OFF
	Distribution in the room ON	In all other cases
	SW consent input (ID2) closed	SW consent input (ID2) open
	Inlet solenoid valve ON Water filling in progress	Inlet solenoid valve OFF Water filling finished
	Outlet solenoid valve ON Water draining in progress	Outlet solenoid valve OFF Water draining finished
	Light blue icon: humidity generation in progress	White icon: humidity generation finished

### 10.8.1 Mistral in alarm mode




Fig. 62. Mistral in alarm mode

## 10.8.2 Operating hours




Fig. 63. Displaying operating hours

## 10.8.3 List of alarms in progress




Fig. 64. List of alarms in progress

### 10.8.4 Alarm history




Fig. 65. Alarm history

### 10.9 Single Mistral menu




Fig. 66. Menu for a single Mistral

Menu	Description
	Access the user menu
	Access the maintenance technician menu


### 10.10 Single Mistral user menu



Fig. 67. User menu for a single Mistral

The user menu on each Mistral connected to the master/slave network can be used to change the user parameters for the selected Mistral.

## 10.11 Single Mistral maintenance menu



**Fig. 68.** Maintenance menu for a single Mistral

Menu option	Description
<b>Configuration parameters</b>	Used to access the list of maintenance engineer parameters
<b>Operating hours</b>	Used to view and reset the operating hours
<b>Alarm history</b>	Used to reset the alarm history
<b>Testing of outputs</b>	Used to access the output functional test screen, where the outputs can be forced on or off
<b>Factory settings</b>	Used to restore the EPJC factory settings
<b>Version</b>	Used to view the fw version

### 10.11.1 Maintenance engineer parameters




Fig. 69. Maintenance engineer parameters

### 10.11.2 Displaying/resetting the operating hours




Fig. 70. Resetting the operating hours

To reset the operating hours as desired, press the  icon.

### 10.11.3 Resetting the alarm history




Fig. 71. Resetting the alarm history

To reset the alarm history, press **Delete**.

#### 10.11.4 Testing of outputs




Fig. 72. Testing of outputs

#### 10.11.5 Restoring factory settings




Fig. 73. Restoring factory settings

### 10.12 Lost connection

If a Mistral in the master/slave network loses connection with that network, after 15 seconds it will begin running in the mode set via the **CFG** parameter on the humidifier.

### 10.13 Master/Slave connection procedure

All Mistrals must be disconnected and switched off.

1. Switch on Mistral 1 and connect it, via RS-485, to the EPJcolor;
2. Perform connection between EPJcolor and Mistral 1 (see **"10.5.1 HUMIDIFIER CONNECTION" ON PAGE 62**;
3. Switch on Mistral 2 and connect it, via RS-485, to the EPJcolor;
4. Perform connection between EPJcolor and Mistral 2 (see **"10.5.1 HUMIDIFIER CONNECTION" ON PAGE 62**;
5. Switch on Mistral 3 and connect it, via RS-485, to the EPJcolor;
6. Perform connection between EPJcolor and Mistral 3 (see **"10.5.1 HUMIDIFIER CONNECTION" ON PAGE 62**;
7. Switch on Mistral 4 and connect it, via RS-485, to the EPJcolor;
8. Perform connection between EPJcolor and Mistral 4 (see **"10.5.1 HUMIDIFIER CONNECTION" ON PAGE 62**;
9. Connect all Mistrals via RS-485.

# 11. MAINTENANCE

## DANGER

### RISK OF ELECTRIC SHOCK OR ELECTRIC ARC

- The maintenance, repair, installation and use of the equipment must only be entrusted to qualified personnel.
- Any procedure on the humidifier, including routine or extraordinary maintenance, must only be carried out while the power supply is disconnected.

## 11.1 Introduction

The **Mistral** humidifier is designed for operation with the water specifications described in subsection “**5.2.1 WATER SPECIFICATIONS**” ON PAGE 26.

Using water with different specifications and/or with a hardness level approaching the limit of 40 °f causes maintenance to be required more frequently. The reservoir requires frequent maintenance and seasonal cleaning in the following conditions:

Water conductivity	Water hardness
0...100 µS/cm	0...5 °f

It is not possible to provide certain instructions to determine the maintenance frequency, as it depends on the morphology of the water used, which can also vary under equal specifications (conductivity and hardness).

If frequent humidifier maintenance takes place, check the quality of the water supply.

## NOTICE

### MALFUNCTIONING OF THE EQUIPMENT

- Only use the humidifier with the water specifications indicated in this manual.
- Only carry out humidifier maintenance in accordance with the instructions provided in section “**11. MAINTENANCE**” ON PAGE 73.

- Leaks may occur due to breakages, cracks and fissures.

## DANGER

### RISK OF ELECTRIC SHOCK OR ELECTRIC ARC

- Any procedure on the humidifier, including routine or extraordinary maintenance, must only be carried out while the power supply is disconnected.
- In the event of water leakage, disconnect the humidifier electric power supply immediately by means of the external isolator.

- If any adverse event not described in this documentation arises, carry out maintenance and/or replace the humidifier. Contact ELSTEAM customer service for guidelines and instructions.

## DANGER

### RISK OF ELECTRIC SHOCK OR ELECTRIC ARC

If an adverse event occurs, disconnect the humidifier power supply immediately.

## 11.2 Periodically checking the status of the humidifier

Perform the following scheduled checks on the humidifier:

When...	What to do...
At first start-up	Make sure there are no leaks after an hour of continuous operation.
When replacing components	Renew the seals and make sure there are no leaks after an hour of continuous operation.
Every 7 days	<ul style="list-style-type: none"> <li>• Make sure the humidifier works properly (based on the instructions provided in this manual);</li> <li>• Make sure there are no leaks in the plumbing system;</li> <li>• Make sure there is no unusual operation.</li> </ul>
Every 30 days	<ul style="list-style-type: none"> <li>• Make sure there are no blockages in the water drain;</li> <li>• Make sure the water drains effectively;</li> <li>• Thoroughly remove limescale and biofilm residues from the reservoir and drain (wash the inside of the reservoir with 20% citric acid and appropriate biocides, and clean the limescale off the surface).</li> </ul>
Seasonally	<ul style="list-style-type: none"> <li>• Check the tightness of the seals and replace them if necessary.</li> </ul>

The Mistral humidifier features:

- Automatic draining for inactivity;
- Periodic automatic cleaning;
- Plastic material on whose surface bacterial colonies do not proliferate.

Inadequate use and/or poor maintenance of the humidifier can damage your health.

## **WARNING**

### **BIOLOGICAL RISK**


- In the event of inadequate use and/or poor maintenance it is possible that microorganisms (including the bacterium that causes Legionellosis) may proliferate and be transferred into the air treatment system or the surrounding environment.
- The humidifier must be used properly and be maintained and cleaned properly at prescribed intervals, as described in chapter **“11. MAINTENANCE” ON PAGE 73**.

## **11.3 Cleaning the Reservoir**

Cleaning and maintenance of the reservoir must be done every 30 days when using non-demineralised drinking water to ensure optimal operation of the humidifier. With demineralised water the cleaning frequency is seasonal. This procedure is useful to prevent the water drain from clogging.

Below are the cleaning instructions:

- Drain the humidifier (see **“9.1 DRAINING WATER / WASHING RESERVOIR” ON PAGE 46**);
- Disconnect the machine power supply using the external isolator;
- Unscrew the screws at the top of the humidifier;
- Clean the following thoroughly using the products indicated in the section **“11.4 GUIDELINES FOR CLEANING AND DETERGENTS” ON PAGE 75** and removing limescale from the surface:
  - The reservoir;
  - The mist-maker;
  - The grooves around seals and couplings.
- Rinse the inside of the tank thoroughly;
- Check the cover seal is intact;
- Install the cover by screwing the screws into the upper face.



**Fig. 74.** Opening the **Mistral** cover to clean the reservoir

For the full list of permitted products that can be used for cleaning, see **“11.4 GUIDELINES FOR CLEANING AND DETERGENTS” ON PAGE 75**.

## 11.4 Guidelines for cleaning and detergents

When cleaning **Mistral** humidifier components, only use the products and detergents indicated in this operating and maintenance manual.

All application methods and safety instructions provided by the manufacturer relating to the detergents used must be observed. More specifically: observe the information relating to personal safety, environmental safeguarding and usage restrictions.

### **DANGER**

#### **RISK OF INHALING TOXIC RESIDUES**

When cleaning the humidifier, do not use detergents that leave behind toxic residues. During subsequent operation, these may be released into the ambient air and put people's health at risk. In any case, the components should be rinsed thoroughly with demineralised water after cleaning.

### **CAUTION**

#### **UNFORESEEN USE**

When cleaning, do not use any solvents, aromatic or halogenated hydrocarbons or other aggressive substances as they may damage the appliance components or human health.

### 11.4.1 Permitted products and detergents

When cleaning the Mistral humidifier and all its components, only use the following products or detergents:

Products/Detergents	Description
	20 % citric acid
	Biocides authorised in compliance with EU Regulation 528/2012
	Medical-surgical detergents and/or disinfectants. Medical-surgical detergents must be authorised by the Ministry of Health in accordance with Italian Presidential Decree 392 dated 6th October 1998 and the Act dated 5th February 1999; furthermore, the product must possess an official label including its registration number.
	Scraper

The active substances contained in biocides, i.e. the substances performing a toxic action on the desired strains, may damage other organisms which constitute, in some cases, essential elements of ecosystems.


### **WARNING**

#### **POLLUTION OF THE ENVIRONMENT AND THE ECOSYSTEM**

Do not discard the products used for cleaning in the environment.

## 11.5 Replacing mist-maker ceramic discs

The illustration gives instructions on how to properly replace the ceramic discs of the mist-maker.



**Fig. 75.** Replacing mist-maker ceramic discs

### **NOTICE**

#### **FAN NOT WORKING**

When removing the cover, be careful not to damage the fan power cables located at the back of the humidifier.

## 12. SPARE PARTS




Fig. 76. Mistral Humidifier spare parts

Ref.	P/n	Description	Ref.	P/n	Description
①	EHUK001	EHUC water drain valve kit	⑥	EHUK012	24 Vdc low speed fan + technopolymer grid
②	EHUK002	EHUC water inlet valve kit	⑦	EHUK020	Level regulator and user interface
③	EHUK003	EHUC seal kit	⑧	EHUK021	EHUC controller
④	EHUK004	EHUC switching power supply unit	⑨	1220000001	DK ceramic transducer set (9 pc blister pack)
⑤	EUHK005	EHUC mist-maker			

# 13. ADJUSTMENT PARAMETERS

## Description of columns in the Table of Parameters

- **Par.:** list of configurable device parameters;
- **Description:** indicates parameter operation and any possible selections;
- **MU:** measurement unit relating to the parameter;
- **Range:** describes the interval of values that the parameter can assume. This can be correlated with other instrument parameters (indicated with the parameter code).

**NOTE:**

- **Default:** indicates the pre-set factory configuration;
- **PW:** indicates the access level for the parameter:
  - **U** = User parameters;
  - **M** = Maintenance parameters.

## 13.1 Table of Mistral adjustment parameters

Par.	Description	MU	Range	PW	Default
<b>SETPOINT group</b>					
<b>SP</b>	Humidity setpoint.	%	<b>r1...r2</b>	U	70
<b>CONFIGURATIONS Group</b>					
<b>CFG</b>	Operating mode. <b>0</b> = Stand-alone, ON/OFF operation, alarm relay; <b>1</b> = Stand-alone, proportional operation, alarm relay; <b>2</b> = Stand-alone, operation with 4...20 mA sensor, alarm relay; <b>3</b> = Stand-alone, operation with 0...10 V sensor, alarm relay; <b>4</b> = Stand-alone, operation with resistive humidity sensor, alarm relay; <b>5</b> = Master, ON/OFF operation; <b>6</b> = Master, proportional operation; <b>7</b> = Master, operation with 4...20 mA sensor; <b>8</b> = Master, operation with 0...10 V sensor; <b>9</b> = Master, operation with resistive humidity sensor; <b>10</b> = Slave.	---	0...10	U	0
<b>ANALOGUE INPUTS group</b>					
<b>P1</b>	Water conductivity.	µS*cm	70...1250	M	500
<b>b4</b>	Initial charge time.	s	0...999	M	130
<b>MAIN REGULATOR group</b>					
<b>r0</b>	Hysteresis. With <b>CFG</b> = 2, 3, 4, 7, 8, 9.	%	2...20	U	5
<b>r1</b>	Minimum humidity setpoint value. With <b>CFG</b> = 2, 3, 4, 7, 8, 9.	%	0... <b>r2</b>	M	20
<b>r2</b>	Maximum humidity setpoint value. With <b>CFG</b> = 2, 3, 4, 7, 8, 9.	%	<b>r1</b> ...100	M	95
<b>r3</b>	Cycle time between two consecutive humidity production activations. With <b>CFG</b> ≠ 10.	s	1...240	M	20
<b>r4</b>	Proportional band. With <b>CFG</b> = 2, 3, 4, 7, 8, 9.	%	0...50	M	50
<b>r5</b>	Minimum humidity production. With <b>CFG</b> ≠ 10.	%	0... <b>r6</b>	M	20
<b>r6</b>	Maximum humidity production. With <b>CFG</b> ≠ 10.	%	<b>r5</b> ...100	U	100
<b>SANITARY SAFETY group</b>					
<b>c0</b>	Number of continuous idle hours causing the water reservoir to empty. <b>0</b> = Function disabled.	h	0...250	U	12
<b>c1</b>	Number of operating hours causing the water reservoir to empty. <b>0</b> = Function disabled.	h	0...250	U	24
<b>FANS group</b>					
<b>F0</b>	Fan speed. <b>0</b> = Fan off; <b>1</b> = Speed at <b>15%</b> ; <b>2</b> = Speed at <b>30%</b> ; <b>3</b> = Speed at <b>60%</b> ; <b>4</b> = Speed at <b>80%</b> .	---	0...4	U	3
<b>F5</b>	Fan off delay from switching mist-maker off (with <b>CFG</b> = 10).	s	0...240	M	20
<b>F6</b>	Fan operation time after emptying due to inactivity.	s	0...999	M	300

Par.	Description	MU	Range	PW	Default
<b>TEMPERATURE ALARMS group</b>					
<b>A5</b>	Low humidity alarm threshold only if <b>CFG = 2, 3, 4, 7, 8, 9</b> . Fixed hysteresis = 2%.	---	0...100	M	20
<b>A6</b>	High humidity alarm threshold only if <b>CFG = 2, 3, 4, 7, 8, 9</b> . Fixed hysteresis = 2%.	---	0...100	M	95
<b>A7</b>	High low humidity alarm delay only if <b>CFG = 2, 3, 4, 7, 8, 9</b> .	s	0...999	M	120
<b>A10</b>	Number of operating hours of the mist-maker for reporting partial hours if the water conductivity <b>P1</b> is between 70...449 $\mu\text{S}\cdot\text{cm}$ . The count can be reset to zero by pressing and holding key <b>T1</b> on the control board for at least 4 s. 0 = Function excluded.	1000h	0...99	M	90
<b>A11</b>	Number of operating hours of the mist-maker for reporting partial hours if the water conductivity <b>P1</b> is between 450...849 $\mu\text{S}\cdot\text{cm}$ . The count can be reset to zero by pressing and holding key <b>T1</b> on the control board for at least 4 s. 0 = Function excluded.	1000h	0...99	M	50
<b>A12</b>	Number of operating hours of the mist-maker for reporting partial hours if the water conductivity <b>P1</b> is between 850...1250 $\mu\text{S}\cdot\text{cm}$ . The count can be reset to zero by pressing and holding key <b>T1</b> on the control board for at least 4 s. 0 = Function excluded.	1000h	0...99	M	20
<b>A13</b>	Number of fan operating hours to signal partial operating hours. The count can be reset to zero by pressing and holding for at least 4 s.	1000h	0...99	M	60
<b>DIGITAL INPUTS group</b>					
<b>i0</b>	<b>ID2</b> port digital input polarity. 0 = Normally closed; 1 = Normally open.	---	0/1	M	0
<b>PASSWORD group</b>					
<b>PAS</b>	Parameter access password.	num	-99...999	M	-19
<b>EVLINK DATALOGGING group</b>					
<b>bLE</b>	Serial port configuration for EVconnect/EPoCA connectivity. 0 = Spare; 1 = Forced for EVconnect or EPoCA; 2...99 = EPoCA local network address.	---	0...99	M	1
<b>rE0</b>	Data logger sampling interval.	min	0...240	M	60
<b>rE1</b>	Enable data logging for data logger. 0 = No; 1 = Yes. Logged data: • Humidity sensor (if fitted); • Temperature sensor (level board); • Mist-maker output status; • Fan output status; • EEVC output status; • EEVS output status.	---	0/1	M	0
<b>MODBUS SERIAL CONFIGURATION group</b>					
<b>LA1</b>	COM1 serial line modbus protocol controller address.	num	1...247	M	20
<b>LB1</b>	COM1 serial line modbus transmission speed (baud rate). 0 = 2400 baud; 1 = 4800 baud; 2 = 9600 baud; 3 = 19200 baud; 4 = 38400 baud.	---	0...4	M	2
<b>LP1</b>	COM1 serial line Modbus serial parity. 0 = No Parity; 1 = Odd; 2 = Even.	---	0...2	M	2

## 13.2 EPJC configuration parameters table (master/slave)

Par.	Description	MU	Range	PW	Default
<b>MASTER/SLAVE CONFIGURATION group</b>					
<b>E0</b>	Number of humidifiers connected.	---	1...4	M	4
<b>E1</b>	Operating mode. 1 = Independent; 2 = Parallel; 3 = Rotation; 4 = Balancing.	---	1...4	M	1
<b>E2</b>	Rotation time.	hours	1...24	M	1
<b>MODBUS SERIAL CONFIGURATION group</b>					
<b>BLE</b>	Enable EVconnect/EPoCA. 0 = Spare; 1 = Forced for EVconnect/EPoCA; 2...99 = EPoCA local network address.	---	0...99	M	0
<b>PA1</b>	User level EPoCA password.	---	-99...999	M	426
<b>PA2</b>	Administrator level EPoCA password.	---	-99...999	M	824
<b>LA1</b>	COM1 address (RS-485 Slave).	---	1...247	M	247
<b>LB1</b>	COM1 Baud rate (RS-485 Slave). 0 = 2400; 1 = 4800; 2 = 9600; 3 = 19200; 4 = 38400.	---	0...4	M	3
<b>LP1</b>	COM1 parity (RS-485 Slave). 0 = None; 1 = Odd; 2 = Even.	---	0...2	M	2

# 14. MODBUS RTU FUNCTIONS AND RESOURCES

## 14.1 Introduction

Modbus RTU (Remote Terminal Unit) protocol is a means of communication which allows data exchange between a computer and programmable logic controllers.

This protocol is based on the exchange of messages between master-slave and client-server devices. Master devices can receive information from slaves and write to their registers, while slave devices cannot initiate any information transfer until they receive a request from the slave device.

Modbus communication is used in industrial automation systems (IAS) and in the construction of building management systems (BMS). Modbus protocol is widely utilised due to the fact it is easy to use, very reliable and has an open source code that can be used royalty-free on any application or device.

Modbus RTU is the most common application and uses CRC error detection and binary encoding.




Fig. 77. Diagram showing message exchange in a Modbus communication

Modbus protocol establishes a Protocol Data Unit (PDU) independent from the communication layer below it, introducing some additional fields specified on the Application Data Unit (ADU) (“**FIG. 78. FRAMING OF A MESSAGE USING MODBUS PROTOCOL” ON PAGE 81**) to specific buses and networks.

Devices such as PLCs (Programmable Logic Controller), HMIs (Human Machine Interface), control panels, drivers, motion controllers, I/O devices, etc. can use Modbus to begin a remote procedure, and the protocol is often used to connect a supervising computer with a Remote Terminal Unit in a supervision, control and data acquisition (SCADA) system.




Fig. 78. Framing of a message using Modbus protocol

For further information relating to Modbus protocol, visit the official Modbus website: [www.modbus.org](http://www.modbus.org).

## 14.2 Modbus message structure

Modbus RTU protocol requires the message to start with a silent time interval of at least 3.5 character times. This feature is often implemented by executing a time interval of multiple of character times at the baud rate used in the network. The characters available for each field are in binary form.

A description of the structure of a Modbus RTU message is provided below.

Start	Address	Function	Data	CRC	Stop
3.5 x character time	8 bit	8 bit	(N x 8 bit)	16 bit	3.5 x character time
Time period in which data must not be exchanged over the communication bus, to allow the connected instruments to recognise the end of one message and the start of the next	Corresponds to the address for the device with which the master has established dialogue; this is a value between 1...247. The address 0 is reserved for the broadcast message sent to all slave devices	Code for the function to execute or which has been executed	Contains the data sent by the master or sent back by the slave as a response to a question	Allows the master and the slave to check whether any errors are present during communication, and if there are, to ignore the message received	Time period in which data must not be exchanged over the communication bus, to allow the connected instruments to recognise the end of one message and the start of the next

## 14.3 Modbus functions and registers

The Modbus registers for the device are organised around the four types of basic data reference indicated above, and this type of data is further identified by the first number of the address.

### 14.3.1 Available Modbus commands and data areas

The commands implemented are as follows:

Command	Description
<b>03 (hex 0x03)</b>	Resource reading command
<b>06 (hex 0x06)</b>	Resource writing command

### 14.4 Address configuration

The RS-485 communication serial port can be used to configure the device, the parameters, the statuses and the Modbus variables and to monitor device operation using Modbus protocol.

The address of a device within a Modbus message is set by the **MODBUS Address** parameter.

The address **0** is only used for broadcast messages, recognised by all slaves. Slave devices do not respond to a broadcast message.

Serial line configuration parameters, which can be accessed via the user interface menu, are:

Par.	Description	MU	Range	Default
<b>LA1</b>	Modbus protocol controller address.	---	1...247	20
<b>LB1</b>	COM1 serial line modbus transmission speed (baud rate). <b>0</b> = 2400 baud; <b>1</b> = 4800 baud; <b>2</b> = 9600 baud; <b>3</b> = 19200 baud; <b>4</b> = 38400 baud.	---	0...4	4
<b>LP1</b>	COM1 serial line Modbus serial parity. <b>0</b> = No Parity; <b>1</b> = Odd; <b>2</b> = Even.	---	0...2	2

The RS-485 RTU serial line has the following characteristics (which cannot be changed):

- RTU mode;
- Bit: 8 bit;
- Stop bit: 1 bit.

### 14.5 Connections

For the entire system to work properly, including the RS-485 RTU serial line, observe the instructions provided in chapter “**6. ELECTRICAL CONNECTIONS**” ON PAGE 32.

In particular, make sure the connections are performed correctly, observing the instructions in section “**6.3 WIRING DIAGRAM**” ON PAGE 34.

### 14.6 Modbus tables content

#### Table content description

The table below contains the information required to access the resources properly and directly.

There are two tables:

- Modbus address table, which contains all the configuration parameters for the device and the corresponding Modbus addresses;
- Modbus resource table, which contains all the status (I/O) and alarm resources in the device memory.

#### Description of columns in the Table of addresses

- **Par.:** list of configurable device parameters;
- **Description:** indicates parameter operation and any possible selections;
- **MU:** measurement unit relating to the parameter;
- **Range:** describes the interval of values that the parameter can assume. This can be correlated with other instrument parameters (indicated with the parameter code).  
**NOTE:** if the actual value is outside the permitted limits for that parameter (for example, because other parameters defining the aforementioned limits have been altered), the value of the violated limit is displayed instead of the actual value;
- **Val. Adr.:** indicates the address of the Modbus register containing the resource you want to access;
- **R/W:** Indicates the option of reading or writing the resource:
  - **R:** the resource is read-only;
  - **W:** the resource is write-only;
  - **R/W:** the resource can be both read and written.
- **CPL:** when the fields indicates Y, the value read by the register needs to be converted because the value represents a number with a sign. In the other cases the value is always positive or zero.
- **DATA SIZE:** indicates the size in data bits:
  - **WORD** = 16 bit
  - **Byte** = 8 bit
  - The “n” bits = 0...15 bit depending on the value of “n”

## 14.7 Mistral modbus addresses

### 14.7.1 Modbus address table

Par.	Description	Val. Adr.	R/W	DATA SIZE	CPL	MU	Range
<b>SETPOINT group</b>							
<b>SP</b>	Humidity setpoint.	1539	R/W	WORD	---	%	r1...r2
<b>CONFIGURATIONS Group</b>							
<b>CFG</b>	Operating mode.	1540	R/W	BYTES	---	---	0...10
<b>ANALOGUE INPUTS group</b>							
<b>P1</b>	Water conductivity.	1541	R/W	WORD	---	μS*cm	70...1250
<b>b4</b>	Initial charge time.	1626	R/W	WORD	---	s	0...999
<b>MAIN REGULATOR group</b>							
<b>r0</b>	Hysteresis. With <b>CFG</b> = 2, 3, 4, 7, 8, 9.	1545	R/W	WORD	---	%	2...20
<b>r1</b>	Minimum humidity setpoint value. With <b>CFG</b> = 2, 3, 4, 7, 8, 9.	1546	R/W	WORD	---	%	0...r2
<b>r2</b>	Maximum humidity setpoint value. With <b>CFG</b> = 2, 3, 4, 7, 8, 9.	1547	R/W	WORD	---	%	r1...100
<b>r3</b>	Minimum delay time between two consecutive humidity production activations. With <b>CFG</b> ≠ 10.	1548	R/W	WORD	---	s	1...240
<b>r4</b>	Proportional band. With <b>CFG</b> = 2, 3, 4, 7, 8, 9.	1549	R/W	BYTES	---	%	0...50
<b>r5</b>	Minimum humidity production. With <b>CFG</b> ≠ 10.	1550	R/W	WORD	---	%	0...r6
<b>r6</b>	Maximum humidity production. With <b>CFG</b> ≠ 10.	1551	R/W	WORD	---	%	r5...100
<b>REGULATOR PROTECTION group</b>							
<b>c0</b>	Number of continuous idle hours causing the water reservoir to empty.	1556	R/W	BYTES	---	h	0...250
<b>c1</b>	Number of operating hours causing the water reservoir to empty.	1557	R/W	BYTES	---	h	0...250
<b>FANS group</b>							
<b>F0</b>	Fan speed.	1559	R/W	3 BIT	---	---	0...4
<b>F5</b>	Fan off delay from switching mist-maker off (with <b>CFG</b> = 10).	1563	R/W	BYTES	---	s	0...240
<b>F6</b>	Fan operation time after emptying due to inactivity.	1564	R/W	WORD	---	s	0...999
<b>ALARMS group</b>							
<b>A5</b>	Low humidity alarm threshold only if <b>CFG</b> = 2, 3, 4, 7, 8, 9.	1568	R/W	BYTES	---	---	0...100
<b>A6</b>	High humidity alarm threshold only if <b>CFG</b> = 2, 3, 4, 7, 8, 9.	1569	R/W	BYTES	---	---	0...100
<b>A7</b>	High low humidity alarm delay only if <b>CFG</b> = 2, 3, 4, 7, 8, 9.	1570	R/W	WORD	---	s	0...999
<b>A10</b>	Number of operating hours of the mist-maker for reporting partial hours if the water conductivity P1 is between 70...449 μS*cm.	1571	R/W	BYTES	---	1000h	0...99
<b>A11</b>	Number of operating hours of the mist-maker for reporting partial hours if the water conductivity P1 is between 450...849 μS*cm.	1572	R/W	BYTES	---	1000h	0...99
<b>A12</b>	Number of operating hours of the mist-maker for reporting partial hours if the water conductivity P1 is between 850...1250 μS*cm.	1573	R/W	BYTES	---	1000h	0...99
<b>A13</b>	Number of fan operating hours to signal partial operating hours.	1574	R/W	BYTES	---	1000h	0...99
<b>DIGITAL INPUTS group</b>							
<b>i0</b>	ID2 port digital input polarity.	1607	R/W	1 BIT	---	---	0/1
<b>PASSWORD group</b>							
<b>PAS</b>	Parameter access password.	1609	R/W	SHORT	Y	num	-99...999
<b>EVLINK DATALOGGING group</b>							
<b>bLE</b>	Serial port configuration for EVconnect/EPoCA connectivity.	1612	R/W	WORD	---	---	0...99
<b>rE0</b>	Datalogger sampling interval.	1613	R/W	BYTES	---	min	0...240
<b>rE1</b>	Enable data logging for datalogger.	1614	R/W	1 BIT	---	---	0/1
<b>MODBUS SERIAL CONFIGURATION group</b>							
<b>LA1</b>	COM1 serial line modbus protocol controller address.	1615	R/W	BYTES	---	num	1...247
<b>LB1</b>	COM1 serial line modbus transmission speed (baud rate).	1616	R/W	3 BIT	---	---	0...4
<b>LP1</b>	COM1 serial line Modbus serial parity.	1617	R/W	2 BIT	---	---	0...2

## 14.7.2 Modbus resource table

Code	Description	Val. Adr.	Filter value	R/W	DATA SIZE	CPL	MU	Range
<b>STATES Group</b>								
<b>PROBE VAL</b>	Analogue control input.	1362	---	R	SHORT	Y	%	-99.9...99.9
<b>FANS</b>	Fan current value.	517	---	R	SHORT	Y	mA	-99.9...99.9
<b>EEVC</b>	Inlet SV current value.	518	---	R	SHORT	Y	mA	-99.9...99.9
<b>MM</b>	Mist-maker current value.	519	---	R	SHORT	Y	mA	-999...999
<b>EEVS</b>	Outlet SV current value.	520	---	R	SHORT	Y	mA	-99.9...99.9
<b>T MMH</b>	Mist-maker partial time (H).	882	---	R	WORD	---	---	0...999
<b>T MML</b>	Mist-maker partial time (L).	883	---	R	WORD	---	---	0...999
<b>T FANH</b>	Fan (H) partial time.	890	---	R	WORD	---	---	0...999
<b>T FANL</b>	Fan (L) partial time.	891	---	R	WORD	---	---	0...999
<b>FW ID</b>	Firmware identifier.	65289	---	R	WORD	---	---	0...65535
<b>FW REV</b>	FW version (bit0-7=REV; bit8-15=VAR).	65290	---	R	SHORT	---	---	\$00...\$FFFF
<b>FW PROGR</b>	FW progressive No.	65291	---	R	WORD	---	---	0...65535
<b>DIGITAL INPUTS group</b>								
<b>HW EN</b>	HW enable consent. <b>0</b> = Off; <b>1</b> = On.	1361	0	R	1 BIT	---	---	0/1
<b>ON/OFF</b>	Inlet ON/OFF status. <b>0</b> = Off; <b>1</b> = On.	1361	2	R	1 BIT	---	---	0/1
<b>i0</b>	<b>ID2</b> port digital input polarity. <b>0</b> = Normally closed; <b>1</b> = Normally open.	1607	---	R/W	1 BIT	---	---	0/1
<b>DIGITAL OUTPUTS group</b>								
<b>EEVC</b>	Inlet SV output status. <b>0</b> = Off; <b>1</b> = On.	1361	8	R	1 BIT	---	---	0/1
<b>EEVS</b>	Outlet SV output status. <b>0</b> = Off; <b>1</b> = On.	1361	9	R	1 BIT	---	---	0/1
<b>FAN</b>	Fan output status. <b>0</b> = Off; <b>1</b> = On.	1361	10	R	1 BIT	---	---	0/1
<b>MM</b>	Mist-maker output status. <b>0</b> = Off; <b>1</b> = On.	1361	11	R	1 BIT	---	---	0/1
<b>ALARM</b>	Alarm output status. <b>0</b> = Off; <b>1</b> = On.	1361	12	R	1 BIT	---	---	0/1
<b>REGULATOR group</b>								
<b>SW EN</b>	SW enable consent. <b>0</b> = Off; <b>1</b> = On.	1126	---	R/W	1 BIT	---	---	0/1
<b>ALARMS group</b>								
<b>AL PROBE</b>	Probe alarm. <b>0</b> = Off; <b>1</b> = On.	1364	8	R	1 BIT	---	---	0/1
<b>AL TEMP LB</b>	Level board temperature alarm. <b>0</b> = Off; <b>1</b> = On.	1364	2	R	1 BIT	---	---	0/1
<b>AL COM LB</b>	Level board communication alarm. <b>0</b> = Off; <b>1</b> = On.	1364	3	R	1 BIT	---	---	0/1
<b>AL TIME MM</b>	Mist-maker operating hours alarm. <b>0</b> = Off; <b>1</b> = On.	1366	8	R	1 BIT	---	---	0/1
<b>AL TIME FAN</b>	Fan operating time alarm. <b>0</b> = Off; <b>1</b> = On.	1366	9	R	1 BIT	---	---	0/1
<b>AL LOW RH</b>	Low humidity alarm. <b>0</b> = Off; <b>1</b> = On.	1366	10	R	1 BIT	---	---	0/1
<b>AL HIGH RH</b>	High humidity alarm. <b>0</b> = Off; <b>1</b> = On.	1366	11	R	1 BIT	---	---	0/1
<b>AL LEVEL</b>	Level not reached alarm. <b>0</b> = Off; <b>1</b> = On.	1366	15	R	1 BIT	---	---	0/1
<b>WAR IMIN EEVC</b>	Inlet SV minimum current warning. <b>0</b> = Off; <b>1</b> = On.	1365	0	R	1 BIT	---	---	0/1
<b>WAR IMAX EEVC</b>	Inlet SV maximum current warning. <b>0</b> = Off; <b>1</b> = On.	1365	1	R	1 BIT	---	---	0/1
<b>WAR IMIN EEVS</b>	Outlet SV minimum current warning. <b>0</b> = Off; <b>1</b> = On.	1365	2	R	1 BIT	---	---	0/1
<b>WAR IMAX EEVS</b>	Outlet SV maximum current warning. <b>0</b> = Off; <b>1</b> = On.	1365	3	R	1 BIT	---	---	0/1
<b>WAR IMIN MM</b>	Mist-maker minimum current warning. <b>0</b> = Off; <b>1</b> = On.	1365	4	R	1 BIT	---	---	0/1
<b>WAR IMAX MM</b>	Mist-maker maximum current warning. <b>0</b> = Off; <b>1</b> = On.	1365	5	R	1 BIT	---	---	0/1

Code	Description	Val. Adr.	Filter value	R/W	DATA SIZE	CPL	MU	Range
<b>WAR IMIN FAN</b>	Fan SV minimum current warning. 0= Off; 1 = On.	1365	6	R	1 BIT	---	---	0/1
<b>WAR IMAX FAN</b>	Fan SV maximum current warning. 0= Off; 1 = On.	1365	7	R	1 BIT	---	---	0/1
<b>AL IMIN EEVC</b>	Inlet SV minimum current alarm. 0= Off; 1 = On.	1365	8	R	1 BIT	---	---	0/1
<b>AL IMAX EEVC</b>	Inlet SV maximum current alarm. 0= Off; 1 = On.	1365	9	R	1 BIT	---	---	0/1
<b>AL IMIN EEVS</b>	Outlet SV minimum current alarm. 0= Off; 1 = On.	1365	10	R	1 BIT	---	---	0/1
<b>AL IMAX EEVS</b>	Outlet SV maximum current alarm. 0= Off; 1 = On.	1365	11	R	1 BIT	---	---	0/1
<b>AL IMIN MM</b>	Mist-maker minimum current alarm. 0= Off; 1 = On.	1365	12	R	1 BIT	---	---	0/1
<b>AL IMAX MM</b>	Mist-maker maximum current alarm. 0= Off; 1 = On.	1365	13	R	1 BIT	---	---	0/1
<b>AL IMIN FAN</b>	Fan SV minimum current alarm. 0= Off; 1 = On.	1365	14	R	1 BIT	---	---	0/1
<b>AL IMAX FAN</b>	Fan SV maximum current alarm. 0= Off; 1 = On.	1365	15	R	1 BIT	---	---	0/1

## 14.8 EPJC modbus addresses (master/slave)

### 14.8.1 Modbus address table

Par.	Description	Val. Adr.	R/W	DATA SIZE	CPL	MU	Range
<b>Group</b>							
<b>E0</b>	Number of humidifiers connected.	1357	R/W	BYTES	---	---	1...4
<b>E1</b>	Operating mode. 1 = Independent; 2 = Parallel; 3 = Rotation; 4 = Balancing.	1358	R/W	BYTES	---	---	1...4
<b>E2</b>	Rotation time.	1359	R/W	BYTES	---	hours	1...24
<b>MODBUS SERIAL CONFIGURATION group</b>							
<b>LA1</b>	COM1 address (RS-485 Slave).	1545	R/W	BYTES	---	---	1...247
<b>LB1</b>	COM1 Baud rate (RS-485 Slave). 0 = 2400; 1 = 4800; 2 = 9600; 3 = 19200; 4 = 38400.	1546	R/W	3 BIT	---	---	0...4
<b>LP1</b>	COM1 parity (RS-485 Slave). 0 = None; 1 = Odd; 2 = Even.	1547	R/W	2 BIT	---	---	0...2
<b>DATA LOGGING group</b>							
<b>BLE</b>	Enable EVconnect/EPoCA. 0 = Spare; 1 = Forced for EVconnect/EPoCA; 2...99 = EPoCA local network address.	1540	R/W	BYTES	---	---	0...99
<b>PA1</b>	User level EPoCA password.	1541	R/W	SHORT	Y	---	-99...999
<b>PA2</b>	Administrator level EPoCA password.	1542	R/W	SHORT	Y	---	-99...999

## 15. DIAGNOSTICS

The table below lists alarms with corresponding solutions.

Warnings are made via LED lighting up (see “15.1 ALARMS TABLE (LED INTERFACE)” ON PAGE 87).

**NOTE:** the last blink of each alarm is followed by 5 s OFF.

### 15.1 Alarms table (LED interface)

#### 15.1.1 Warnings

LED	Lamp No.	Description	Cause	Effects	Solution
	1	Mist-maker current warning	Absorption warning thresholds exceeded in normal operation	<ul style="list-style-type: none"> <li>No effect on regulation</li> <li>LED blinks</li> </ul>	<ul style="list-style-type: none"> <li>Schedule maintenance and/or component replacement</li> <li>Contact ELSTEAM technical support</li> </ul>
	2	Fan current warning	Absorption warning thresholds exceeded in normal operation		
	3	Inlet solenoid valve current warning	Absorption warning thresholds exceeded in normal operation		
	4	Outlet solenoid valve current warning	Absorption warning thresholds exceeded in normal operation		

#### 15.1.2 Alarms

LED	Lamp No.	Description	Cause	Effects	Solution
	1	Mist-maker current alarm	Absorption alarm thresholds exceeded in normal operation	<ul style="list-style-type: none"> <li>Mist-maker OFF</li> <li>If <b>CFG</b> = 0...4 then <b>Out1</b> is activated</li> <li>LED blinks 0.5 s ON / 5 s OFF</li> </ul>	<ul style="list-style-type: none"> <li>Replace mist-maker</li> <li>Contact ELSTEAM technical support</li> </ul>
	2	Fan current alarm	Absorption alarm thresholds exceeded in normal operation	<ul style="list-style-type: none"> <li>Regulation OFF</li> <li>If <b>CFG</b> = 0...4 then <b>Out1</b> is activated</li> <li>LED blinks 0.5 s ON / 5 s OFF</li> </ul>	<ul style="list-style-type: none"> <li>Replace fan</li> <li>Contact ELSTEAM technical support</li> </ul>
	3	Inlet solenoid valve current alarm	Absorption alarm thresholds exceeded in normal operation	<ul style="list-style-type: none"> <li>Inlet solenoid valve OFF</li> <li>If <b>CFG</b> = 0...4 then <b>Out1</b> is activated</li> <li>LED blinks 0.5 s ON / 5 s OFF</li> </ul>	<ul style="list-style-type: none"> <li>Replace inlet solenoid valve</li> <li>Contact ELSTEAM technical support</li> </ul>
	4	Outlet solenoid valve current alarm	Absorption alarm thresholds exceeded in normal operation	<ul style="list-style-type: none"> <li>Outlet solenoid valve OFF</li> <li>If <b>CFG</b> = 0...4 then <b>Out1</b> is activated</li> <li>LED blinks 0.5 s ON / 5 s OFF</li> </ul>	<ul style="list-style-type: none"> <li>Replace outlet solenoid valve</li> <li>Contact ELSTEAM technical support</li> </ul>
	5	Level board high temperature alarm	<ul style="list-style-type: none"> <li>Level board high temperature</li> <li>Impurities in the water in the reservoir</li> </ul>	<ul style="list-style-type: none"> <li>Regulation OFF</li> <li>If <b>CFG</b> = 0...4 then <b>Out1</b> is activated</li> <li>LED blinks 0.5 s ON / 5 s OFF</li> </ul>	<ul style="list-style-type: none"> <li>Check the characteristics of the water</li> <li>Clean the reservoir</li> <li>Switch the humidifier off and on again</li> </ul>
	6	Mist-maker operating hours alarm	<ul style="list-style-type: none"> <li>If <b>P1</b> = 70...449 <math>\mu\text{S}\cdot\text{cm}</math>, operating hours &gt; <b>A10</b></li> <li>If <b>P1</b> = 450...849 <math>\mu\text{S}\cdot\text{cm}</math>, operating hours &gt; <b>A11</b></li> <li>If <b>P1</b> = 850...1250 <math>\mu\text{S}\cdot\text{cm}</math>, operating hours &gt; <b>A12</b></li> </ul>	<ul style="list-style-type: none"> <li>No effect on regulation</li> <li>If <b>CFG</b> = 0...4 then <b>Out1</b> is activated</li> <li>LED blinks 0.5 s ON / 5 s OFF</li> </ul>	Carry out maintenance (see “11. MAINTENANCE” ON PAGE 73)
	7	Fan operating hours alarm	Operating hours > <b>A13</b>	<ul style="list-style-type: none"> <li>No effect on regulation</li> <li>If <b>CFG</b> = 0...4 then <b>Out1</b> is activated</li> <li>LED blinks 0.5 s ON / 5 s OFF</li> </ul>	Carry out maintenance (see “11. MAINTENANCE” ON PAGE 73)

### 15.1.3 High or low humidity alarm

Only if **CFG** = 2, 3, 4, 7, 8, 9.

LED	Description	Cause	Effects	Solution
	High humidity alarm	<ul style="list-style-type: none"> <li>RH sensor &gt; <b>A6</b> for a time <b>A7</b></li> <li>RH sensor not working or not connected</li> </ul>	<ul style="list-style-type: none"> <li>LED blinks 0.5 s ON / 0.5 s OFF</li> <li>Mist-maker and fan OFF until automatic reset</li> <li>If <b>CFG</b> = 0...4, alarm output ON</li> </ul>	RH sensor < <b>A6</b> - 2 % reactivation is automatic
	Low humidity alarm	<ul style="list-style-type: none"> <li>RH sensor &lt; <b>A5</b> for a time <b>A7</b></li> <li>RH sensor not working or not connected</li> </ul>	<ul style="list-style-type: none"> <li>LED blinks 1 s ON / 1 s OFF</li> <li>Mist-maker and fan OFF until automatic reset</li> <li>If <b>CFG</b> = 0...4, alarm output ON</li> </ul>	RH sensor > <b>A5</b> + 2 % reactivation is automatic

### 15.1.4 Level sensor alarm

LED	Description	Cause	Effects	Solution
	Level sensor alarm	Level board not working	<ul style="list-style-type: none"> <li>Regulation OFF</li> <li>LED blinks 0.5 s ON / 0.5 s OFF</li> <li>If <b>CFG</b> = 0...4, alarm output ON</li> </ul>	Contact ELSTEAM technical support
	Level sensor self-test alarm			Check for correct water pressure. If the alarm reoccurs at reset, replace the control board

### 15.1.5 Water alarm

LED	Description	Cause	Effects	Solution
	Minimum water level alarm	<ul style="list-style-type: none"> <li>Level board not working</li> <li>Minimum water level not reached</li> <li>Water present after draining</li> </ul>	<p><i>Level board not working:</i></p> <ul style="list-style-type: none"> <li>mist-maker and fan OFF</li> <li>LED on steady</li> <li>If <b>CFG</b> = 0...4, alarm output ON</li> </ul> <p><i>Minimum water level not reached:</i></p> <ul style="list-style-type: none"> <li>mist-maker OFF</li> <li>LED blinks 3 s ON/3 s OFF</li> <li>If <b>CFG</b> = 0...4, alarm output ON</li> </ul> <p><i>Water present after draining:</i></p> <ul style="list-style-type: none"> <li>mist-maker and fan OFF</li> <li>LED blinks 0.5 s ON/ 0.5 s OFF</li> <li>If <b>CFG</b> = 0...4, alarm output ON</li> </ul>	Contact ELSTEAM technical support

## 15.2 Alarms table (EV3K interface)

The table below lists alarms with corresponding solutions.

The upper line of the display shows **Err** (if alarm in progress) or **UUor** (if warning in progress).


**NOTE:** LED user interface

Code	Type	Description	Cause	Effects	Solution
<b>Pr1</b>	<b>Err</b>	Adjustment sensor error	<ul style="list-style-type: none"> <li>Probe not working</li> <li>Probe not connected properly</li> <li>Incorrect probe type</li> </ul>	<ul style="list-style-type: none"> <li>Showing code <b>Pr1</b></li> <li>Alarm LED  lit steadily</li> <li>ON alarm output</li> <li>If <b>CFG</b> = 0...4, alarm output ON</li> </ul>	<ul style="list-style-type: none"> <li>Check the sensor type</li> <li>Check the sensor wiring</li> <li>Change the sensor type</li> <li>Automatic reset</li> </ul>
<b>Pr2</b>	<b>Err</b>	NTC on-board sensor error	<ul style="list-style-type: none"> <li>NTC on-board sensor not working</li> <li>Level board not working</li> </ul>	<ul style="list-style-type: none"> <li>Showing code <b>Pr2</b></li> <li>Alarm LED  lit steadily</li> <li>Regulation OFF</li> <li>If <b>CFG</b> = 0...4, alarm output ON</li> </ul>	<ul style="list-style-type: none"> <li>Replace level board</li> <li>Contact ELSTEAM technical support</li> <li>Automatic reset</li> </ul>

Code	Type	Description	Cause	Effects	Solution
A1	UUor	Inlet solenoid valve minimum current alarm	Absorption thresholds exceeded in normal operation	<ul style="list-style-type: none"> <li>Showing code <b>A1</b></li> <li>Indicator LED  lit steadily</li> </ul>	<ul style="list-style-type: none"> <li>Replace inlet solenoid valve</li> <li>Contact ELSTEAM technical support</li> </ul>
	Err			<ul style="list-style-type: none"> <li>Showing code <b>A1</b></li> <li>Alarm LED  lit steadily</li> <li>Regulation OFF</li> <li>If <b>CFG</b> = 0...4, alarm output ON</li> </ul>	
A2	UUor	Inlet solenoid valve maximum current alarm	Absorption thresholds exceeded in normal operation	<ul style="list-style-type: none"> <li>Showing code <b>A2</b></li> <li>Indicator LED  lit steadily</li> </ul>	<ul style="list-style-type: none"> <li>Replace inlet solenoid valve</li> <li>Contact ELSTEAM technical support</li> </ul>
	Err			<ul style="list-style-type: none"> <li>Showing code <b>A2</b></li> <li>Alarm LED  lit steadily</li> <li>Regulation OFF</li> <li>If <b>CFG</b> = 0...4, alarm output ON</li> </ul>	
A3	UUor	Outlet solenoid valve minimum current alarm	Absorption thresholds exceeded in normal operation	<ul style="list-style-type: none"> <li>Showing code <b>A3</b></li> <li>Indicator LED  lit steadily</li> </ul>	<ul style="list-style-type: none"> <li>Replace outlet solenoid valve</li> <li>Contact ELSTEAM technical support</li> </ul>
	Err			<ul style="list-style-type: none"> <li>Showing code <b>A3</b></li> <li>Alarm LED  lit steadily</li> <li>Regulation OFF</li> <li>If <b>CFG</b> = 0...4, alarm output ON</li> </ul>	
A4	UUor	Outlet solenoid valve maximum current alarm	Absorption thresholds exceeded in normal operation	<ul style="list-style-type: none"> <li>Showing code <b>A4</b></li> <li>Indicator LED  lit steadily</li> </ul>	<ul style="list-style-type: none"> <li>Replace outlet solenoid valve</li> <li>Contact ELSTEAM technical support</li> </ul>
	Err			<ul style="list-style-type: none"> <li>Showing code <b>A4</b></li> <li>Alarm LED  lit steadily</li> <li>Regulation OFF</li> <li>If <b>CFG</b> = 0...4, alarm output ON</li> </ul>	
A5	UUor	Mist-maker minimum current alarm	Absorption thresholds exceeded in normal operation	<ul style="list-style-type: none"> <li>Showing code <b>A5</b></li> <li>Indicator LED  lit steadily</li> </ul>	<ul style="list-style-type: none"> <li>Replace mist-maker</li> <li>Contact ELSTEAM technical support</li> </ul>
	Err			<ul style="list-style-type: none"> <li>Showing code <b>A5</b></li> <li>Alarm LED  lit steadily</li> <li>Regulation OFF</li> <li>If <b>CFG</b> = 0...4, alarm output ON</li> </ul>	
A6	UUor	Mist-maker maximum current alarm	Absorption thresholds exceeded in normal operation	<ul style="list-style-type: none"> <li>Showing code <b>A6</b></li> <li>Indicator LED  lit steadily</li> </ul>	<ul style="list-style-type: none"> <li>Replace mist-maker</li> <li>Contact ELSTEAM technical support</li> </ul>
	Err			<ul style="list-style-type: none"> <li>Showing code <b>A6</b></li> <li>Alarm LED  lit steadily</li> <li>Regulation OFF</li> <li>If <b>CFG</b> = 0...4, alarm output ON</li> </ul>	
A7	UUor	Fan minimum current alarm	Absorption thresholds exceeded in normal operation	<ul style="list-style-type: none"> <li>Showing code <b>A7</b></li> <li>Indicator LED  lit steadily</li> </ul>	<ul style="list-style-type: none"> <li>Automatic reset</li> <li>Contact ELSTEAM technical support</li> </ul>
	Err			<ul style="list-style-type: none"> <li>Showing code <b>A7</b></li> <li>Alarm LED  lit steadily</li> <li>Regulation OFF</li> <li>If <b>CFG</b> = 0...4, alarm output ON</li> </ul>	
A8	UUor	Fan maximum current alarm	Absorption thresholds exceeded in normal operation	<ul style="list-style-type: none"> <li>Showing code <b>A8</b></li> <li>Indicator LED  lit steadily</li> </ul>	<ul style="list-style-type: none"> <li>Automatic reset</li> <li>Contact ELSTEAM technical support</li> </ul>
	Err			<ul style="list-style-type: none"> <li>Showing code <b>A8</b></li> <li>Alarm LED  lit steadily</li> <li>Regulation OFF</li> <li>If <b>CFG</b> = 0...4, alarm output ON</li> </ul>	
A9	UUor	Mist-maker operating hours alarm	<ul style="list-style-type: none"> <li>If <b>P1</b> = 70...449 <math>\mu\text{S}\cdot\text{cm}</math>, operating hours &gt; <b>A10</b></li> <li>If <b>P1</b> = 450...849 <math>\mu\text{S}\cdot\text{cm}</math>, operating hours &gt; <b>A11</b></li> <li>If <b>P1</b> = 850...1250 <math>\mu\text{S}\cdot\text{cm}</math>, operating hours &gt; <b>A12</b></li> </ul>	<ul style="list-style-type: none"> <li>Showing code <b>A9</b></li> <li>Indicator LED  lit steadily</li> <li>No effect on regulation</li> </ul>	Carry out maintenance (see " <b>11. MAINTENANCE</b> " ON <b>PAGE 73</b> )
A10	UUor	Fan operating hours alarm	Fan operating hours > <b>A13</b>	<ul style="list-style-type: none"> <li>Showing code <b>A10</b></li> <li>Indicator LED  lit steadily</li> <li>No effect on regulation</li> </ul>	Carry out maintenance (see " <b>11. MAINTENANCE</b> " ON <b>PAGE 73</b> )
A11	Err	Low humidity alarm	RH sensor humidity < <b>A5</b> for a time period <b>A7</b>	<ul style="list-style-type: none"> <li>Showing code <b>A11</b></li> <li>Alarm LED  lit steadily</li> <li>Mist-maker and fan OFF until automatic reset</li> <li>If <b>CFG</b> = 0...4, alarm output ON</li> </ul>	Reactivation is automatic if RH sensor > <b>A5</b> + 2 %

Code	Type	Description	Cause	Effects	Solution
<b>A12</b>	<b>Err</b>	High humidity alarm	RH sensor humidity > <b>A6</b> for a time period <b>A7</b>	<ul style="list-style-type: none"> <li>• Showing code <b>A12</b></li> <li>• Alarm LED  lit steadily</li> <li>• Mist-maker and fan OFF until automatic reset</li> <li>• If <b>CFG</b> = 0...4, alarm output ON</li> </ul>	Reactivation is automatic if RH sensor < <b>A6</b> - 2 %
<b>A13</b>	<b>Err</b>	Level board high temperature alarm	<ul style="list-style-type: none"> <li>• Level board high temperature</li> <li>• Impurities in the water in the reservoir</li> </ul>	<ul style="list-style-type: none"> <li>• Showing code <b>A13</b></li> <li>• Alarm LED  lit steadily</li> <li>• Regulation OFF</li> <li>• If <b>CFG</b> = 0...4, alarm output ON</li> </ul>	<ul style="list-style-type: none"> <li>• Check the characteristics of the water</li> <li>• Clean the reservoir</li> <li>• Switch the humidifier off and on again</li> </ul>
<b>SCh</b>	<b>Err</b>	<b>Mistral</b> communication alarm	<b>Mistral</b> no communication	<ul style="list-style-type: none"> <li>• Showing code <b>SCh</b></li> <li>• Alarm LED  lit steadily</li> <li>• Regulation OFF until automatic reset</li> <li>• If <b>CFG</b> = 0...4, alarm output ON</li> </ul>	<ul style="list-style-type: none"> <li>• Automatic reset</li> <li>• Contact ELSTEAM technical support</li> </ul>
<b>ERRc</b>	<b>Err</b>	<b>EV3K</b> and <b>Mistral</b> communication alarm	No communication between <b>EV3K</b> interface and <b>Mistral</b>	<ul style="list-style-type: none"> <li>• Showing code <b>ERRc</b></li> <li>• Alarm LED  lit steadily</li> <li>• Regulation OFF until automatic reset</li> <li>• If <b>CFG</b> = 0...4, alarm output ON</li> </ul>	<ul style="list-style-type: none"> <li>• Restore communication between EV3K and Mistral</li> <li>• Automatic reset</li> </ul>
<b>LEu</b>	<b>Err</b>	Minimum water level alarm	Water level < <b>r9</b>	<ul style="list-style-type: none"> <li>• Showing code <b>LEu</b></li> <li>• Alarm LED  lit steadily</li> <li>• Mist-maker and fan OFF until automatic reset</li> <li>• If <b>CFG</b> = 0...4, alarm output ON</li> </ul>	<ul style="list-style-type: none"> <li>• Wait for the water level to reach the minimum required level for production</li> <li>• Automatic reset</li> </ul>

# 16. WIRING DIAGRAM



This document and the solutions contained within it are the intellectual property of ELSTEAM, safeguarded by the Italian Industrial Property Code (CPI). ELSTEAM forbids the reproduction and distribution, even in part, of the contents, unless express authorisation is obtained directly from ELSTEAM.

The customer (manufacturer, installer or end user) assumes all responsibility for device configuration.

ELSTEAM does not assume any responsibility for potential errors and reserves the right to make any changes, at any time, without the basic functional and safety-related features being affected.

## **MADE IN ITALY**

### **ELSTEAM S.r.l.**

Via Enrico Fermi 496, 21042,  
Caronno Pertusella (VA) ITALY

**Telephone:** +39 02 9659890

**Fax:** +39 02 96457007

**Email:** [info@elsteam.it](mailto:info@elsteam.it)

**Web:** [www.elsteam.com](http://www.elsteam.com)













