


# VEH OEM

Immersed electrode humidifiers for air handling units



**⚠ WARNING**  
Make sure you read and fully understand the manual before using this device.  
**Non-observance of these instructions may result in death or serious injury.**



# CONTENTS

<b>IMPORTANT INFORMATION</b>	<b>6</b>
<b>IMPORTANT SAFETY INFORMATION</b>	<b>7</b>
<b>SAFETY INFORMATION RELATING TO THE PRODUCT</b>	<b>8</b>
<b>SAFETY INFORMATION RELATED TO HEALTH AND HYGIENE</b>	<b>9</b>
<b>1. INTRODUCTION</b>	<b>10</b>
1.1 Description	10
1.2 Product overview	10
1.3 Why choose VEH?	11
1.4 Main features	11
1.4.1 Electronic control features	11
1.5 Applications	11
1.6 Available models	12
1.7 Available configurations	12
1.7.1 400 Vac three-phase models	12
1.7.2 460 Vac three-phase models	12
1.8 Accessories	13
1.8.1 Hydraulic unit extraction flange	13
<b>2. TECHNICAL DATA</b>	<b>15</b>
2.1 Technical specifications	15
2.1.1 400 Vac models   VEH OEM	15
2.1.2 460 Vac models   VEH OEM	16
<b>3. RECEIVING THE PRODUCT</b>	<b>17</b>
3.1 Checking the packaging	17
3.1.1 Opening the packaging	17
3.1.2 Checking the packaging contents	17
<b>4. DIMENSIONS AND MECHANICAL ASSEMBLY</b>	<b>18</b>
4.1 Dimensions	18
4.1.1 Hydraulic unit	18
4.2 Hydraulic unit installation	19
4.2.1 Installation instructions	19
4.2.2 Minimum installation dimensions	19
4.2.3 Minimum distances for one hydraulic unit - AHU	20
4.2.4 Minimum distances for two hydraulic units - AHU	21
<b>5. INSTALLATION</b>	<b>22</b>
5.1 Hydraulic unit structure	22
5.1.1 Rear	22
5.2 Plumbing installation	22
5.2.1 Water specifications	23
5.3 Water drainage system	23
5.3.1 Connection specifications	23



# CONTENTS

5.4 Steam distribution in the AHU .....	24
<b>6. ELECTRICAL CONNECTIONS .....</b>	<b>25</b>
6.1 Before you start .....	25
6.2 Connection best practice .....	25
6.2.1 Wiring best practices .....	25
6.3 Dimensioning electrical components .....	27
6.4 Electrical connections .....	28
6.4.1 Control board .....	28
6.4.2 Expansion .....	29
6.5 Configurations .....	30
6.5.1 ON/OFF connection with humidistat or external contact (CFG = 0-1) .....	30
6.5.2 External proportional humidistat connection (CFG = PROP) .....	30
6.5.3 Humidity sensor connection (CFG = HUM) .....	30
6.5.4 Humidity sensor connection EVHTP520 (CFG = HUM) .....	31
6.5.5 Connection for humidity sensor and limit sensor (CFG = HUML) .....	31
6.5.6 Temperature sensor connection (CFG = 1T) .....	31
6.5.7 Connection for two temperature sensors (CFG = 2T) .....	32
6.5.8 Humidity sensor connection 0...5 V / 0...10 V .....	32
6.6 Power supply and earth wiring connection .....	32
6.7 DIP switch functions .....	33
6.7.1 DIP switch   Control board .....	33
6.7.2 DIP switch   Expansion .....	33
<b>7. USER INTERFACE (OPTIONAL) .....</b>	<b>34</b>
7.1 User interface .....	34
7.1.1 Icons .....	34
7.1.2 Keys .....	34
7.1.3 First start-up .....	35
7.2 User interface menu .....	35
7.2.1 Home screen .....	35
7.2.2 Changing the main sensor humidity setpoint .....	36
7.2.3 Changing the temperature setpoint .....	36
7.2.4 Manual draining .....	36
7.2.5 Menu .....	37
7.2.6 User Menu .....	38
7.2.7 Maintenance menu .....	39
7.2.8 Displaying/resetting the operating hours .....	40
7.2.9 Output functional test .....	41
<b>8. POWER-UP AND START-UP .....</b>	<b>42</b>
8.1 First start-up instructions .....	42
8.2 Instructions for seasonal or long-term shut-down .....	42
8.3 Starting up after a seasonal or long-term shut-down .....	43



# CONTENTS

<b>9. OPERATION</b>	<b>44</b>
9.1 Principle of operation	44
9.2 Humidity regulation	44
9.2.1 ON-OFF regulation   CFG = 0-1	44
9.2.2 Proportional regulation   CFG = PROP	44
9.2.3 Regulation with the humidity sensor   CFG = HUM	45
9.2.4 Regulation with the humidity sensor + limit sensor   CFG = HUML	46
9.2.5 Regulation with a temperature probe   CFG = 1T	47
9.2.6 Regulation with two temperature probes   CFG = 2T	47
9.3 Water dilution	47
9.3.1 Current-based water dilution	47
9.3.2 Time-based water dilution	48
9.4 Hydraulic unit draining	48
9.5 Complete hydraulic unit emptying	48
9.6 Level sensor	48
9.7 Foam management	48
9.8 Operating hours	49
9.8.1 Resetting the operating hours	49
9.9 Overproduction	49
<b>10. CONFIGURATION PARAMETERS</b>	<b>50</b>
9.10 Table of adjustment parameters	50
<b>11. MODBUS RTU FUNCTIONS AND RESOURCES</b>	<b>53</b>
11.1 Introduction	53
11.2 Modbus message structure	53
11.3 Modbus functions and registers	53
11.3.1 Available Modbus commands and data areas	54
11.4 Address configuration	54
11.5 Connections	54
11.6 Modbus table content	54
11.7 Modbus addresses	55
11.7.1 Modbus address table	55
11.7.2 Modbus resource table	58
<b>12. DIAGNOSTICS</b>	<b>61</b>
12.1 Table of VEH alarms	61
<b>13. MAINTENANCE</b>	<b>66</b>
13.1 Introduction	66
13.2 Regular cleaning of the product and its components	68
13.3 Cleaning the tank	68
13.4 Cleaning the optional STAINLESS STEEL discharge tank (VI accessory)	68



# CONTENTS

13.5 Replacing the electrodes .....	68
<b>14. SPARE PARTS .....</b>	<b>69</b>
14.1 Hydraulic unit .....	69
14.2 Electrical part.....	70
<b>15. WIRING DIAGRAMS.....</b>	<b>71</b>
15.1 VEH OEM humidifier (4 or 7 electrodes).....	71
15.2 VEH OEM dual hydraulic unit humidifier .....	72
<b>16. MODEL SELECTION AND DEFINITION .....</b>	<b>73</b>
16.1 Introduction.....	73
16.2 Procedure for selecting and defining the model .....	73

# IMPORTANT INFORMATION

## Liability and residual risks

ELSTEAM assumes no liability for any damage caused by the following (by way of example; this is not an exhaustive list):

- Installation/use for purposes other than those specified and, in particular, not adhering to the safety provisions set out by current regulations in the country in which the product is installed and/or contained in this manual;
- Use in appliances that do not guarantee sufficient protection against electric shocks, water and dust within the installation conditions created;
- Use in appliances that allow access to hazardous parts without the use of a keyed or tooled locking mechanism when accessing the instrument;
- Tampering and/or modifying the product;
- Installation/use in appliances which do not comply with current regulations in the country in which the product is installed.

The customer/manufacturer is responsible for ensuring their machine complies with these regulations.

ELSTEAM's responsibility is limited to the correct and professional use of the product in accordance with regulations and the instructions contained in this manual and other product support documents.

To comply with EMC standards, observe all the electrical connection instructions. As it depends on the wiring configuration as well as the load and the installation type, compliance must be verified for the final machine as specified by the relevant product standard.

## Disclaimer

This document is the exclusive property of ELSTEAM. It contains a general description and/or a description of the technical specifications for the services offered by the products listed herein. This document should not be used to determine the suitability or reliability of these products in relation to specific user applications. Each user or integration specialist should conduct their own complete and appropriate risk analysis, in addition to carrying out a product evaluation and test in relation to its specific application or use. Users can send us comments and suggestions on how to improve or correct this publication.

Neither ELSTEAM nor any of its associates or subsidiaries shall be held responsible or liable for improper use of the information contained herein.

ELSTEAM has a policy of continuous development; therefore, ELSTEAM reserves the right to make changes and improvements to any product described in this document without prior notice.

The images in this document and other documentation supplied with the product are provided for illustrative purposes only and may differ from the product itself.

The technical data in this manual is subject to change without prior notice.

## Terms and Conditions of use

### Permitted use

The device should only be used for humidification inside the air treatment unit (AHU).

The device must be installed and used in accordance with the instructions provided and, in particular, hazardous live parts or highly pressurised water must not be accessible under normal conditions.

The device must be suitably protected from water and dust with regard to its application and must also only be accessible with the aid of a tool.

Only qualified personnel may install the product or perform technical support procedures on it.

The customer must only use the product as described in the documentation relating to that product.

### Prohibited use

Any use other than those described in the "**Permitted use**" section and in the product support documentation is prohibited.

## Disposal



The device must be disposed of in accordance with local regulations regarding the collection of electrical and electronic appliances.

## Consider the environment



The company works towards protecting the environment, while taking account of customer requirements, technological innovations in materials and the expectations of the community to which we belong. ELSTEAM places great importance on respecting the environment, encouraging all associates to become involved with company values and guaranteeing safe, healthy and functional working conditions and workplaces.

**Please consider the environment before printing this document.**

# IMPORTANT SAFETY INFORMATION

Please read this document carefully before installation; study all the warnings before using the device. Only use the device in accordance with the methods described in this document. The following safety messages may be repeated several times in the document, to provide information regarding potential hazards or to attract attention to information which may be useful in explaining or clarifying a procedure.

## SYMBOLS



This symbol is used to indicate a risk of electric shock.  
It is a safety indication and as such, should be observed to avoid potential accidents or fatalities.



This symbol is used to indicate a risk of serious personal injury.  
It is a safety indication and as such, should be observed to avoid potential accidents or fatalities.



This symbol is used to indicate a serious risk of exposure to biological agents.  
It is a safety indication and as such, should be observed to avoid potential accidents or fatalities.



This symbol is used to indicate a serious risk of scalding from steam.  
It is a safety indication and as such, should be observed to avoid potential accidents or fatalities.



This symbol is used to indicate a risk of serious burns.  
It is a safety indication and as such, should be observed to avoid potential accidents or fatalities.

## SAFETY MESSAGES

### **DANGER**

**DANGER** indicates a situation of imminent danger which, if not avoided, **will lead to death or serious injury**.

### **WARNING**

**WARNING** indicates a situation of imminent danger which, if not avoided, **may lead to death or serious injury**.

### **WARNING**

**WARNING** indicates a situation of imminent danger which, if not avoided, **may lead to death or serious injury**.

### **CAUTION**

**CAUTION** indicates a potentially hazardous situation which, if not avoided, **could cause minor or moderate injury**.

### **NOTICE**

**NOTICE** indicates a situation not related to physical injuries but which, if not avoided, **could damage the equipment**.

**NOTE:** the maintenance, repair, installation and use of the equipment must only be entrusted to qualified personnel.

## QUALIFIED PERSONNEL

Only suitably trained and experienced personnel capable of understanding the content of this manual and all documentation regarding the product are authorised to work on and with this equipment. Furthermore, the personnel must have completed courses in safety and must be able to recognise and prevent the implied dangers. The personnel must have suitable training, knowledge and experience at a technical level, and be capable of anticipating and detecting potential risks caused by using the product, as well as changing the settings and modifying the mechanical, electric and electronic equipment for the entire system in which the product is used. All personnel working on and with the product must be entirely familiar with the relevant standards and directives, as well as safety regulations.

## UNAUTHORISED PERSONNEL

The humidifier must **not** be used by persons (including children) with reduced physical, sensory or mental capabilities or persons with no experience or knowledge.

# SAFETY INFORMATION RELATING TO THE PRODUCT

**VEH OEM** series humidifiers are defined as **"NOT ACCESSIBLE TO THE PUBLIC"**.

Before carrying out any work on the equipment, read these instructions carefully, making sure you understand everything.

## **DANGER**

### **RISK OF ELECTRIC SHOCK, EXPLOSION OR ELECTRIC ARC**

- Only use electrically insulated measuring devices and equipment.
- Do not install the equipment while the power supply is connected.
- Cut off the power supply to all equipment, including any connected devices, before removing any covers or hatches, or before installing/uninstalling accessories, hardware, cables or wires.
- Provide safety interlocks (isolators) of a suitable size between the power supply and the humidifier, with a contact opening distance of at least 3 mm for each pole.
- Always use a properly calibrated Voltmeter to make sure the system is powered off.
- The maintenance, repair, installation and use of the equipment must only be entrusted to qualified personnel.
- Do not touch the unshielded components or the terminals while they are live.
- Do not open, disassemble, repair or modify the product.
- Do not expose the equipment to liquids or chemicals.
- Make sure there is an effective earth connection.
- Before applying voltage to the equipment:
  - Make sure all protective elements, such as covers, hatches and grilles, are fitted and/or closed using a tool (e.g. a spanner).
  - Check all wiring connections.

## **DANGER**

### **RISK OF ELECTRIC SHOCK AND FIRE**

- Do not use the device with loads greater than those indicated in the technical data section.
- Do not exceed the temperature and humidity ranges indicated in the technical data section.
- Provide safety interlocks (isolators) of a suitable size between the power supply and the humidifier.
- Only use cables with a suitable cross-section as indicated in the section "Wiring best practices".

## **WARNING**

### **MALFUNCTIONING OF THE EQUIPMENT**

- Perform the wiring carefully, in compliance with electromagnetic compatibility and safety requirements.
- Carry out a full start-up test.
- Make sure the wiring is correct for the end application.
- Minimise the length of the connections as much as possible, to avoid winding the cables around electrically connected parts.
- Before applying the power supply, check all the wiring connections.
- Do not connect wires to unused terminals and/or terminals marked with the text "No connection" ("N.C.").

The humidifier produces steam at 100 °C (212 °F) and discharges water at a temperature of approximately 98 °C (208.4 °F).

## **WARNING**

### **HOT WATER VAPOUR**

Do not touch the equipment while it is running.

## **WARNING**

### **RISK OF BURNS**

Before carrying out any work on the system, place the equipment out of service and wait for the machine to cool down (< 50 °C (122 °F)).

## **WARNING**

### **REGULATORY INCOMPATIBILITY**

Make sure all the equipment used and systems designed conform to current local, regional and national standards.

## SAFETY INFORMATION RELATED TO HEALTH AND HYGIENE

The **VEH OEM** humidifier features:

- Automatic draining for inactivity;
- Periodic automatic cleaning;
- Plastic material on whose surface bacterial colonies do not proliferate.

Inadequate use and/or poor maintenance of the humidifier can damage your health.



### WARNING

#### **BIOLOGICAL RISK**

- In the event of poor maintenance/cleaning after the humidifier has been shut-down for a long time, microorganisms (including the bacteria that cause Legionellosis) may proliferate and be transferred into the air treatment system.
- The humidifier must be used properly and be maintained and cleaned properly at prescribed intervals, as described in the **MAINTENANCE** chapter.

Thoroughly remove limescale and biofilm residues from the reservoir and drain (rinse the inside of the reservoir with 20% citric acid and appropriate biocides, and clean the limescale off the surface).

# 1. INTRODUCTION

## 1.1 Description

**VEH OEM** is the ELSTEAM immersed electrode humidifier solution dedicated to installations within air handling units (AHUs).

The **VEH OEM** humidifier consists of 4 elements:

- Hydraulic unit;
- Wiring kit;
- Electronic controller on DIN rail mount;
- TA current sensor.

As an option, it can have the following:

- 2 hydraulic units;
- 2 wiring kits;
- Electronic controller + expansion controller on DIN rail mount;
- 2 TA current sensors.

It can all be equipped with an LED HMI interface and other accessories (see chapter "**1.8 ACCESSORIES**" ON PAGE 13)

**VEH** series humidifiers generate humidity (steam) by means of a current passing between 4 or more electrodes immersed in drinking water and bringing it to boiling point.

The steam is controlled by adjusting the intensity of the current transferred to the water by the immersed electrodes, which indirectly controls the boiling of the water.


Steam is produced and pumped directly into an AHU (air handling unit) or into an air conditioning duct by positioning the hydraulic module inside the unit.

**VEH** series humidifiers do not require a technical area if installed outdoors, as the hydraulic unit is installed inside the AHU; moreover, it is not affected by condensation in the steam supply pipe, as it introduces steam from the hydraulic unit directly into the AHU, which also overcomes pressure differences. The hydraulic unit is not subject to drops in energy efficiency caused by condensation and low outdoor temperatures.

To prevent the ice from forming during winter, use heating cables for the water supply and discharge pipes.

**NOTE:** **VEH OEM** series humidifiers are defined as "**NOT ACCESSIBLE TO THE PUBLIC**".

## 1.2 Product overview



**Fig. 1.** Hydraulic unit overview

Reference	Description	Reference	Description
①	Water drain outlet	④	Water filling solenoid valve
②	Power supply wiring entry	⑤	Electric outlet pump
③	Water filling inlet	⑥	Steam outlet

### 1.3 Why choose VEH?

Compared to traditional immersed electrode humidifiers on the market, **VEH** offers several advantages, including:

- *No back pressure effects*: Steam is produced in the hydraulic unit located inside the AHU.
- *Improved thermal efficiency*: There are no steam pipes and distributors subject to condensation due to the connection between the boiler and the distributor.
- *Quick and easy maintenance*: The boiler consists of a parallelepiped tank with a low height; it is easy to access the electrodes and clean it once the two covers are removed.
- *It does not require a protected technical area*: The hydraulic part is inside the AHU, while the AHU manufacturer has integrated the electrical components and electronic controller into the electrical compartment of the AHU, or at its discretion in another dedicated space.

### 1.4 Main features

- Isothermal humidifier;
- Sterile steam (steam with a temperature of approximately 100 °C (212 °F));
- Automatic limescale removal from the tank;
- Broad range of steam production (10...200 kg/h);
- Integrated electronic control via probe or humidistat (with external ON/OFF signal, or in proportional mode from external 0...10 V / 4...20 mA signal or internal configuration);
- Stainless steel water drainage tray (on request);
- Stainless steel condensate collection tank for AHUs (on request).

#### 1.4.1 Electronic control features

- Proportional microprocessor control of steam production:
  - High efficiency;
  - Rapid response to changes in requirements;
  - Precise production control.
- Automatic electrode and tank cleaning cycles:
  - Reduced maintenance frequency;
  - High performance levels;
  - Longer electrode and tank life.
- Automatic hydraulic unit discharge:
  - Removal of limescale residues deposited in the manifold sleeve facilitated by the action of the drainage pump, which can even eliminate medium-sized clusters and grind them down;
  - Longer tank life.
- Operating status signalling via a user interface with a 2-line, 16-character display:
  - Periodic maintenance alerts;
  - Continuous monitoring of the operating status;
  - Automatic analysis of malfunctions.

### 1.5 Applications

The **VEH OEM** series is mainly used in applications requiring sterile steam, including:

- Hospital settings;
- Medical settings;
- Commercial settings (offices, industrial premises, etc.);
- Industrial processes that use AHUs.

## 1.6 Available models

P/n	Name	VEH OEM immersed electrode humidifier...
<b>EHKOD010T0XS</b>	VEH OEM 10XS	10 kg/h, 400/460 Vac, three-phase, extra small (XS)
<b>EHKOD020T0XS</b>	VEH OEM 20XS	20 kg/h, 400/460 Vac, three-phase, extra small (XS)
<b>EHKOD020T0S</b>	VEH OEM 20S	20 kg/h, 400/460 Vac, three-phase, small (S)
<b>EHKOD030T0M</b>	VEH OEM 30M	30 kg/h, 400/460 Vac, three-phase, medium (M)
<b>EHKOD040T0S</b>	VEH OEM 40S	40 kg/h, 400/460 Vac, three-phase, small (S)
<b>EHKOD040T0L</b>	VEH OEM 40L	40 kg/h, 400/460 Vac, three-phase, large (L)
<b>EHKOD060T0M</b>	VEH OEM 60M	60 kg/h, 400/460 Vac, three-phase, medium (M)
<b>EHKOD060T0XL</b>	VEH OEM 60XL	60 kg/h, 400/460 Vac, three-phase, extra large (XL)
<b>EHKOD080T0L</b>	VEH OEM 80L	80 kg/h, 400/460 Vac, three-phase, large (L)
<b>EHKOD100T0XL</b>	VEH OEM 100XL	100 kg/h, 400/460 Vac, three-phase, extra large (XL)

## 1.7 Available configurations

### 1.7.1 400 Vac three-phase models

P/n	Name	VEH OEM immersed electrode humidifier...
<b>EHKOD010T4XS</b>	VEH OEM 10XS	10 kg/h, 400 Vac, three-phase, extra small (XS)
<b>EHKOD020T4XS</b>	VEH OEM 20XS	20 kg/h, 400 Vac, three-phase, extra small (XS)
<b>EHKOD020T4S</b>	VEH OEM 20S	20 kg/h, 400 Vac, three-phase, small (S)
<b>EHKOD030T4M</b>	VEH OEM 30M	30 kg/h, 400 Vac, three-phase, medium (M)
<b>EHKOD040T4S</b>	VEH OEM 40S	40 kg/h, 400 Vac, three-phase, small (S)
<b>EHKOD040T4L</b>	VEH OEM 40L	40 kg/h, 400 Vac, three-phase, large (L)
<b>EHKOD060T4M</b>	VEH OEM 60M	60 kg/h, 400 Vac, three-phase, medium (M)
<b>EHKOD060T4XL</b>	VEH OEM 60XL	60 kg/h, 400 Vac, three-phase, extra large (XL)
<b>EHKOD080T4L</b>	VEH OEM 80L	80 kg/h, 400 Vac, three-phase, large (L)
<b>EHKOD100T4XL</b>	VEH OEM 100XL	100 kg/h, 400 Vac, three-phase, extra large (XL)

### 1.7.2 460 Vac three-phase models


P/n	Name	VEH OEM immersed electrode humidifier...
<b>EHKD010T5XS</b>	VEH OEM 10XS	10 kg/h, 460 Vac, three-phase, extra small (XS)
<b>EHKD020T5XS</b>	VEH OEM 20XS	20 kg/h, 460 Vac, three-phase, extra small (XS)
<b>EHKD020T5S</b>	VEH OEM 20S	20 kg/h, 460 Vac, three-phase, small (S)
<b>EHKD030T5S</b>	VEH OEM 30S	30 kg/h, 460 Vac, three-phase, small (S)
<b>EHKD030T5M</b>	VEH OEM 30M	30 kg/h, 460 Vac, three-phase, medium (M)
<b>EHKD040T5S</b>	VEH OEM 40S	40 kg/h, 460 Vac, three-phase, small (S)
<b>EHKD040T5L</b>	VEH OEM 40L	40 kg/h, 460 Vac, three-phase, large (L)
<b>EHKD060T5M</b>	VEH OEM 60M	60 kg/h, 460 Vac, three-phase, medium (M)
<b>EHKD060T5XL</b>	VEH OEM 60XL	60 kg/h, 460 Vac, three-phase, extra large (XL)
<b>EHKD080T5L</b>	VEH OEM 80L	80 kg/h, 460 Vac, three-phase, large (L)
<b>EHKD100T5XL</b>	VEH OEM 100XL	100 kg/h, 460 Vac, three-phase, extra large (XL)

## 1.8 Accessories

The following accessories are available for use with **VEH OEM** series immersed electrode humidifiers:

P/n	Description	P/n	Description
<b>EHKD0K20</b>	Hydraulic unit removal flange kit	<b>0016020018</b>	Condensate collection tank 490x690x70 AISI304
<b>EHKD0K21</b>	D40 drainage unit kit	<b>0016020019</b>	Condensate collection tank 490x950x70 AISI304
<b>EHKD0K08</b>	3 m power cable kit for <b>VEH OEM 10-20-30-40</b>	<b>0016020020</b>	Condensate collection tank 490x1350x70 AISI304
<b>EHKD0K09</b>	3 m power cable kit for <b>VEH OEM 60</b>	<b>EVHP523</b>	Humidity probe 4...20 mA
<b>EHKD0K10</b>	3 m power cable kit for <b>VEH OEM 80-100</b>	<b>EVTPNW30F200</b>	NTC temperature probe, IP68
<b>EHKD0K18</b>	5 m power cable kit for <b>VEH OEM 10-20-30-40</b>	<b>EV3411M7</b>	Universal controller, 1 output, 230 Vac
<b>EHKD0K17</b>	5 m power cable kit for <b>VEH OEM 80-100</b>	<b>EHHKT001P4</b>	Complete control unit
<b>EHKD0K19</b>	5 m power cable kit for <b>VEH OEM 60</b>	<b>EHHKX002E4</b>	Expansion board for <b>VEH OEM 60-80-100</b>
<b>EHKD0K28</b>	1 m power cable kit for <b>VEH OEM 10-20-30</b>	<b>0103349007</b>	TA current sensor
<b>EHKD0K29</b>	1 m power cable kit for <b>VEH OEM 40-60-80</b>	<b>0150130001</b>	Fuse holder for <b>VEH OEM 10-20</b>
<b>EHKD0K30</b>	1 m power cable kit for <b>VEH OEM 100</b>	<b>0150130002</b>	Fuse holder for <b>VEH OEM 30-40</b>
<b>EHKD0K22</b>	Hydraulic connections feedthrough kit	<b>0150130003</b>	Fuse holder for <b>VEH OEM 60-80-100</b>
<b>EHKD0K23</b>	Filling/discharge unit kit external to AHU	<b>EHVI</b>	Water drainage tray
<b>0031000048</b>	3/4"G Female water inlet hose	<b>EHKOD0K01</b>	Hydraulic unit casing for VDI6022-1
<b>EHK00K01</b>	DIN rail mount for 1 electronic controller		

### 1.8.1 Hydraulic unit extraction flange



**Fig. 2.** Hydraulic unit extraction flange


Providing a rectangular hole on the AHU panel and applying the **EHKD0K20** KIT gives the AHU a hydraulic unit extraction window.

Fit the hydraulic unit on the corner guides, taking care to secure it with the fastening screws.

Installing the extraction flange means there is no need to turn off the AHU when carrying out maintenance on the **VEH OEM** humidifier. Simply remove the panel (flange), release the hydraulic unit from the fastening screws in the guides, remove it by sliding it out of the corner guides and finally refit the panel (flange) until the maintenance is finished.

### Hole sizes for EHKD0K20 KIT


mm (ft.)



**Fig. 3.** Hole sizes for *EHKD0K20 KIT*

### Fastening corner guide dimensions

mm (in.)



**Fig. 4.** Corner bracket dimensions

50x50 mm (1.97x1.97 in.) corner bracket with a thickness of at least 1.5 mm (0.06 in.) made of AISI 304 stainless steel or engineering polymer based on polypropylene that does not promote bacterial proliferation.

Fit the fastening corner guides inside the condensate (or leak) collection tank so that they form a 2% slope.

## 2. TECHNICAL DATA

### 2.1 Technical specifications

#### 2.1.1 400 Vac models | VEH OEM...

Description	MU	10XS	20••	30M	40•	60••	80L	100XL	120XL	160XL	200XL
<b>Steam production</b>											
Production capacity:	kg/h	10	20	30	40	60	80	100	60x2	80x2	100x2
Pressure limits:	Pa/bar	There are no pressure limits (*)									
<b>Electrical properties</b>											
Power absorbed:	kW	7.5	15	22.5	30	45	60	75	45x2	60x2	75x2
Power supply:	V, Hz	400 Vac, 50/60									
Phases:	Ph	3									
Absorption per phase:	A	11	22	32.5	44	65	87	109	130	174	218
<b>Water properties</b>											
Supply water quality:	---	See section <b>"5.2.1 WATER SPECIFICATIONS" ON PAGE 23</b>									
Supply water conductivity:	μS*cm	70...1250									
Supply water hardness:	°f	5...50									
Minimum inlet flow rate:	l/h	300									
Supply water pressure:	MPa/bar	0.02...1/0.2...10									
Supply water connection:	---	M 3/4" GAS									
Water drain outside diameter:	mm (in.)	40 (1.57)									
<b>General specifications</b>											
Dimensions:	mm (in.)	See section <b>"4.1 DIMENSIONS" ON PAGE 18</b>									
Weight (hydraulic unit):	kg	8.5	11	13	16.5	18	22.5	24	18x2	22.5x2	24x2
IP protection degree of the hydraulic unit:	---	IPX0									
Maximum installation altitude:	m (ft.)	≤2000 (6561.6)									
<b>Ambient conditions of the hydraulic unit</b>											
Ambient operating conditions:	°C (°F), %	1...40 (33.8...104), 10...80%									
Transportation and storage conditions:	°C (°F), %	-10...70 (14...185), 5...95%									
<b>Regulation</b>											
Control type/command signal:	---	ON/OFF Proportional Probe									
Supervision/Configuration:	---	RS-485 MODBUS Supervision Wi-Fi									
<b>Compliance</b>											
EC:	---	Yes, with self-certification									

**NOTE:** The • symbol indicates that the data applies to every p/n; for further information please contact the ELSTEAM sales office.

**NOTE:** Models with dual hydraulic units can be created by adding an expansion to the control board, in which case the aforementioned values become the sum of those for the 2 hydraulic units chosen.

(\*): Steam production occurs inside the AHU and therefore under equivalent pressure conditions.

## 2.1.2 460 Vac models | VEH OEM...

Description	MU	10XS	20••	30M	40•	60••	80L	100XL	120XL	160XL	200XL
<b>Steam production</b>											
Production capacity:	kg/h	10	20	30	40	60	80	100	60x2	80x2	100x2
Pressure limits:	Pa/bar	There are no pressure limits (*)									
<b>Electrical properties</b>											
Power absorbed:	kW	7.5	15	22.5	30	45	60	75	45x2	60x2	75x2
Power supply:	V, Hz	460 Vac, 50/60									
Phases:	Ph	3									
Absorption per phase:	A	11	22	32.5	44	65	87	109	130	174	218
<b>Water properties</b>											
Supply water quality:	---	See section <b>"5.2.1 WATER SPECIFICATIONS" ON PAGE 23</b>									
Supply water conductivity:	μS*cm	70...1250									
Supply water hardness:	°f	5...50									
Minimum inlet flow rate:	l/h	300									
Supply water pressure:	MPa/bar	0.02...1/0.2...10									
Supply water connection:	---	M 3/4" GAS									
Water drain outside diameter:	mm (in.)	40 (1.57)									
<b>General specifications</b>											
Dimensions:	mm (in.)	See section <b>"4.1 DIMENSIONS" ON PAGE 18</b>									
Weight (hydraulic unit):	kg	8.5	11	13	16.5	18	22.5	24	18x2	22.5x2	24x2
IP protection degree of the hydraulic unit:	---	IPX0									
Maximum installation altitude:	m (ft.)	≤2000 (6561.6)									
<b>Ambient conditions of the hydraulic unit</b>											
Ambient operating conditions:	°C (°F), %	1...40 (33.8...104), 10...80%									
Transportation and storage conditions:	°C (°F), %	-10...70 (14...185), 5...95%									
<b>Regulation</b>											
Control type/command signal:	---	ON/OFF Proportional Probe									
Supervision/Configuration:	---	RS-485 MODBUS Supervision Wi-Fi									
<b>Compliance</b>											
EC:	---	Yes, with self-certification									

**NOTE:** The • symbol indicates that the data applies to every p/n; for further information please contact the ELSTEAM sales office.

**NOTE:** Models with dual hydraulic units can be created by adding an expansion to the control board, in which case the aforementioned values become the sum of those for the 2 hydraulic units chosen.

(\*): Steam production occurs inside the AHU and therefore under equivalent pressure conditions.

## 3. RECEIVING THE PRODUCT

### CAUTION

#### IMPROPER HANDLING

- Use all necessary personal protective equipment (PPE), such as safety gloves and shoes, while handling packaging and unpacking.
- Follow the handling instruction given in this manual and any other documentation associated with the product.
- Handle and store the product in its original packaging.
- Do not handle or store the product if the packaging is or seems to be damaged.
- Take all necessary measures to avoid damaging the product and prevent other hazards while handling or opening the packaging.

### NOTICE

#### UNEXPECTED EQUIPMENT OPERATION

- Droppages and shocks can damage the humidifier beyond repair.
- Tampering with or removing the identification stickers invalidates the warranty.

### 3.1 Checking the packaging

- Make sure the packaging is intact;
- Make sure the humidifier is intact upon delivery and inform the courier immediately, in writing, of any problems caused by careless or improper transportation (accept the package conditionally).

#### 3.1.1 Opening the packaging

- Take the packages to the humidifier installation site;
- Open the cardboard boxes, removing the corner protectors;
- Take the electric panel and the hydraulic unit out of their packaging.

#### 3.1.2 Checking the packaging contents

The product package contains:


- **VEH OEM** series humidifier, consisting of:
  - One or two hydraulic units;
  - Wiring kit;
  - Electronic controller on DIN rail mount;
  - TA current sensor.
- Instruction sheet;
- Water inlet connection pipe for use between the main supply and the solenoid valve at the humidifier inlet;
- Water drain unit.

## 4. DIMENSIONS AND MECHANICAL ASSEMBLY

### 4.1 Dimensions

#### 4.1.1 Hydraulic unit

mm (in.)



**Fig. 5.** Hydraulic unit dimensions

Dimension (X) for models [mm (ft.)]	VEH OEM 10XS	VEH OEM 20S	VEH OEM 20XS	VEH OEM 30M	VEH OEM 40L	VEH OEM 40S	VEH OEM 60XL	VEH OEM 60M	VEH OEM 80L	VEH OEM 100XL
<b>4 electrodes</b>	635 (2.08)	785 (2.57)	---	985 (3.23)	1185 (3.89)	---	1385 (4.54)	---	---	---
<b>7 electrodes</b>	---	---	635 (2.08)	---	---	785 (2.57)	---	985 (3.23)	1185 (3.89)	1385 (4.54)

## 4.2 Hydraulic unit installation

### 4.2.1 Installation instructions

- Place the hydraulic unit inside the condensate tank inside the AHU;
- Secure the hydraulic unit with 3 screws inserted into the anchoring hooks (see "**FIG. 6. HYDRAULIC UNIT INSTALLATION**" ON PAGE 19) (not mandatory);
- Connect the inlet solenoid valve to the pipe provided;
- Connect the discharge unit using special water drainage pipes (Ø 40 mm (1.57 in.));
- Restore the connection between the hydraulic unit and the electric panel, keeping the power cables separate from the other service cables.




Fig. 6. Hydraulic unit installation

### 4.2.2 Minimum installation dimensions

mm (in.)






Fig. 7. Minimum installation distances

### 4.2.3 Minimum distances for one hydraulic unit - AHU



**Fig. 8.** Minimum installation distances from the droplet separator

#### 4.2.4 Minimum distances for two hydraulic units - AHU



**Fig. 9.** Minimum installation distances from the droplet separator for two hydraulic units

# 5. INSTALLATION

VEH OEM series humidifiers are defined as "NOT ACCESSIBLE TO THE PUBLIC".

## 5.1 Hydraulic unit structure




Fig. 10. Hydraulic unit overview

Reference	Description	Reference	Description
①	Water drain outlet for connection to waste water drainage pipes (Ø 40 mm (1.57 in.));	④	Water filling solenoid valve
②	Power supply wiring entry	⑤	Electric outlet pump
③	Water filling inlet, 3/4" GAS male	⑥	Steam outlet

### 5.1.1 Rear

- Maximum level sensor connection.

## 5.2 Plumbing installation

For correct hydraulic installation, the following should be provided outside the AHU and in the immediate surroundings of the hydraulic unit installation site:

- A shut-off tap;
- A filter supplementing the one already present inside the solenoid valve;
- A pressure reducer (if the mains pressure exceeds 1 MPa (10 bar)).

If using metal pipes, make sure they are properly earthed.

Do not use pre-existing system pipework or used materials. Only use the materials supplied with the product.

**NOTE:** if using a pressure reducer, make sure it is effective and does not cause drastic pressure drops when the mains pressure is very low.

## NOTICE

### MALFUNCTIONING OF THE EQUIPMENT

- The water supply must have a minimum pressure of 0.02 MPa (0.2 bar).
- Connect the solenoid valve to the mains using the hose supplied in order to reduce water hammer in the water supply to the humidifier.
- During installation, take care not to damage the plastic thread on the solenoid valve.
- The water connection should allow access to the mechanical filter in the inlet solenoid valve in order to clean it.
- Connect the drainage circuit using exclusively the D40 mm (1.57 in.) pipes provided.
- If the AHU is exposed to atmospheric agents, fit heating cables to the water supply and discharge pipes.

### 5.2.1 Water specifications

- Water pressure between 0.02...1 MPa (0.2...10 bar) inclusive;
- Temperature between 1...50 °C (33.8...122 °F) inclusive;
- Conductivity between 75...1250 µS/cm inclusive;
- Maximum water hardness between 5...50 °f.

**NOTE:** higher water hardness or a higher level of organic matter does not preclude proper equipment operation, nevertheless these factors mean that more frequent maintenance will be required.

#### What should you do?

- Open the water supply and let the water flow into the drain for a few hours before making the final connection in order to clean any processing debris out of the hydraulic system.
- Check the retention status of the hydraulic circuit regularly to prevent faults and consequent water leakage into the room.
- Make sure the hydraulic unit is always installed within a condensate collection tank with drainage.

#### What should you **NOT** do?

- Soften the water. If the water hardness is over 50 °f or if the hardness level requires frequent maintenance, use demineralised water mixed with drinking water in a percentage that ensures minimum conductivity of 200 µS/cm and hardness of at least 10 °f;

## NOTICE

### MALFUNCTIONING OF THE EQUIPMENT

- Do not use softened water.
- Once the humidifier has been installed, let the remaining water in the pipes flow out to prevent the filter from becoming clogged.
- Make sure the humidifier parts are perfectly intact.
- If any of the humidifier parts are not intact, do not proceed with installation.

## 5.3 Water drainage system

The drainage system must be able to drain a water flow of at least 60 l/minute.

## NOTICE

### MALFUNCTIONING OF THE EQUIPMENT

Size the drain pipe correctly in order to prevent blockages and clogging during automatic cleaning.

**NOTE:** the drain pipes are not supplied (except for the initial ø40 section, see "**FIG. 7. MINIMUM INSTALLATION DISTANCES**" ON PAGE 19).

**NOTE:** a fixed drain connection must be used.

### 5.3.1 Connection specifications

- Minimum diameter 40 mm (1.57 in.);
- Maximum bend radius 300 mm (0.98 ft.);
- Minimum average incline of 45° and without traps (outside the AHU, inside refer to the accessories kits).

If the installation does not comply with these specifications, install a water and limescale collection tank at the drain outlet point outside the AHU (p/n **EHVI**) (contact the Elsteam sales office for further information).


#### Discharge tank features

- Discharge (drainage) tank with trap for limescale collection.

## NOTICE

### MALFUNCTIONING OF THE EQUIPMENT

If the water hardness is over 40 °f, carry out maintenance/manual cleaning of the tank at least twice a year.



**Fig. 11.** Drainage tank features

If the water hardness reflects the optimal specifications indicated in sub-section "5.2.1 WATER SPECIFICATIONS" ON PAGE 23, the tank will only need cleaning once a year.

If the drainage network or drainage tank is made of electrically conductive material, safety standards require it to be electrically earthed.

**⚡ ⚠ DANGER**

**RISK OF ELECTRIC SHOCK**

If the drainage tank is made of electrically conductive material, earth the tank or the drainage network.

Drained water may reach a temperature of 98 °C (208.4 °F) or higher.

**⚠ ⚠ WARNING**

**RISK OF BURNS**

- Before starting to drain the water, wear all necessary personal protective equipment (PPE).
- Do not touch the equipment when draining the water.

**5.4 Steam distribution in the AHU**

**⚠ ⚠ WARNING**

**RISK OF BURNS**

- The hydraulic unit must be installed so that it cannot be accessed by unauthorised persons.
- Only qualified personnel may access the inside of the air handling unit (where the hydraulic unit is installed) using a tool (e.g. a spanner).

**⚠ ⚠ WARNING**

**HOT WATER VAPOUR**

Do not touch the equipment while it is running.

**⚠ WARNING**

**MALFUNCTIONING OF THE EQUIPMENT**

- Install the equipment in a position which ensures the minimum distances from all adjacent structures and equipment as indicated in this document.
- Install all equipment in compliance with the technical specifications indicated in the relevant documentation.

**Fig. 12.** Positioning the hydraulic unit in the AHU

**NOTE:** in ambient temperature conditions which may lead to the formation of ice, it is wise to take all necessary precautions to prevent the supply water and the drain water from freezing and causing the humidifier to malfunction.

# 6. ELECTRICAL CONNECTIONS

## 6.1 Before you start

Read this manual carefully before installing the equipment.

In particular, the safety instructions, electrical requirements and current regulations for the machine or the process in which this device is involved must be observed.

The use and application of the information contained herein requires experience in the design and installation of humidification systems. Only the user, integrator or manufacturer of the machine can be familiar with all the conditions and factors which arise during installation and configuration, operation and maintenance of the machine or the process, and as such can identify the relevant automation equipment and the corresponding interlocks and safety systems which can be used effectively and appropriately. When selecting automation and control equipment and other connected equipment and software, for a particular application, you must consider all applicable local, regional and national standards and/or regulations.

### **DANGER**

#### **RISK OF ELECTRIC SHOCK, EXPLOSION OR ELECTRIC ARC**

- Only use electrically insulated measuring devices and equipment.
- Do not install the equipment while the power supply is connected.
- Cut off the power supply to all equipment, including any connected devices, before removing any covers or hatches, or before installing/uninstalling accessories, hardware, cables or wires.
- Provide safety interlocks (isolators) of a suitable size between the power supply and the humidifier, with a contact opening distance of at least 3 mm for each pole.
- Always use a properly calibrated Voltmeter to make sure the system is powered off.
- The maintenance, repair, installation and use of the equipment must only be entrusted to qualified personnel.
- Do not touch the unshielded components or the terminals while they are live.
- Do not open, disassemble, repair or modify the product.
- Do not expose the equipment to liquids or chemicals.
- Make sure there is an effective earth connection.
- Before applying voltage to the equipment:
  - Make sure all protective elements, such as covers, hatches and grilles, are fitted and/or closed using a tool (e.g. a spanner).
- Check all wiring connections.

### **WARNING**

#### **REGULATORY INCOMPATIBILITY**

Make sure all the equipment used and systems designed conform to current local, regional and national standards.

## 6.2 Connection best practice

### 6.2.1 Wiring best practices

### **DANGER**

#### **RISK OF ELECTRIC SHOCK AND FIRE**

- Do not use the device with loads greater than those indicated in the technical data section.
- Do not exceed the temperature and humidity ranges indicated in the technical data section.
- Provide safety interlocks (isolators) of a suitable size between the power supply and the humidifier.
- Only use cables with a suitable cross-section as indicated in the section "Wiring best practices".

When wiring the humidifiers, observe the following instructions:

- Make sure the operating environment and conditions fall within the specified values.
- Use cables with the correct diameter, suited to the voltage and current requirements.
- Use double-insulated cables suitable for outdoor use (minimum requirement: H05RN-F) which also include an earth wire.

### **DANGER**

#### **LOOSE WIRING CAUSES ELECTRIC SHOCKS AND OVERHEATING**

Tighten the connections in compliance with the technical specifications relating to tightening torques.

### **WARNING**

#### **MALFUNCTIONING OF THE EQUIPMENT**

- Perform the wiring carefully, in compliance with electromagnetic compatibility and safety requirements.
- Carry out a full start-up test.
- Make sure the wiring is correct for the end application.
- Minimise the length of the connections as much as possible, to avoid winding the cables around electrically connected parts.
- Before applying the power supply, check all the wiring connections.
- Do not connect cables to unused terminals and/or terminals marked with the text "No connection" (N.C.).

**⚠ WARNING**

**REGULATORY INCOMPATIBILITY**

Make sure all the equipment used and systems designed conform to current local, regional and national standards.

**Suitable wiring for the power supply**

Step 17,8 mm (0.70 in.)

$\frac{\text{mm}}{\text{in.}}$ $\frac{7}{0.28}$ 				 	$\text{N}\cdot\text{m}$ 2,5 $\text{lb}\cdot\text{in}$ 22.12
	$\text{mm}^2$ 4 AWG 10 no. of conductors 3+G	4 10 3+G	4 10 3+G		

**Fig. 13.** Suitable wiring for the power supply - **VEH OEM 10**

Step 17,8 mm (0.70 in.)

$\frac{\text{mm}}{\text{in.}}$ $\frac{7}{0.28}$ 				 	$\text{N}\cdot\text{m}$ 2,5 $\text{lb}\cdot\text{in}$ 22.12
	$\text{mm}^2$ 6 AWG 8 no. of conductors 3+G	6 8 3+G	6 8 3+G		


**Fig. 14.** Suitable wiring for the power supply - **VEH OEM 20**

Step 26,5 mm (1.04 in.)

$\frac{\text{mm}}{\text{in.}}$ $\frac{7}{0.28}$ 				 	$\text{N}\cdot\text{m}$ 3 $\text{lb}\cdot\text{in}$ 26.55
	$\text{mm}^2$ 10 AWG 7 no. of conductors 3+G	10 7 3+G	10 7 3+G		

**Fig. 15.** Suitable wiring for the power supply - **VEH OEM 30**

Step 26,5 mm (1.04 in.)

$\frac{\text{mm}}{\text{in.}}$ $\frac{7}{0.28}$ 				 	$\text{N}\cdot\text{m}$ 3 $\text{lb}\cdot\text{in}$ 26.55
	$\text{mm}^2$ 16 AWG 5 no. of conductors 3+G	16 5 3+G	16 5 3+G		

**Fig. 16.** Suitable wiring for the power supply - **VEH OEM 40**

Step 35,5 mm (1.40 in.)

$\frac{\text{mm}}{\text{in.}}$ $\frac{7}{0.28}$ 				 	$\text{N}\cdot\text{m}$ 4 $\text{lb}\cdot\text{in}$ 35.40
	$\text{mm}^2$ 16 AWG 5 no. of conductors 3+G	16 5 3+G	16 5 3+G		

**Fig. 17.** Suitable wiring for the power supply - **VEH OEM 60**

Step 35,5 mm (1.40 in.)

$\frac{\text{mm}}{\text{in.}}$ $\frac{7}{0.28}$ 				 	$\text{N}\cdot\text{m}$ 4 $\text{lb}\cdot\text{in}$ 35.40
	$\text{mm}^2$ 25 AWG 7 no. of conductors 3+G	25 7 3+G	25 7 3+G		

**Fig. 18.** Suitable wiring for the power supply - **VEH OEM 80**

Step 35,5 mm (1.40 in.)

$\frac{\text{mm}}{\text{in.}}$ $\frac{7}{0.28}$ 				 	$\text{N}\cdot\text{m}$ 4 $\text{lb}\cdot\text{in}$ 35.40
	$\text{mm}^2$ 25 AWG 3 no. of conductors 3+G	25 3 3+G	25 3 3+G		

**Fig. 19.** Suitable wiring for the power supply - **VEH OEM 100**



**RISK OF ELECTRIC SHOCK**

- Cut off the power supply to all equipment, including any connected devices, before removing any covers or hatches, or before installing/uninstalling accessories, hardware, fuses, cables or wires.
- Always use a properly calibrated Voltmeter to make sure the system is powered off.

	VEH10	VEH20	VEH30	VEH40	VEH60	VEH80	VEH100
Current (A)	16	32	50	50	80	100	125
Type	Rapid						
Size	10x38	10x38	14x51	14x51	22x58	22x58	22x58

Fig. 20. Overload protection devices according to model

**6.3 Dimensioning electrical components**

P/n	Nominal current	Cable section (L maximum 15 m)	Recommended LOVATO/ITALWEBER fuse holder	Recommended LOVATO contactor	Electric panel and tank wiring 3 m/5 m H07RNF NEOPRENE
EHKOD010T•XS	11	3G4	FB01B	11BG0910 A024 (20A)	3 x 6 mm <sup>2</sup>
EHKOD020T•XS	22	3G10	FB01B	BF2600 A024 (45A)	3 x 6 mm <sup>2</sup>
EHKOD020T•S	22	3G10	FB01B	BF2600 A024 (45A)	3 x 6 mm <sup>2</sup>
EHKOD030T•M	32.5	3G16	FB02A	BF3800 A024 (56-60A)	3 x 6 mm <sup>2</sup>
EHKOD030T•S	32.5	3G16	FB02A	BF3800 A024 (56-60A)	3 x 6 mm <sup>2</sup>
EHKOD040T•M	44	3G16	FB02A	BF4000 A024 (70A)	3 x 16 mm <sup>2</sup>
EHKOD040T•L	44	3G16	FB02A	BF4000 A024 (70A)	3 x 16 mm <sup>2</sup>
EHKOD060T•M	65.0	3G25	ITW2303058	BF5000 A024 (90A)	3 x 16 mm <sup>2</sup>
EHKOD060T•XL	65.0	3G25	ITW2303058	BF5000 A024 (90A)	3 x 16 mm <sup>2</sup>
EHKOD0080T•L	87	3G35	ITW2303058	BF6500 A024 (100A)	3 x 25 mm <sup>2</sup>
EHKOD100T•XL	109	3G35	ITW2303058	11BF9500 A024 (125A)	3 x 25 mm <sup>2</sup>

## 6.4 Electrical connections

### 6.4.1 Control board




Fig. 21. Control board electrical connections

TERMINALS	
1-2	24 Vac power supply
2-3	Digital output: water outlet solenoid valve
2-4	Digital output: water outlet pump
2-5	Digital output: contactor (steam generation)
6-7	Digital output: dehumidification enable
8-9	Digital output: ventilated distributor control
10...12	Digital output: alarm
13-14	Hazardous voltage digital input: level sensor LS1
20-21	Digital input: enable from ventilation (CV)
22-23	Digital input: remote ON/OFF (0/1)
24-25	Digital input: humidistat (CFG = 0-1) (S0)
26-27	S1 analogue input: temperature (anti-freezing and hold)
28...30	S2 analogue input: humidity sensor (or 0...10 V signal)
31...33	S3 analogue input: humidity limit sensor
34...37	Serial line connection: HMI Intrabus
38...40	Serial line connection: RS-485 modbus for BMS slave
45-46	Analogue connection: external current sensor CT1 (TA)
47...52	Reserved
TERM3	Activate termination resistor on the SCI1 RS-485 serial line. ON = Termination resistor enabled; OFF = Disabled.
TERM1	Termination resistor on BMS RS-485 serial line. ON = Termination resistor enabled; OFF = Disabled.
TERM2	Termination resistor on CANBUS serial line. ON = Termination resistor enabled; OFF = Disabled.

## 6.4.2 Expansion





Fig. 22. Expansion electrical connections

TERMINALS			
1-55	24 Vac connection for relay	82...85	Connection to expansion board <b>SCI1</b>
2-56	Digital output: boiler 2 water outlet solenoid valve	DP1	Modbus communication address of expansion board
2-57	Digital output: boiler 2 water outlet pump		<b>ADDR1</b> <b>ADDR2</b> Address offset relative to <b>LA1</b>
2-58	Digital output: electrodes (steam generation)		OFF OFF LA1 + 0
63-64	Hazardous voltage digital input: level sensor <b>LS2</b>		OFF ON LA1 + 1
70...73	Connection to control board <b>SCI1</b>		ON OFF LA1 + 2
74...77	Serial line input: <b>HMI</b> Intrabus	ON ON LA1 + 3	
78-79	Analogue input: external current sensor <b>CT2</b> (TA) for boiler 2	<b>TERM3</b>	Activate termination resistor on SCI1 RS-485 serial line. <b>ON</b> = Termination resistor enabled; <b>OFF</b> = Disabled.
80-81	Reserved		

## 6.5 Configurations

### 6.5.1 ON/OFF connection with humidistat or external contact (CFG = 0-1)

Configuration
CFG = 0-1
CV input = Closed
0/1 input = Closed




**Fig. 23.** ON/OFF connection with humidistat or external contact (CFG = 0-1)

**NOTE:** To start humidity production, the **CV** and **0/1** contacts must be closed.

### 6.5.2 External proportional humidistat connection (CFG = PROP)

Configuration
CFG = PROP
P2 = 0-10
P2 = 0-5
P2 = 0.20
P2 = 4.20
CV input = Closed
0/1 input = Closed




**Fig. 24.** External proportional humidistat connection (CFG = PROP)

**NOTE:** To start humidity production, the **CV** and **0/1** contacts must be closed.

### 6.5.3 Humidity sensor connection (CFG = HUM)

Configuration
CFG = HUM
P2 = 0-10
P2 = 0-5
P2 = 0.20
P2 = 4.20
CV input = Closed
0/1 input = Closed



**Fig. 25.** Humidity sensor connection (CFG = HUM)

**NOTE:** To start humidity production, the **CV** and **0/1** contacts must be closed.

### 6.5.4 Humidity sensor connection EVHTP520 (CFG = HUM)




Fig. 26. Humidity sensor connection EVHTP520 (CFG = HUM)

**NOTE:** To start humidity production, the **CV** and **0/1** contacts must be closed.

### 6.5.5 Connection for humidity sensor and limit sensor (CFG = HUML)




Fig. 27. Connection for humidity sensor and limit sensor (CFG = HUML)

**NOTE:** To start humidity production, the **CV** and **0/1** contacts must be closed.

### 6.5.6 Temperature sensor connection (CFG = 1T)





Fig. 28. Temperature sensor connection (CFG = 1T)

**NOTE:** To start humidity production, the **CV** and **0/1** contacts must be closed.

### 6.5.7 Connection for two temperature sensors (CFG = 2T)

Configuration
<b>CFG = 2T</b>
<b>P2 = PTC</b> <b>P2 = 1000</b> <b>P2 = NTC</b>
<b>P7 = PTC</b> <b>P7 = 1000</b> <b>P7 = NTC</b>
<b>CV input = Closed</b>
<b>0/1 input = Closed</b>



**Fig. 29.** Temperature sensor connection (CFG = 2T)


**NOTE:** To start humidity production, the **CV** and **0/1** contacts must be closed.

### 6.5.8 Humidity sensor connection 0...5 V / 0...10 V

Configuration
<b>CFG = HUM</b> <b>CFG = HUML</b>
<b>P2 = 0-5</b> <b>P2 = 0-10</b>
<b>P7 = 0-5</b> <b>P7 = 0-10</b>
<b>CV input = Closed</b>
<b>0/1 input = Closed</b>

**S2 input**  
28 = GND  
29 = V+  
30 = Sensor power supply

**S3 input**  
31 = GND  
32 = V+  
33 = Sensor power supply



**Fig. 30.** Humidity sensor connection 0...5 V

**NOTE:** To start humidity production, the **CV** and **0/1** contacts must be closed.

## 6.6 Power supply and earth wiring connection

**⚠ ⚠ DANGER**

### RISK OF ELECTRIC SHOCK

Make sure that the entire system is earthed to the highest standards.

## 6.7 DIP switch functions

The control board and the expansion board have dip switches to configure the termination resistors and the Modbus address of the expansion board.

### 6.7.1 DIP switch | Control board

DIP	Description	Description
<b>TERM3</b>	Activate termination resistor on the <b>SCI1 RS-485</b> serial line. <b>ON</b> = Termination resistor enabled; <b>off</b> = Disabled.	Set to <b>ON</b> if connected to the expansion, but only if it is the first or last element wired in the network.
<b>TERM1</b>	Termination resistor on <b>BMS RS-485</b> serial line. <b>ON</b> = Termination resistor enabled; <b>off</b> = Disabled.	Set to <b>ON</b> if connected to the MODBUS network, but only if it is the first or last element wired in the network.
<b>TERM2</b>	Termination resistor on <b>CANBUS</b> serial line. <b>ON</b> = Termination resistor enabled; <b>off</b> = Disabled.	Set to <b>ON</b> only if it is the first or last element wired in the network. It must be <b>ON</b> if wired to an EPJ terminal.

### 6.7.2 DIP switch | Expansion

DIP	Description	Description	
<b>DP1</b>	Modbus communication address of expansion board		
	<b>ADDR1</b>	<b>ADDR2</b>	Expansion board address
	OFF	OFF	2
	OFF	ON	3
	ON	OFF	4
	ON	ON	5
<b>TERM1</b>	Activate termination resistor on SCI1 RS-485 serial line. <b>ON</b> = Termination resistor enabled; <b>off</b> = Disabled.	Set to <b>ON</b> if connected to the expansion, but only if it is the first or last element wired in the network.	

## 7. USER INTERFACE (OPTIONAL)

Make sure the humidifier and all the installed components are properly connected before start-up, in accordance with regulations, criteria and all applicable local, regional and national standards.

### 7.1 User interface



Fig. 31. VEH humidifier user interface

#### 7.1.1 Icons

Icon	Lit steadily	OFF	Icon	Lit steadily	OFF
1	<ul style="list-style-type: none"> <li>Main sensor configured and present</li> <li>CFG = 1T (one temperature probe)</li> </ul>	In all other cases	⚠	Warning in progress	No warning in progress
2	<ul style="list-style-type: none"> <li>Limit sensor configured and present</li> <li>CFG = 2T (two temperature probes)</li> </ul>	In all other cases	🔗	CV input closed (enable signal given)	CV input open (enable signal not given)
🌀	Steam request	In all other cases	SP	Changing humidity setpoint in progress	In all other cases
📈	Proportional operating mode	In all other cases	⚠	Alarm in progress	No alarm in progress
📉	ON/OFF operating mode	In all other cases	⚡	Contactor ON	Contactor OFF
🔌	Humidifier OFF	Humidifier ON	🌀	Washing or draining in progress	In all other cases
V	Voltage sensor operating mode	In all other cases	🕒	Displayed value is operating hours	In all other cases
I	Current sensor operating mode	In all other cases	F	Display shows temperature in °F	In all other cases
R	Resistive sensor operating mode	In all other cases	%	Display shows humidity in %	In all other cases
A	Display shows the current absorbed by the electrodes	In all other cases	°C	Display shows temperature in °C	In all other cases
μS	Changing value of P1 in progress	In all other cases			

#### 7.1.2 Keys

Key...	Tap and release to...	Tap and hold for at least 3 seconds to...
🔌	Go back a level	Humidifier ON/OFF
FNC ✓	<ul style="list-style-type: none"> <li>Scroll down through the values</li> <li>Navigate within the menu</li> </ul>	Go to the maintenance and reset operating hours menu
^	<ul style="list-style-type: none"> <li>Scroll up through the values</li> <li>Navigate within the menu</li> </ul>	Activate manual draining
🔒 SET	<ul style="list-style-type: none"> <li>Confirm the values on the display</li> <li>Set/change the humidity setpoint</li> </ul>	Enter the main menu

### 7.1.3 First start-up

Make sure the humidifier and all the installed components are properly connected before start-up, in accordance with regulations, criteria and all applicable local, regional and national standards.

At the first start-up, you must enter the electrical conductivity of the inlet water, after which the humidifier OFF screen will open automatically.

**NOTE:** If you do not have the electrical conductivity value of the water, it can be obtained from the website of the drinking water supplier.



Fig. 32. First start-up - Setting the electrical conductivity




Fig. 33. Humidifier OFF

## 7.2 User interface menu

### 7.2.1 Home screen

HOME screen with ON/OFF regulation from digital input (CFG = 0-1)



Fig. 34. Home screen with ON/OFF regulation from digital input (CFG = 0-1)

**Top line:** Shows the state of the digital control input (S0).

**NOTE:** The CV and 0/1 contacts must be closed to produce humidity.

HOME screen with proportional regulation (CFG = PROP)




Fig. 35. Home screen with proportional regulation (CFG = PROP)

**Top line:** Actual humidity request in %.

**Bottom line:** Humidity request.

**NOTE:** The CV and 0/1 contacts must be closed to produce humidity.

HOME screen with regulation via humidity sensor (CFG = HUM) or humidity sensor and limit sensor (CFG = HUML)



Fig. 36. Home screen with humidity sensor alone



Fig. 37. Home screen with humidity sensor and limit sensor

**Top line:** Humidity measured by the room humidity sensor.

**Bottom line:** Humidity setpoint.

**NOTE:** The CV and O/1 contacts must be closed to produce humidity.

### 7.2.2 Changing the main sensor humidity setpoint

With CFG = HUM or CFG = HUML only.

To change the humidity setpoint:




Fig. 38. Changing the humidity setpoint

### 7.2.3 Changing the temperature setpoint

With CFG = 1T or CFG = 2T only.

To change the temperature setpoint:




Fig. 39. Changing the temperature setpoint

### 7.2.4 Manual draining

To start manual draining:




Fig. 40. Manual draining

## 7.2.5 Menu




Fig. 41. Menu

Menu	Description
<i>USER</i>	Access the user menu
<i>MA in</i>	Access the maintenance technician menu
<i>MA nF</i>	<b>RESERVED. NOT ACCESSIBLE TO THE PUBLIC.</b>
<i>AL n</i>	Currently accessing alarm control
<i>H iSt</i>	Access the alarm log
<i>SEtt</i>	Reset parameters to factory settings

### 7.2.6 User Menu

The user menu can be used to display and change user parameters.

To access the user menu:




Fig. 42. User menu

Top line	Bottom line	Description
<b>LANG</b>	Set language	Sets the display language. <b>EnG</b> = English; <b>Ita</b> = Italian.
<b>SP1</b>	Humidity setpoint	Sets the humidity setpoint. See "9.10 TABLE OF ADJUSTMENT PARAMETERS" ON PAGE 50
<b>SP2</b>	Humidity limit setpoint	Sets the humidity limit setpoint`. See "9.10 TABLE OF ADJUSTMENT PARAMETERS" ON PAGE 50
<b>SP3</b>	Temperature setpoint	Sets the temperature setpoint (wellness application). See "9.10 TABLE OF ADJUSTMENT PARAMETERS" ON PAGE 50

### 7.2.7 Maintenance menu

To access the maintenance menu:




Fig. 43. Maintenance menu

The following is a table with the labels shown on the display and their description:

Top line	Bottom line	Description
<b>SP1</b>	Setpoint <b>SP1</b> value	Displays the value of setpoint <b>SP1</b> .
<b>SP2</b>	Setpoint <b>SP2</b> value	Displays the value of setpoint <b>SP2</b> .
<b>SP3</b>	Setpoint <b>SP3</b> value	Displays the value of setpoint <b>SP3</b> .
<b>CFG</b>	Set operating mode	Sets the operating mode See " <b>9.10 TABLE OF ADJUSTMENT PARAMETERS</b> " ON PAGE 50
<b>c0...c11</b>	Parameter value	See " <b>9.10 TABLE OF ADJUSTMENT PARAMETERS</b> " ON PAGE 50
<b>S1</b>	Sensor S1 value	Displays the value read by sensor S1 if it is connected.
<b>S2</b>	Sensor S2 value	Displays the value read by sensor S2 if it is connected.
<b>S3</b>	Sensor S3 value	Displays the value read by sensor S3 if it is connected.
<b>tA</b>	Sensor tA value	Displays the value read by sensor CT1 if it is connected.
<b>CU</b>	<b>CV</b> input status.	Displays the status of the <b>CV</b> digital input (fan enable) if it is connected. <b>OFF</b> = <b>CV</b> input closed; <b>On</b> = <b>CV</b> input open.
<b>OI</b>	<b>0/1</b> input status	Displays the status of the <b>0/1</b> digital input (remote ON/OFF) if it is connected. <b>OFF</b> = <b>0/1</b> input closed; <b>On</b> = <b>0/1</b> input open.
<b>SO</b>	<b>S0</b> input status	Displays the status of the <b>S0</b> digital input (remote humidistat enable) if it is connected. <b>OFF</b> = <b>S0</b> input closed; <b>On</b> = <b>S0</b> input open.
<b>LS</b>	<b>LS1</b> input status	Displays the status of the <b>LS1</b> digital input (level sensor) if it is connected. <b>OFF</b> = <b>LS1</b> input closed; <b>On</b> = <b>LS1</b> input open.
<b>oEU</b>	Inlet solenoid valve output status	Displays the status of the inlet solenoid valve. <b>OFF</b> = Inlet solenoid valve output OFF; <b>ON</b> = Inlet solenoid valve output ON.
<b>oP</b>	Outlet pump status	Displays the status of the outlet pump. <b>OFF</b> = Outlet pump output OFF; <b>ON</b> = Outlet pump output ON.

Top line	Bottom line	Description
<b>oS</b>	Steam generation contactor status	Displays the status of the steam generator contactor. <b>OFF</b> = Steam generator electrode output OFF; <b>ON</b> = Steam generator electrode output ON.
<b>od</b>	Dehumidification enable output status	Displays the status of the dehumidification enable output. <b>OFF</b> = Dehumidification enable output OFF; <b>ON</b> = Dehumidification enable output ON.
<b>oF</b>	Fan output status	Displays the status of the fan digital output. <b>OFF</b> = Fan output OFF; <b>ON</b> = Fan output ON.
<b>oAL</b>	General alarm output status	Displays the status of the general alarm output. <b>OFF</b> = General alarm output OFF; <b>ON</b> = General alarm ON.
<b>HrS</b>	Operating hours management page	Enters the page that displays the operating hours of the humidifier and its parts. To access the page: Double tap the <b>SET</b> key, enter password <b>PA2</b> using the <b>FNC</b> $\checkmark$ or $\wedge$ keys, and tap <b>SET</b> to confirm.
<b>MAnu</b>	Output forcing page	Enters the output forcing page. To access the page: Double tap the <b>SET</b> key, enter password <b>PA2</b> using the <b>FNC</b> $\checkmark$ or $\wedge$ keys, and tap <b>SET</b> to confirm.

### 7.2.8 Displaying/resetting the operating hours

The operating hours can be displayed and reset from the maintenance menu.




Fig. 44. Displaying the operating hours

The following is a table with the labels shown on the display and their description:

Top line	Bottom line	Description
<b>SH</b>	Humidifier hours	Displays the hours of humidifier operation.
<b>PbH</b>	Partial H.U. hours	Displays the partial hours of hydraulic unit operation.
<b>tbH</b>	Total H.U. hours	Displays the total hours of hydraulic unit operation.
<b>EUH</b>	Inlet SV hours	Displays the hours of outlet solenoid valve operation.
<b>PH</b>	Outlet pump hours	Displays the hours of outlet pump operation.
<b>FH</b>	Fan hours	Displays the operating hours of the fans.

#### Reset operating hours

The operating hours can be reset by setting the parameters to 0.

### 7.2.9 Output functional test

The output functional test page can be accessed from the maintenance menu. Here the outputs can be forced on or off:




Fig. 45. Output functional test

The table below contains the labels shown on the display and their descriptions:

Top line	Bottom line	Description
<b>SEU</b>	Inlet SV output status	Forces the inlet solenoid valve output on/off. <b>OFF</b> = Inlet solenoid valve output forced OFF; <b>ON</b> = Inlet solenoid valve output forced ON.
<b>SP</b>	Outlet pump output status	Forces the outlet pump output on/off. <b>OFF</b> = Outlet pump output forced OFF; <b>ON</b> = Outlet pump output forced ON.
<b>SS</b>	Steam generation contactor status	Forces the steam generation contactor on/off. <b>OFF</b> = Steam generator electrode output forced OFF; <b>ON</b> = Steam generator electrode output forced ON.
<b>Sd</b>	Dehumidification enable output status	Forces the dehumidifier enable output on/off. <b>OFF</b> = Dehumidification enable output forced OFF; <b>ON</b> = Dehumidification enable output forced ON.
<b>SF</b>	Fan output status	Forces the fan output on/off. <b>OFF</b> = Fan output forced OFF; <b>ON</b> = Fan output forced ON.
<b>SAL</b>	General alarm output status	Forces the general alarm output on/off. <b>OFF</b> = General alarm output forced OFF; <b>ON</b> = General alarm output forced ON.

## 8. POWER-UP AND START-UP

### 8.1 First start-up instructions

#### **DANGER**

##### **RISK OF ELECTRIC SHOCK, EXPLOSION OR ELECTRIC ARC**

- Do not install the equipment while the power supply is connected.
- Cut off the power supply to all equipment, including any connected devices, and remove the power fuses before removing any covers or hatches, or before installing/uninstalling accessories, hardware, cables or wires.
- Always use a properly calibrated Voltmeter to make sure the system is powered off.
- Do not touch the unshielded components or the terminals while they are live.
- Make sure there is an effective earth connection; if there is not, earth the equipment.
- Before applying voltage to the equipment:
  - Make sure all protective elements, such as covers, hatches and grilles, are fitted and/or closed.
  - Check all wiring connections.

#### **NOTICE**

##### **MALFUNCTIONING OF THE EQUIPMENT**

- Make sure the water mains is correctly connected.
- Make sure there are no traps in the drainage duct.
- Make sure the steam outlet closure clamps are properly tightened.
- Make sure there are no pockets of condensate or throttling in the steam delivery channel.

Make sure the humidifier and all the installed components are properly connected before start-up, in accordance with regulations, criteria and all applicable local, regional and national standards.

At the first start-up, the machine is disabled until the inlet water conductivity has been entered, after which the humidifier OFF screen will open automatically.

To start the humidifier (with humidistat connected or sensor connected if in proportional mode):

- Check the filling and drain network (see sections: "**5.2 PLUMBING INSTALLATION**" ON PAGE 22, "**5.3 WATER DRAINAGE SYSTEM**" ON PAGE 23 and "**5.4 STEAM DISTRIBUTION IN THE AHU**" ON PAGE 24);
- Let the water flow through the drain for a few hours before making the final connection;
- Fit the power fuses;
- Connect the humidistat or the probe in accordance with the required operation (**SEE "6.4 ELECTRICAL CONNECTIONS" ON PAGE 28**);
- Check that the **CV** and **0/1** contacts are closed, see "**6.4 ELECTRICAL CONNECTIONS**" ON PAGE 28;
- Close the electric panel door;
- Activate the isolator installed outside the humidifier and open the water supply source;
- Press the ON/OFF key on the electric panel door to start the humidifier;
- Set the electrical conductivity of the incoming water (if you do not have the electrical conductivity value of the water, it can be obtained from the website of the drinking water supplier);
- Set the humidity setpoint **SP** to 100%;
- The humidifier starts a boiler loading cycle;
- Set the humidity setpoint **SP** to the value required for the application;
- The humidifier drains the water and replenishes it cyclically to perform the dilution procedure in order to keep the humidifier in a good operating condition. The humidifier cyclically carries out a full wash and then restarts with a lower frequency. Operation has been developed to ensure maximum energy efficiency and optimal water use.

### 8.2 Instructions for seasonal or long-term shut-down

If you need to switch off the humidifier for long periods of time, you must:

- Manually drain the product using the manual drainage launch procedure;
- When draining is complete, deactivate the isolator installed outside the humidifier and open the water supply source;
- Open the manual drain plug to complete draining the manifold and pump.

#### **WARNING**

##### **BIOLOGICAL RISK**

- In the event of poor maintenance/cleaning after the humidifier has been shut-down for a long time, microorganisms (including the bacteria that cause Legionellosis) may proliferate and be transferred into the air treatment system.
- The humidifier must be used properly and be maintained and cleaned properly at prescribed intervals, as described in the **MAINTENANCE** chapter.

### 8.3 Starting up after a seasonal or long-term shut-down

- It is advisable to clean the boiler before a seasonal start-up;
- Check the steam inlet and outlet lines (see sections: "**5.2 PLUMBING INSTALLATION**" ON PAGE 22, "**5.3 WATER DRAINAGE SYSTEM**" ON PAGE 23 and "**5.4 STEAM DISTRIBUTION IN THE AHU**" ON PAGE 24);
- Let the water flow through the drain for a few hours before making the final connection;
- Check the power fuses;
- Check the humidistat or sensor connections, depending on the required operation (**SEE "6.4 ELECTRICAL CONNECTIONS" ON PAGE 28**);
- Check that the **CV** and **0/1** contacts are closed, see "**6.4 ELECTRICAL CONNECTIONS**" ON PAGE 28;
- Close the electric panel door;
- Activate the isolator installed outside the humidifier and open the water supply source;
- Press the ON/OFF key on the electric panel door to start the humidifier;
- Set the electrical conductivity of the incoming water (if you do not have the electrical conductivity value of the water, it can be obtained from the website of the drinking water supplier);
- Set the humidity setpoint **SP** to 100%;
- The humidifier starts a boiler loading cycle;
- Set the humidity setpoint **SP** to the value required for the application;
- The humidifier drains the water and replenishes it cyclically to perform the dilution procedure in order to keep the humidifier in a good operating condition. The humidifier cyclically carries out a full wash and then restarts with a lower frequency. Operation has been developed to ensure maximum energy efficiency and optimal water use.

# 9. OPERATION

## 9.1 Principle of operation

The **VEH OEM** series is the ELSTEAM immersed electrode humidifier solution dedicated to installations within air handling units (AHUs).

**VEH OEM** series humidifiers generate humidity (steam) by means of a current passing between 4 or 7 electrodes immersed in drinking water to bring it to boiling point.

The steam is controlled by adjusting the current strength transferred to the water via the immersed electrodes. When there is a humidity request, the inlet solenoid valve lets water into the hydraulic unit until the required production is reached, at which point the solenoid valve is closed.

When the steam production is below the required level, the inlet solenoid valve is activated again until the optimal working condition is reached.

## 9.2 Humidity regulation

The humidity can be regulated in 6 ways, depending on how the **CFG** parameter is set:

- ON-OFF regulation (**CFG** = 0-1);
- Proportional regulation (**CFG** = PROP);
- Regulation with the humidity sensor (**CFG** = HUM);
- Regulation with the humidity sensor and limit sensor (**CFG** = HUML);
- Regulation with a temperature probe (wellness applications) (**CFG** = 1T);
- Regulation with two temperature probes (wellness applications) (**CFG** = 2T)

### 9.2.1 ON-OFF regulation | CFG = 0-1

To use the **VEH OEM** with ON-OFF regulation, the following conditions must be met:

- **CFG** = 0-1;
- Enable digital input closed (**CV**);
- Remote ON/OFF digital input closed (**0/1**).


When the **S0** digital input is closed, the **VEH OEM** generates humidity at the maximum value set in parameter **r6**.

### 9.2.2 Proportional regulation | CFG = PROP

To use the **VEH OEM** with proportional regulation, the following conditions must be met:

- **CFG** = PROP;
- Set the minimum humidity production **r5**;
- Set the maximum humidity production **r6**;
- Enable digital input closed (**CV**);
- Remote ON/OFF digital input closed (**0/1**).

The humidity production varies with the value read at the **S1** analogue input, with the logic expressed in the graph below, without exceeding parameter **r6**:





KEY	
Line	Description
—	$V_{in}$
—	Production

Fig. 46. How proportional regulation works | **CFG** = PROP

### 9.2.3 Regulation with the humidity sensor | CFG = HUM

To use the **VEH OEM** with regulation based on a humidity sensor, the following conditions must be met:

- **CFG** = HUM or **CFG** = HUML;
- Set parameter **P2** according to the sensor type to be used;
- Set the minimum humidity production **r5**;
- Set the maximum humidity production **r6**;
- Enable digital input closed (**CV**);
- Remote ON/OFF digital input closed (**0/1**).




KEY	
Line	Description
	$V_{in}$
	Production

Fig. 47. How regulation with the humidity sensor works | **CFG** = HUM

### 9.2.4 Regulation with the humidity sensor + limit sensor | CFG = HUML

To use the **VEH OEM** with regulation based on a humidity sensor and limit sensor, the following conditions must be met:

- **CFG** = HUML;
- Set parameter **P2** according to the sensor type to be used;
- Set parameter **P7** according to the limit sensor type to be used;
- Set the minimum humidity production **r5**;
- Set the maximum humidity production **r6**;
- Enable digital input closed (**CV**);
- Remote ON/OFF digital input closed (**0/1**).



**Fig. 48.** How regulation with the humidity sensor + limit sensor works | **CFG** = HUML

The humidity production behaves in the same way as for regulation with the humidity sensor (**CFG** = HUM), but the second sensor connected to the **S2** analogue input stops steam generation according to the humidity delivery.

The humidity limit activates when the humidity measured by sensor **S2** exceeds **SP2 + r10**.

### 9.2.5 Regulation with a temperature probe | CFG = 1T

To use the **VEH OEM** with regulation based on a temperature sensor, the following conditions must be met:

- **CFG** = 1T;
- Set parameter **P0** according to the sensor type to be used
- Set the minimum humidity production **r5**;
- Set the maximum humidity production **r6**;
- Enable digital input closed (**CV**);
- Remote ON/OFF digital input closed (**0/1**).

#### Principle of operation

The humidity requirement is managed with proportional temperature regulation between **SP3** and the proportional band **r20**, according to the following logic:

- Temperature  $\geq$  **SP3**: 0% humidity required;
- Temperature  $\leq$  **SP3 - r20**: humidity requirement at **r6**;
- **SP3** < Temperature < **r20**: proportionally linearized humidity required (minimum production **r5**).

### 9.2.6 Regulation with two temperature probes | CFG = 2T

To use the **VEH OEM** with regulation based on two temperature sensors, the following conditions must be met:

- **CFG** = 2T;
- Set parameter **P0** according to the sensor type to be used
- Set the minimum humidity production **r5**;
- Set the maximum humidity production **r6**;
- Set parameter **r23**;
- Set parameter **r24**;
- Enable digital input closed (**CV**);
- Remote ON/OFF digital input closed (**0/1**).

## 9.3 Water dilution

Water dilution in the hydraulic unit is controlled in two ways, depending on how parameter **c3** is set:

Par.	Description	MU	Range
<b>c3</b>	Type of draining for dilution. <b>0</b> = Current-based; <b>1</b> = Time-based.	---	0/1

**NOTE:** The electrodes are off while draining the water. Draining is activated 3 seconds after turning the electrodes off.

#### 9.3.1 Current-based water dilution

Setting **c3** = 0 configures water dilution based on the measured currents.

The evaporation cycle and water filling times to reach the required production are monitored during operation.

The electrical conductivity of the water tends to rise while producing humidity because it concentrates the substances in the water, and consequently the times mentioned above tend to reduce; during this stage, the **VEH OEM** activates the outlet pump until the internal current drops below the threshold set in parameter **c6**.

**NOTE:** The electrodes are off during draining to ensure safety.

The configuration parameters for current-based water dilution are:

Par.	Description	MU	Range
<b>c6</b>	Draining value for dilution (if <b>C3</b> = 0).	%	20...80

### 9.3.2 Time-based water dilution

Setting **c3** = 1 configures time-based water dilution to ensure that the water is diluted periodically without waiting for the internal conditions to become critical.

The **VEH OEM** dilutes the water after time **c5** for a duration of **c4**.

The configuration parameters for time-based water dilution are:

Par.	Description	MU	Range
<b>c4</b>	Draining duration for dilution (if <b>C3</b> = 1).	s	0...9999
<b>c5</b>	Time between two dilution draining events (if <b>C3</b> = 1).	min	30...999

### 9.4 Hydraulic unit draining

When the electrical conductivity of the water becomes too high, the hydraulic unit must be drained completely to restore optimal operating conditions.

The evaporation cycle and water filling times to reach the required production are monitored during operation.

Once it has been completely drained, it is washed a second time if the **VEH OEM** detects that the unfavourable conditions persist; if the second washing fails to create optimal operating conditions, alarm **AL08** is generated and the humidifier is forced OFF until maintenance is carried out (see "**12.1 TABLE OF VEH ALARMS" ON PAGE 61**).

### 9.5 Complete hydraulic unit emptying

The **VEH** hydraulic unit must be emptied completely in the following cases:

- After the inactivity time set in parameter **c0**;
- After the activity time set in parameter **c1**;
- If the timer is not working, when the humidifier is powered up;
- Whenever electrical power is supplied;
- When manual draining is activated from the user menu.

The configuration parameters for the cleaning cycles are:

Par.	Description	MU	Range
<b>c0</b>	Number of consecutive days of inactivity after which the hydraulic unit is emptied. <b>0</b> = Function disabled.	days	0...10
<b>c1</b>	Number of consecutive days of activity after which the hydraulic unit is emptied. <b>0</b> = Function disabled.	days	0...100

### 9.6 Level sensor

When the humidifier is running, the water may exceed the level sensor at the top of the hydraulic unit. This is caused by low electrical conductivity of the water in the boiler. The **VEH OEM** activates the outlet pump to drain it partially and resumes the evaporation cycles to achieve optimum electrical conductivity.

### 9.7 Foam management

Foaming may occur while the water is boiling in the hydraulic unit. Foaming is generally due to surfactants (manufacturing residues in the water filling system, water treatment agents, softeners) or an excessive concentration of dissolved salts in the water.

If **c11** = 1, the **VEH OEM** indicates and manages this condition.

If there is no foam in the boiler, the **VEH OEM** resumes normal operation.

If the level sensor is reached again within time **c12**, there is foam in the boiler. The **VEH OEM** empties the boiler completely. Thereafter, if the following occurs within time **c12**:

- The level sensor is reached again, and the **VEH OEM** performs two complete washing cycles;
- If the level sensor is not reached, the **VEH OEM** resumes normal operation.

If there is foam, the **VEH OEM** displays the code **W05** (see "**12.1 TABLE OF VEH ALARMS" ON PAGE 61**).

## 9.8 Operating hours

The **VEH OEM** records the hours of humidifier operation to allow periodic maintenance.

The following times are monitored:

- Total hours of machine operating; this cannot be reset and shows the hours of humidifier operation;
- Partial hours of hydraulic unit operation; this can be reset after maintenance on the tank;
- Total hours of hydraulic unit operation; this can be reset after replacing the tank;
- Operating hours of the inlet solenoid valve; this can be reset after replacing the component;
- Operating hours of the inlet pump; this can be reset after replacing the component.

The configuration parameters for the maintenance warning thresholds are:

Par.	Description	MU	Range
<b>M10</b>	Operating hours threshold for unit maintenance warning.	hx10	100....1000
<b>M11</b>	Partial operating hours threshold for the hydraulic unit maintenance warning.	hx10	100....1000
<b>M12</b>	Total operating hours threshold for the hydraulic unit maintenance warning.	hx10	100....1000
<b>M13</b>	Operating hours threshold for valve maintenance warning.	hx10	100....1000
<b>M14</b>	Operating hours threshold for the outlet pump maintenance warning.	hx10	100....1000

### 9.8.1 Resetting the operating hours

The operating hours can be reset from the maintenance menu by setting the parameters to 0.

## 9.9 Overproduction

When the humidity production exceeds 30% of the steam demand, draining is performed to return the steam production to the required value.

# 10. CONFIGURATION PARAMETERS

## Description of columns in the Table of Parameters

- **Par.:** list of configurable device parameters;
- **Description:** indicates parameter operation and any possible selections;
- **MU:** measurement unit relating to the parameter;
- **Range:** describes the interval of values that the parameter can assume. This can be correlated with other instrument parameters (indicated with the parameter code).  
**NOTE:** if the actual value is outside the permitted limits for that parameter (for example, because other parameters defining the aforementioned limits have been altered), the value of the violated limit is displayed instead of the actual value;
- **Default:** indicates the pre-set factory configuration;
- **PW:** indicates the access level for the parameter:
  - **U** = User parameters;
  - **M** = Maintenance parameters.

## 9.10 Table of adjustment parameters

Par.	Description	MU	Range	Default	PW
<b>SETPOINT group</b>					
<b>SP1</b>	Humidity setpoint.	%	<b>r1...r2</b>	70.0	U
<b>SP2</b>	Humidity limit setpoint.	%	<b>r11...r12</b>	85.0	U
<b>SP3</b>	Wellness temperature setpoint.	°C/°F	<b>r21...r22</b>	40.0	U
<b>CONFIGURATION group</b>					
<b>CFG</b>	Operating mode (see " <b>9.2 HUMIDITY REGULATION" ON PAGE 44</b> ) <b>0-1</b> (0) = ON/OFF from digital input; <b>PROP</b> (1) = Proportional input; <b>HUM</b> (2) = Humidity sensor; <b>HUML</b> (3) = Humidity sensor + limit sensor; <b>1T</b> (4) = 1 temperature sensor; <b>2T</b> (5) = 2 temperature sensors.	---	0-1 / PROP / HUM / HUML / 1T / 2T	0-1	M
<b>duAL</b>	Dual boiler humidifier operation. <b>0</b> = Parallel; <b>1</b> = Sequential.	---	0/1	0	U
<b>P0</b>	Type of sensor <b>S1</b> temperature of pre-heating + anti-freeze. --- (0) = Disabled; <b>PTC</b> (1) = PTC; <b>NTC</b> (2) = NTC.	---	--- / PTC / NTC	---	M
<b>P1</b>	Electrical conductivity of the water.	µS/cm	0...1250	0	M
<b>P2</b>	Type of regulator/sensor/probe <b>S2</b> (regulation input). <b>PTC</b> (0) = PTC probe; <b>1000</b> (1) = Pt1000 probe; <b>NTC</b> (2) = NTC probe; <b>0-10</b> (3) = Proportional input 0...10 V; <b>0-5</b> (4) = Proportional input 0...5 V; <b>0.20</b> (5) = Input 0...20 mA; <b>4.20</b> (6) = Input 4...20 mA; <b>E520</b> (7) = EVHTP520 proprietary probe.	---	PTC / 1 000 / NTC / 0-10 / 0-5 / 0.20 / 4.20 / E520	0-10	M
<b>P3</b>	Minimum value <b>S2</b> (if <b>CFG</b> = HUM or <b>CFG</b> = HUML).	%rH	0...100	0	M
<b>P4</b>	Maximum value <b>S2</b> (if <b>CFG</b> = HUM or <b>CFG</b> = HUML).	%rH	0...100	100	M
<b>P5</b>	Sensor offset <b>S2</b> (if <b>CFG</b> = HUM or <b>CFG</b> = HUML).	%rH	-10...10	0	M
<b>P6</b>	<b>S1</b> sensor offset (temperature).	°C/°F	-10.0...10.0	0.0	M
<b>P7</b>	Type of sensor/probe <b>S3</b> (limit or mediating probe with input <b>P2</b> if temperature). Similar to <b>P2</b> .	---	PTC / 1 000 / NTC / 0-10 / 0-5 / 0.20 / 4.20 / E520	0-10	M
<b>P8</b>	Minimum value <b>S3</b> (if <b>CFG</b> = HUML).	%rH	0...100	0	M
<b>P9</b>	Maximum value <b>S3</b> (if <b>CFG</b> = HUML).	%rH	0...100	100	M
<b>P10</b>	Sensor offset <b>S3</b> humidity (if <b>CFG</b> = HUML).	%rH	-10...10	0	M
<b>P11</b>	TA sensor K (1000 = current multiplier of 1.000).	---	0...2000	1000	M
<b>P12</b>	Ventilation presence (enables maintenance management based on utility operating hours). <b>No</b> = No ventilation; <b>Yes</b> = Ventilation present.	---	No/Yes	Yes	M

Par.	Description	MU	Range	Default	PW
<b>P13</b>	Sensor offset <b>S2</b> temperature (if <b>CFG = 1T</b> or <b>CFG = 2T</b> ).	°C/°F	-10.0...10.0	0.0	M
<b>P14</b>	Sensor offset <b>S3</b> temperature (if <b>CFG = 1T</b> or <b>CFG = 2T</b> ).	°C/°F	-10.0...10.0	0.0	M
<b>P20</b>	Electrical conductivity of the water at 100°C (212 °F). <b>0</b> = 3000 µS/cm; <b>1</b> = 4000 µS/cm; <b>2</b> = 5000 µS/cm.	---	0...2	1	M
<b>P21</b>	Temperature unit of measure (changing value means that the temperature parameter limits will need to be reset manually). <b>0</b> = °C; <b>1</b> = °F.	---	0/1	0	M
<b>P22</b>	Steam production unit of measurement. <b>0</b> = kg/h; <b>1</b> = lb/h.	---	0/1	0	M
<b>REGULATION group</b>					
<b>r0</b>	Humidity probe setpoint hysteresis.	%	0...20	2	M
<b>r1</b>	Minimum value for setting humidity setpoint.	%	0... <b>r2</b>	20	M
<b>r2</b>	Maximum value for setting humidity setpoint.	%	<b>r1</b> ...100	95	M
<b>r4</b>	Humidity proportional band.	%	0...50	50	M
<b>r5</b>	Minimum production.	%	20... <b>r6</b>	20	M
<b>r6</b>	Maximum production.	%	<b>r5</b> ...100	75	U
<b>r10</b>	Humidity limit probe setpoint hysteresis.	%	0...20	2	M
<b>r11</b>	Minimum value for setting humidity limit setpoint.	%	0... <b>r12</b>	20	M
<b>r12</b>	Maximum limit setpoint value.	%	<b>r11</b> ...100	95	M
<b>r20</b>	Temperature proportional band.	°C/°F	0.1... 10.0	5.0	M
<b>r21</b>	Minimum value for setting temperature setpoint.	°C/°F	10.0... <b>r22</b>	20.0	M
<b>r22</b>	Maximum value for setting temperature setpoint.	°C/°F	<b>r21</b> ...60.0	50.0	M
<b>r23</b>	Wellness temperature probe 1 weight.	%	0...100	50	M
<b>r24</b>	Wellness temperature probe 2 weight.	%	0...100	50	M
<b>c0</b>	Number of consecutive days of inactivity after which the hydraulic unit is emptied. <b>0</b> = Function disabled.	days	0...10	2	M
<b>c1</b>	Number of consecutive days of activity after which the hydraulic unit is emptied. <b>0</b> = Function disabled.	days	0...100	14	M
<b>c3</b>	Type of draining for dilution. <b>0</b> = Current-based; <b>1</b> = Time-based.	---	0/1	0	M
<b>c4</b>	Draining duration for dilution (if <b>c3 = 1</b> ).	s	0...9999	5	M
<b>c5</b>	Time between two dilution draining events (if <b>c3 = 1</b> ).	m	30...999	60	M
<b>c6</b>	Percentage draining for dilution (if <b>c3 = 0</b> ).	%	20...80	30	M
<b>c10</b>	Maximum initial water filling time for water inlet check.	s	50...2000	1200	M
<b>c11</b>	Anti-foam process. <b>0</b> = Disabled; <b>1</b> = Enabled.	---	0/1	0	M
<b>c14</b>	Time to drain the hydraulic unit completely. (* ) Default according to model, from: <b>3 kg/h</b> = 30 s; <b>5..15 kg/h</b> = 40 s; <b>20...200 kg/h</b> = 180 s.	s	0...240	(*)	M
<b>c15</b>	Hours of dual hydraulic unit machine rotation.	hours	10...500	150	M
<b>c16</b>	Low conductivity algorithm enable. <b>0</b> = Disabled; <b>1</b> = Enabled.	---	0/1	0	M
<b>MAINTENANCE/ALARMS group</b>					
<b>M5</b>	Low humidity alarm threshold. The hysteresis is fixed at 2%. <b>0</b> = Disabled.	%	0...100	20	M
<b>M6</b>	High humidity alarm threshold. The hysteresis is fixed at 2%. <b>0</b> = Disabled.	%	0...100	95	M
<b>M7</b>	High/low humidity alarm delay. <b>0</b> = Disabled.	s	0...999	120	M
<b>M8</b>	Delay in alarm for no production	hours	1...100	48	M
<b>M9</b>	Maximum number of automatic attempts to rearm alarm <b>AL03</b> "No water" after which the alarm blocks manual rearming.	num	1...10	3	M
<b>M10</b>	Operating hours threshold for unit maintenance warning.	hx10	100....10000	4000	M
<b>M11</b>	Partial operating hours threshold for the hydraulic unit maintenance warning.	hx10	100....2000	200	M
<b>M12</b>	Total operating hours threshold for the hydraulic unit maintenance warning.	hx10	100....2000	1000	M
<b>M13</b>	Operating hours threshold for valve maintenance warning.	hx10	100....2000	1000	M
<b>M14</b>	Operating hours threshold for pump maintenance warning.	hx10	100....2000	1000	M
<b>M15</b>	Operating hours threshold for fan maintenance warning.	hx10	100....2000	1000	M

Par.	Description	MU	Range	Default	PW
<b>M20</b>	High temperature alarm threshold. The hysteresis is fixed at 0.5 °C; <b>0</b> = Excluded.	°C/°F	0.0...80.0	50.0	M
<b>M21</b>	Maximum number of automatic attempts to rearm the high temperature alarm after which the alarm blocks manual rearming (attempts every hour)	num	1...10	3	M
<b>COMMUNICATION group</b>					
<b>LA1</b>	Modbus communication protocol address.	num	1...247	247	M
<b>Lb1</b>	Modbus transmission speed (baud rate). <b>0</b> = 2400; <b>1</b> = 4800; <b>2</b> = 9600; <b>3</b> = 19200; <b>4</b> = 38400.	---	0...4	4	E
<b>LP1</b>	Modbus parity bit. <b>0</b> = None; <b>1</b> = Odd; <b>2</b> = Even.	---	0...2	2	E
<b>LS1</b>	Modbus stop bit. <b>0</b> = 1 stop bit; <b>1</b> = 2 stop bits.	---	0/1	0	E
<b>PASSWORD group</b>					
<b>PA1</b>	First level password. <b>0</b> = No password	---	-99...999	0	U
<b>PA2</b>	Second level password.	---	-99...999	824	M

# 11. MODBUS RTU FUNCTIONS AND RESOURCES

## 11.1 Introduction

Modbus RTU (Remote Terminal Unit) protocol is a means of communication which allows data exchange between a computer and programmable logic controllers.

This protocol is based on the exchange of messages between master-slave and client-server devices. Master devices can receive information from slaves and write to their registers, while slave devices cannot initiate any information transfer until they receive a request from the slave device.

Modbus communication is used in industrial automation systems (IAS) and in the construction of building management systems (BMS). Modbus protocol is widely utilised due to the fact it is easy to use, very reliable and has an open source code that can be used royalty-free on any application or device.

Modbus RTU is the most common application and uses CRC error detection and binary encoding.




Fig. 49. Diagram showing message exchange in a Modbus communication

Modbus protocol establishes a Protocol Data Unit (PDU) independent from the communication layer below it, introducing some additional fields specified on the Application Data Unit (ADU) ("FIG. 50. FRAMING OF A MESSAGE USING MODBUS PROTOCOL" ON PAGE 53) to specific buses and networks.

Devices such as PLCs (Programmable Logic Controller), HMIs (Human Machine Interface), control panels, drivers, motion controllers, I/O devices, etc. can use Modbus to begin a remote procedure, and the protocol is often used to connect a supervising computer with a Remote Terminal Unit in a supervision, control and data acquisition (SCADA) system.




Fig. 50. Framing of a message using Modbus protocol

For further information relating to Modbus protocol, visit the official Modbus website: [www.modbus.org](http://www.modbus.org).

## 11.2 Modbus message structure

Modbus RTU protocol requires the message to start with a silent time interval of at least 3.5 character times. This feature is often implemented by executing a time interval of multiple of character times at the baud rate used in the network. The characters available for each field are in binary form.

A description of the structure of a Modbus RTU message is provided below.

Start	Address	Function	Data	CRC	Stop
3.5 x character time	8 bit	8 bit	(N x 8 bit)	16 bit	3.5 x character time
Time period in which data must not be exchanged over the communication bus, to allow the connected instruments to recognise the end of one message and the start of the next	Corresponds to the address for the device with which the master has established dialogue; this is a value between 1...247. The address 0 is reserved for the broadcast message sent to all slave devices	Code for the function to execute or which has been executed	Contains the data sent by the master or sent back by the slave as a response to a question	Allows the master and the slave to check whether any errors are present during communication, and if there are, to ignore the message received	Time period in which data must not be exchanged over the communication bus, to allow the connected instruments to recognise the end of one message and the start of the next

## 11.3 Modbus functions and registers

The Modbus registers for the device are organised around the four types of basic data reference indicated above, and this type of data is further identified by the first number of the address.

### 11.3.1 Available Modbus commands and data areas

The commands implemented are as follows:

Command	Description
<b>03 (hex 0x03)</b>	Resource reading command
<b>06 (hex 0x06)</b>	Resource writing command

### 11.4 Address configuration

The RS-485 communication serial port can be used to configure the device, the parameters, the statuses and the Modbus variables and to monitor device operation using Modbus protocol.

The device address in a Modbus message is set by parameter **LA1**.

The address **0** is only used for broadcast messages, recognised by all slaves. Slave devices do not respond to a broadcast message.

Serial line configuration parameters, which can be accessed via the user interface menu, are:

Par.	Description	MU	Range	Default
<b>LA1</b>	Modbus communication protocol address.	---	0...247	247
<b>Lb1</b>	Modbus transmission speed (baud rate). <b>0</b> = 2400; <b>1</b> = 4800; <b>2</b> = 9600; <b>3</b> = 19200; <b>4</b> = 38400.	---	0...4	4
<b>LP1</b>	Modbus parity bit. <b>0</b> = None; <b>1</b> = Odd; <b>2</b> = Even.	---	0...2	2
<b>LS1</b>	Modbus stop bit. <b>0</b> = 1 stop bit; <b>1</b> = 2 stop bits.	---	0/1	0

The RS-485 RTU serial line has the following characteristics:

- RTU mode;
- Bit: 8 bit

### 11.5 Connections

For the entire system to work properly, including the RS-485 RTU serial line, observe the instructions provided in chapter "**6. ELECTRICAL CONNECTIONS**" **ON PAGE 25**.

In particular, take care to make the connections correctly, observing the instructions in section "**6.4 ELECTRICAL CONNECTIONS**" **ON PAGE 28**

### 11.6 Modbus table content

#### Table content description

The table below contains the information required to access the resources properly and directly.

There are two tables:

- The Modbus address table, which contains all the configuration parameters for the device and the corresponding Modbus addresses;
- Modbus resource table, which contains all the status (I/O) and alarm resources in the device memory.

#### Description of columns in the Table of addresses

- **Par.:** list of configurable device parameters;
- **Description:** indicates parameter operation and any possible selections;
- **MU:** measurement unit relating to the parameter;
- **Range:** describes the interval of values that the parameter can assume. This can be correlated with other instrument parameters (indicated with the parameter code).  
**NOTE:** if the actual value is outside the permitted limits for that parameter (for example, because other parameters defining the aforementioned limits have been altered), the value of the violated limit is displayed instead of the actual value;
- **Val. Adr.:** Indicates the address of the Modbus register containing the resource you want to access;
- **R/W:** Indicates the option of reading or writing the resource:
  - **R:** The resource is read-only;
  - **W:** The resource is write-only;
  - **R/W:** The resource can be both read and written.
- **CPL:** When the fields indicates Y, the value read by the register needs to be converted because the value represents a number with a sign. In the other cases the value is always positive or zero.
- **DATA SIZE:** Indicates the size in data bits:
  - **DWORD** = 32 bit
  - **DOUBLE** = 32 bit with sign
  - **SHORT** = 16 bit with sign
  - **WORD** = 16 bit
  - **Byte** = 8 bit
  - The "n" bits = 0...15 bit depending on the value of "n"

## 11.7 Modbus addresses

### 11.7.1 Modbus address table

Par.	Description	Val. Adr.	R/W	DATA SIZE	CPL	MU	Range
<b>SETPOINT group</b>							
<b>SP1</b>	Humidity setpoint.	2001	R/W	SHORT	Y	%	r1...r2
<b>SP2</b>	Humidity limit setpoint.	2002	R/W	SHORT	Y	%	r11...r12
<b>SP3</b>	Temperature probe setpoint.	2086	R/W	SHORT	Y	°C/°F	r21...r22
<b>CONFIGURATION group</b>							
<b>CFG</b>	Control input selection. <b>0-1</b> (0) = ON/OFF from digital input; <b>PROP</b> (1) = Proportional input; <b>HUM</b> (2) = Humidity sensor; <b>HUML</b> (3) = Humidity sensor + limit sensor; <b>1T</b> (4) = 1 temperature sensor; <b>2T</b> (5) = 2 temperature sensors.	2003	R/W	BYTES	---	---	0...5
<b>duAL</b>	Dual boiler humidifier operation. <b>0</b> = Parallel; <b>1</b> = Sequential.	2066	R/W	1 BIT	---	---	0/1
<b>nTyp</b>	Master/Slave operation. <b>0</b> = Disabled; <b>1</b> = Parallel; <b>2</b> = Rotation; <b>3</b> = Balancing.	2073	R/W	BYTES	---	---	0...3
<b>nAdr</b>	Networked master/slave module (only if enabled Master/Slave Operation <b>nTyp</b> ≠ 0). <b>1</b> = Master; <b>2</b> = Slave 1; <b>3</b> = Slave 2; <b>4</b> = Slave 3; <b>5</b> = Slave 4.	2070	R/W	BYTES	---	---	1...5
<b>nPrE</b>	Master/Slave machine pre-heating enabled. <b>0</b> = Disabled; <b>1</b> = Enabled.	2074	R/W	1BIT	---	---	0/1
<b>ntot</b>	Total number of Master/Slave machines.	2072	R/W	3 BIT	---	num	2...5
<b>nbAc</b>	Number of Master/Slave backup machines.	2071	R/W	2BIT	---	num	1...3
<b>nHrs</b>	Hours of Master/Slave machine rotation.	2075	R/W	BYTES	---	hours	10...500
<b>P0</b>	S1 sensor type (temperature). --- (0) = Disabled; <b>PTC</b> (1) = PTC; <b>NTC</b> (2) = NTC.	2076	R/W	3 BIT	---	---	0...2
<b>P1</b>	Electrical conductivity of the water.	2006	R/W	WORD	---	µS/cm	0...1250
<b>P2</b>	<b>S2</b> sensor type (humidity 1 / proportional input). <b>PTC</b> (0) = PTC probe; <b>1000</b> (1) = Pt1000 probe; <b>NTC</b> (2) = NTC probe; <b>0-10</b> (3) = Proportional input 0...10 V; <b>0-5</b> (4) = Proportional input 0...5 V; <b>0.20</b> (5) = Input 0...20 mA; <b>4.20</b> (6) = Input 4...20 mA; <b>E520</b> (7) = EVHTP520 proprietary probe.	2007	R/W	BYTES	---	---	0...7
<b>P3</b>	Minimum value <b>S2</b> (if <b>CFG</b> = HUM or <b>CFG</b> = HUML).	2008	R/W	BYTES	---	%rH	0...100
<b>P4</b>	Maximum value <b>S2</b> (if <b>CFG</b> = HUM or <b>CFG</b> = HUML).	2009	R/W	BYTES	---	%rH	0...100
<b>P5</b>	Sensor offset <b>S2</b> (if <b>CFG</b> = HUM or <b>CFG</b> = HUML).	2010	R/W	BYTES	Y	%rH	-10...10
<b>P6</b>	<b>S1</b> sensor offset (temperature).	2011	R/W	SHORT	Y	°C/°F	-10.0...10.0
<b>P7</b>	<b>S3</b> sensor type (humidity 2 limit). Similar to <b>P2</b> .	2012	R/W	BYTES	---	---	0...7
<b>P8</b>	Minimum value <b>S3</b> (if <b>CFG</b> = HUML).	2013	R/W	BYTES	---	%rH	0...100
<b>P9</b>	Maximum value <b>S3</b> (if <b>CFG</b> = HUML).	2014	R/W	BYTES	---	%rH	0...100
<b>P10</b>	Sensor offset <b>S3</b> (if <b>CFG</b> = HUML).	2015	R/W	SHORT	Y	%rH	-10...10
<b>P12</b>	Ventilation presence (enables maintenance management based on utility operating hours).	2077	R/W	1 BIT	---	---	0/1

Par.	Description	Val. Adr.	R/W	DATA SIZE	CPL	MU	Range
<b>P13</b>	Sensor offset <b>S2</b> temperature (if <b>CFG</b> = 1T or <b>CFG</b> = 2T).	2078	R/W	SHORT	Y	°C/°F	-10.0...10.0
<b>P14</b>	Sensor offset <b>S3</b> temperature (if <b>CFG</b> = 1T or <b>CFG</b> = 2T).	2079	R/W	SHORT	Y	°C/°F	-10.0...10.0
<b>P20</b>	Electrical conductivity of the water at 100°C (212°F). <b>0</b> = 3000 µS/cm; <b>1</b> = 4000 µS/cm; <b>2</b> = 5000 µS/cm.	2016	R/W	3 BIT	---	---	0...2
<b>P21</b>	Temperature unit of measure (changing value means that the temperature parameter limits will need to be reset manually). <b>0</b> = °C; <b>1</b> = °F.	2017	R/W	1 BIT	---	---	0/1
<b>P22</b>	Steam production unit of measurement. <b>0</b> = kg/h; <b>1</b> = lb/h.	2080	R/W	1 BIT	---	---	0/1
<b>REGULATION group</b>							
<b>r0</b>	Sensor 1 setpoint hysteresis.	2018	R/W	BYTES	---	%	0...20
<b>r1</b>	Minimum setpoint value.	2019	R/W	BYTES	---	%	0... <b>r2</b>
<b>r2</b>	Maximum setpoint value.	2020	R/W	BYTES	---	%	<b>r1</b> ...100
<b>r4</b>	Proportional band.	2021	R/W	BYTES	---	%	0...50
<b>r5</b>	Minimum production.	1927	R/W	BYTES	---	%	0... <b>r6</b>
<b>r6</b>	Maximum production.	1926	R/W	BYTES	---	%	<b>r5</b> ...100
<b>r10</b>	Limit sensor setpoint hysteresis.	2024	R/W	BYTES	---	%	0...20
<b>r11</b>	Minimum limit setpoint value.	2025	R/W	BYTES	---	%	0... <b>r12</b>
<b>r12</b>	Maximum limit setpoint value.	2026	R/W	BYTES	---	%	<b>r11</b> ...100
<b>c0</b>	Number of continuous days of inactivity after which the boiler is emptied. <b>0</b> = Function disabled.	2027	R/W	BYTES	---	days	0...10
<b>c1</b>	Number of continuous days of activity after which the boiler is emptied. <b>0</b> = Function disabled.	2028	R/W	BYTES	---	days	0...100
<b>c2</b>	Number of cleaning cycles (filling+draining) following emptying due to activity or inactivity.	2029	R/W	BYTES	---	num	0...10
<b>c3</b>	Type of draining for dilution. <b>0</b> = Current-based; <b>1</b> = Time-based.	2030	R/W	1 BIT	---	---	0/1
<b>c4</b>	Draining duration for dilution (if <b>C3</b> = 1).	2031	R/W	WORD	---	s	0...9999
<b>c5</b>	Time between two dilution draining events (if <b>C3</b> = 1).	2032	R/W	WORD	---	min	30...999
<b>c6</b>	Draining value for dilution (if <b>C3</b> = 0).	2033	R/W	BYTES	---	%	20...80
<b>c10</b>	Maximum initial water filling time for water inlet check, depending on the model.	2036	R/W	WORD	---	s	50...2000
<b>c11</b>	Anti-foam process. <b>0</b> = Disabled; <b>1</b> = Enabled.	2037	R/W	1 BIT	---	---	0/1
<b>c12</b>	Time to detect foam after lowering the current by 30%.	2038	R/W	WORD	---	s	10...300
<b>c13</b>	Enable water filling with steam generation active.	2039	R/W	1 BIT	---	---	0/1
<b>c14</b>	Time to drain the hydraulic unit completely.	2040	R/W	BYTES	---	s	0...240
<b>c15</b>	Hours of dual hydraulic unit machine rotation.	2065	R/W	WORD	---	hours	10...500
<b>c16</b>	Low conductivity algorithm enable.	1323	R/W	1 BIT	---	---	0/1
<b>MAINTENANCE/ALARMS group</b>							
<b>M5</b>	Low humidity alarm threshold. The hysteresis is fixed at 2%. <b>0</b> = Disabled.	2041	R/W	BYTES	---	%	0...100
<b>M6</b>	High humidity alarm threshold. The hysteresis is fixed at 2%. <b>0</b> = Disabled.	2042	R/W	BYTES	---	%	0...100
<b>M7</b>	High/low humidity alarm delay. <b>0</b> = Disabled.	2043	R/W	WORD	---	s	0...999
<b>M8</b>	Delay in alarm for no production.	2064	R/W	BYTES	---	h	1...100
<b>M9</b>	Maximum number of automatic attempts to rearm alarm <b>AL03</b> "No water" after which the alarm blocks manual rearming	2067	R/W	BYTES	---	num	1...10
<b>M10</b>	Operating hours threshold for unit maintenance warning.	2044 ... 2045	R/W	DWORD	---	hours x10	100....10000
<b>M11</b>	Operating hours threshold for partial boiler maintenance warning.	2046 ... 2047	R/W	DWORD	---	hours x10	100....2000
<b>M12</b>	Operating hours threshold for full boiler maintenance warning.	2048 ... 2049	R/W	DWORD	---	hours x10	100....2000

Par.	Description	Val. Adr.	R/W	DATA SIZE	CPL	MU	Range
<b>M13</b>	Operating hours threshold for valve maintenance warning.	2050 ... 2051	R/W	DWORD	---	hours x10	100...2000
<b>M14</b>	Operating hours threshold for pump maintenance warning.	2052 ... 2053	R/W	DWORD	---	hours x10	100...2000
<b>M15</b>	Operating hours threshold for fan maintenance warning.	2054 ... 2055	R/W	DWORD	---	hours x10	100...2000
<b>M20</b>	High temperature alarm threshold. The hysteresis is fixed at 3 °C (6 °F); <b>0</b> = Excluded.	2068	R/W	BYTES	---	°C/°F	0.0...80.0
<b>M21</b>	Maximum number of automatic attempts to rearm the high temperature alarm after which the alarm blocks manual rearming (attempts every hour)	2069	R/W	BYTES	---	num	1...10
<b>COMMUNICATION group</b>							
<b>LA1</b>	Modbus communication protocol address.	2056	R/W	BYTES	---	num	1...247
<b>Lb1</b>	Modbus transmission speed (baud rate). <b>0</b> = 2400; <b>1</b> = 4800; <b>2</b> = 9600; <b>3</b> = 19200; <b>4</b> = 38400.	2057	R/W	BYTES	---	---	0...4
<b>LP1</b>	Modbus parity bit. <b>0</b> = None; <b>1</b> = Odd; <b>2</b> = Even.	2058	R/W	BYTES	---	---	0...2
<b>LS1</b>	Modbus stop bit. <b>0</b> = 1 stop bit; <b>1</b> = 2 stop bits.	2059	R/W	1 BIT	---	---	0/1
<b>PASSWORD group</b>							
<b>PA1</b>	First level password. <b>0</b> = No password.	2061	R/W	SHORT	Y	---	-99...999
<b>PA2</b>	Second level password.	2062	R/W	SHORT	Y	---	-99...999

### 11.7.2 Modbus resource table

Code	Description	Val. Adr.	Filter value	R/W	DATA SIZE	CPL	MU	Range
<b>DI1_s0</b>	<b>S0</b> digital input status.	257	---	R	1 BIT	---	---	0/1
<b>DI2_cv</b>	Digital input <b>CV</b> status.	258	---	R	1 BIT	---	---	0/1
<b>DI3_of</b>	Digital input <b>0/1</b> status.	259	---	R	1 BIT	---	---	0/1
<b>DI4_Is</b>	Level sensor input status.	260	---	R	1 BIT	---	---	0/1
<b>DO1_EV1</b>	Inlet solenoid valve output status.	385	---	R	1 BIT	---	---	0/1
<b>DO2_DP1</b>	Inlet pump output status.	386	---	R	1 BIT	---	---	0/1
<b>DO3_G1</b>	Steam generation output status.	387	---	R	1 BIT	---	---	0/1
<b>DO4_DEH</b>	Dehumidification output status.	388	---	R	1 BIT	---	---	0/1
<b>DO5_FANS</b>	Ventilated distributor output status.	389	---	R	1 BIT	---	---	0/1
<b>DO6_AL</b>	Alarm output status.	390	---	R	1 BIT	---	---	0/1
<b>AI_temperature</b>	Temperature sensor <b>S1</b> value.	516	---	R	SHORT	Y	°C/°F	-3276.8... 3276.7
<b>AI_Humidity</b>	Humidity sensor <b>S2</b> value.	517	---	R	SHORT	Y	%rH	-32768... 32767
<b>AI_Humidity_L</b>	Humidity limit sensor <b>S3</b> value.	518	---	R	SHORT	Y	%rH	-32768... 32767
<b>AI_Request</b>	Proportional input <b>S2</b> value.	519	---	R	SHORT	Y	%	-32768... 32767
<b>AI_Current</b>	Current sensor <b>CT1</b> value.	520	---	R	SHORT	Y	A	-327.68... 327.67
<b>PackedAlarm1</b>	Status of warning <b>W01</b> .	769	0	R	1 BIT	---	---	0/1
<b>PackedAlarm1</b>	Status of alarm <b>AL01</b> .	769	1	R	1 BIT	---	---	0/1
<b>PackedAlarm1</b>	Status of warning <b>W02</b> .	769	2	R	1 BIT	---	---	0/1
<b>PackedAlarm1</b>	Status of alarm <b>AL02</b> .	769	3	R	1 BIT	---	---	0/1
<b>PackedAlarm1</b>	Status of alarm <b>AL03</b> .	769	4	R	1 BIT	---	---	0/1
<b>PackedAlarm1</b>	Status of warning <b>W04</b> .	769	5	R	1 BIT	---	---	0/1
<b>PackedAlarm1</b>	Status of warning <b>W05</b> .	769	6	R	1 BIT	---	---	0/1
<b>PackedAlarm1</b>	Status of warning <b>W06</b> .	769	7	R	1 BIT	---	---	0/1
<b>PackedAlarm1</b>	Status of alarm <b>AL07</b> .	769	8	R	1 BIT	---	---	0/1
<b>PackedAlarm1</b>	Status of warning <b>W08</b> .	769	9	R	1 BIT	---	---	0/1
<b>PackedAlarm1</b>	Status of alarm <b>AL08</b> .	769	10	R	1 BIT	---	---	0/1
<b>PackedAlarm1</b>	Status of alarm <b>AL09</b> .	769	11	R	1 BIT	---	---	0/1
<b>PackedAlarm1</b>	Status of alarm <b>AL10</b> .	769	12	R	1 BIT	---	---	0/1
<b>PackedAlarm1</b>	Status of alarm <b>AL11</b> .	769	13	R	1 BIT	---	---	0/1
<b>PackedAlarm1</b>	Status of warning <b>W12</b> .	769	14	R	1 BIT	---	---	0/1
<b>PackedAlarm1</b>	Status of warning <b>W13</b> .	769	15	R	1 BIT	---	---	0/1
<b>PackedAlarm2</b>	Status of alarm <b>AL14</b> .	770	0	R	1 BIT	---	---	0/1
<b>PackedAlarm2</b>	Status of alarm <b>AL15</b> .	770	1	R	1 BIT	---	---	0/1
<b>PackedAlarm2</b>	Status of alarm <b>AL16</b> .	770	2	R	1 BIT	---	---	0/1
<b>PackedAlarm2</b>	Status of alarm <b>AL17</b> .	770	3	R	1 BIT	---	---	0/1
<b>PackedAlarm2</b>	Status of alarm <b>AL18</b> .	770	4	R	1 BIT	---	---	0/1
<b>PackedAlarm2</b>	Status of alarm <b>AL19</b> .	770	5	R	1 BIT	---	---	0/1
<b>PackedAlarm2</b>	Status of alarm <b>AL20</b> .	770	6	R	1 BIT	---	---	0/1
<b>PackedAlarm2</b>	Status of alarm <b>AL21</b> .	770	7	R	1 BIT	---	---	0/1
<b>PackedAlarm2</b>	Status of alarm <b>AL22</b> .	770	8	R	1 BIT	---	---	0/1
<b>PackedAlarm2</b>	Status of alarm <b>AL23</b> .	770	9	R	1 BIT	---	---	0/1
<b>PackedAlarm2</b>	Status of alarm <b>AL24</b> .	770	10	R	1 BIT	---	---	0/1
<b>PackedAlarm2</b>	Status of alarm <b>AL25</b> .	770	11	R	1 BIT	---	---	0/1
<b>PackedAlarm2</b>	Status of alarm <b>AL26</b> .	770	12	R	1 BIT	---	---	0/1
<b>PackedAlarm2</b>	Status of alarm <b>AL27</b> .	770	13	R	1 BIT	---	---	0/1
<b>PackedAlarm2</b>	Status of alarm <b>AL28</b> .	770	14	R	1 BIT	---	---	0/1
<b>PackedAlarm2</b>	Status of warning <b>W29</b> .	770	15	R	1 BIT	---	---	0/1

Code	Description	Val. Adr.	Filter value	R/W	DATA SIZE	CPL	MU	Range
<b>PackedAlarm3</b>	Status of alarm <b>AL29</b> .	771	0	R	1 BIT	---	---	0/1
<b>PackedAlarm3</b>	Status of warning <b>W30</b> .	771	1	R	1 BIT	---	---	0/1
<b>PackedAlarm3</b>	Status of alarm <b>AL30</b> .	771	2	R	1 BIT	---	---	0/1
<b>PackedAlarm3</b>	Status of alarm <b>AL31</b> .	771	3	R	1 BIT	---	---	0/1
<b>PackedAlarm3</b>	Status of warning <b>W32</b> .	771	4	R	1 BIT	---	---	0/1
<b>PackedAlarm3</b>	Status of warning <b>W33</b> .	771	5	R	1 BIT	---	---	0/1
<b>PackedAlarm3</b>	Status of warning <b>W34</b> .	771	6	R	1 BIT	---	---	0/1
<b>PackedAlarm3</b>	Status of warning <b>W35</b> .	771	7	R	1 BIT	---	---	0/1
<b>PackedAlarm3</b>	Status of alarm <b>AL35</b> .	771	8	R	1 BIT	---	---	0/1
<b>PackedAlarm3</b>	Status of alarm <b>AL36</b> .	771	9	R	1 BIT	---	---	0/1
<b>PackedAlarm3</b>	Status of alarm <b>AL37</b> .	771	10	R	1 BIT	---	---	0/1
<b>PackedAlarm3</b>	Status of alarm <b>AL38</b> .	771	11	R	1 BIT	---	---	0/1
<b>BMS_AL1</b>	<b>AL01</b> manual reset.	773	---	R/W	1 BIT	---	---	0/1
<b>BMS_AL3</b>	<b>AL03</b> manual reset.	774	---	R/W	1 BIT	---	---	0/1
<b>BMS_W04</b>	<b>W04</b> manual reset.	775	---	R/W	1 BIT	---	---	0/1
<b>BMS_AL22</b>	<b>AL22</b> manual reset.	776	---	R/W	1 BIT	---	---	0/1
<b>BMS_AL29_B2</b>	<b>AL29</b> manual reset.	777	---	R/W	1 BIT	---	---	0/1
<b>BMS_AL31_B2</b>	<b>AL31</b> manual reset.	778	---	R/W	1 BIT	---	---	0/1
<b>BMS_W32_B2</b>	<b>W32</b> manual reset.	779	---	R/W	1 BIT	---	---	0/1
<b>manWash</b>	Manual draining command (OFF/ON).	1282	---	R/W	1 BIT	---	---	0/1
<b>GeneralAlarm</b>	General alarm status (OFF/ON).	1283	---	R/W	1 BIT	---	---	0/1
<b>unitOn</b>	Unit status (OFF/ON).	1284	---	R/W	1 BIT	---	---	0/1
---	Restore default parameters command	1285	---	R/W	1 BIT	---	---	0/1
<b>HoursService</b>	Hours of humidifier operation (LOW) (*).	1286	---	R/W	DWORD	---	h x 10	0.0 ... 429496729.5
	Hours of humidifier operation (HIGH) (*).	1287	---	R/W	DWORD	---	h x 10	0.0 ... 429496729.5
<b>HoursBoilerP</b>	Partial hours of boiler operation. (LOW) (*).	1288	---	R/W	DWORD	---	h x 10	0.0 ... 429496729.5
	Partial hours of boiler operation. (HIGH) (*).	1289	---	R/W	DWORD	---	h x 10	0.0 ... 429496729.5
<b>HoursBoilerT</b>	Total hours of boiler operation (hours x 10) (LOW) (*).	1290	---	R/W	DWORD	---	h x 10	0.0 ... 429496729.5
	Total hours of boiler operation (hours x 10). (HIGH) (*).	1291	---	R/W	DWORD	---	h x 10	0.0 ... 429496729.5
<b>HoursEV1</b>	Hours of water inlet solenoid valve operation (hours x 10) (LOW) (*).	1292	---	R/W	DWORD	---	h x 10	0.0 ... 429496729.5
	Hours of water inlet solenoid valve operation (hours x 10) (HIGH) (*).	1293	---	R/W	DWORD	---	h x 10	0.0 ... 429496729.5
<b>HoursPump</b>	Hours of outlet pump operation (hours x 10) (LOW) (*).	1294	---	R/W	DWORD	---	h x 10	0.0 ... 429496729.5
	Hours of outlet pump operation (hours x 10). (HIGH) (*).	1295	---	R/W	DWORD	---	h x 10	0.0 ... 429496729.5
<b>HoursFan</b>	Hours of fan operation (hours x 10) (LOW) (*).	1296	---	R/W	DWORD	---	h x 10	0.0 ... 429496729.5
	Hours of fan operation (hours x 10). (HIGH) (*).	1297	---	R/W	DWORD	---	h x 10	0.0 ... 429496729.5
<b>curr100</b>	Nominal current.	1298	---	R/W	WORD	---	A	0.00...655.35
<b>tevap</b>	Evaporation time.	1299	---	R/W	WORD	---	s	0.0 ... 6553.5
<b>actProd</b>	Actual steam production.	1303	---	R/W	SHORT	Y	kg/h	-3276.8 ... 3276.7
<b>limH</b>	Humidity limit sensor status (ON/OFF).	1304	---	R/W	1 BIT	---	---	0/1

Code	Description	Val. Adr.	Filter value	R/W	DATA SIZE	CPL	MU	Range
<b>HoursAct</b>	Hours of continuous activity. (LOW) (*).	1316	---	R/W	DWORD	---	h x 10	0.0 ... 429496729.5
	Hours of continuous activity. (HIGH) (*).	1317	---	R/W	DWORD	---	h x 10	0.0 ... 429496729.5
<b>HoursNotAct</b>	Hours of continuous inactivity. (LOW) (*).	1318	---	R/W	DWORD	---	h x 10	0.0 ... 429496729.5
	Hours of continuous inactivity. (HIGH) (*).	1319	---	R/W	DWORD	---	h x 10	0.0 ... 429496729.5
<b>MBS_SwEn</b>	On/Off command from BMS.	1922	---	R/W	1 BIT	---	---	0/1

(\*) **Calculation of operating hours**

Operating hours = (HIGH register x 65536) + LOW register

## 12. DIAGNOSTICS

The table below lists alarms with corresponding solutions. Indication takes place via the alarm LED  and the buzzer. Each alarm is recorded in the alarm log.

### 12.1 Table of VEH alarms

Code	Description	Cause	Effects	Solution
<b>W01</b>	Warning: +30% overcurrent	<ul style="list-style-type: none"> <li>Overcurrent between the electrodes</li> <li>Electrodes not working or shorted</li> </ul>	<ul style="list-style-type: none"> <li>Fixed alarm icon</li> <li><b>W01</b> displayed</li> <li>Partial draining</li> <li><b>W01</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>Carry out maintenance</li> <li>Replace the boiler</li> <li>Check that the outlet pump is working</li> </ul>
<b>AL01</b>	Alarm: +50% overcurrent	<ul style="list-style-type: none"> <li>Current sensor not working</li> <li>Control board not working</li> <li>Boiler compromised</li> <li>High electrical conductivity</li> <li>Use softened water</li> </ul>	<ul style="list-style-type: none"> <li>Fixed alarm icon</li> <li><b>AL01</b> displayed</li> <li>Humidifier OFF</li> <li><b>AL01</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>Check that the TA is working (if external)</li> <li>Check the water properties</li> </ul>
<b>W02</b>	Warning: no production	<ul style="list-style-type: none"> <li>Foam in the boiler</li> <li>Water inlet flow rate too low</li> <li>Boiler failing</li> </ul>	<ul style="list-style-type: none"> <li>Fixed alarm icon</li> <li><b>W02</b> displayed</li> <li>No effect on regulation</li> <li><b>W02</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>Check the water mains flow rate</li> <li>Check that the solenoid valve is working</li> </ul>
<b>AL02</b>	Alarm: no production	<ul style="list-style-type: none"> <li>Water pipes or filter clogged</li> <li>Backpressure at the steam outlet is greater than rated value</li> <li>Very low electrical conductivity</li> <li>No production for a long time</li> </ul>	<ul style="list-style-type: none"> <li>Fixed alarm icon</li> <li><b>AL02</b> displayed</li> <li>Alarm relay ON</li> <li>Humidifier OFF if <b>AL02</b> &gt; 100 h</li> <li><b>AL02</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>Carry out maintenance on the solenoid valve</li> <li>Replace the solenoid valve</li> <li>Check for foam</li> <li>Check the backpressure in the steam outlet duct</li> </ul>
<b>AL03</b>	No water alarm	<ul style="list-style-type: none"> <li>Water fill time &gt; <b>c10</b></li> <li>Inlet filter clogged</li> <li>Solenoid valve not working</li> <li>Water pressure too low</li> <li>Water inlet circuit leaking</li> </ul>	<ul style="list-style-type: none"> <li>Fixed alarm icon</li> <li><b>AL03</b> displayed</li> <li>Humidifier inhibited for 15 minutes</li> <li><b>AL03</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>Check the water mains flow rate</li> <li>Check that the solenoid valve is working</li> <li>Carry out maintenance on the solenoid valve</li> <li>Replace the solenoid valve</li> <li>Check and clean the internal pipes and inlet/outlet manifold</li> <li>Cleaning the boiler</li> <li>Replace the boiler (if there is significant limescale residue)</li> </ul>
<b>W04</b>	Warning: insufficient draining	<ul style="list-style-type: none"> <li>Insufficient water drained</li> <li>Water inlet/outlet clogged</li> </ul>	<ul style="list-style-type: none"> <li>Fixed alarm icon</li> <li><b>W04</b> displayed</li> <li>Alarm relay ON</li> <li><b>W04</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>Cleaning the boiler</li> <li>Replace the boiler (if there is significant limescale residue)</li> <li>Clean the pump, outlet manifold and outlet circuit</li> <li>Replace the outlet pump if it is not working</li> </ul>
<b>W05</b>	Warning: foam	The water in the boiler reaches the maximum level sensor	<ul style="list-style-type: none"> <li>Fixed alarm icon</li> <li><b>W05</b> displayed</li> <li>Anti-foam washing activated</li> <li><b>W05</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>Automatic reset</li> <li>If it persists over time, disconnect the humidifier water connections and let the water drain, then wash and clean the boiler</li> <li>Check if the filling water is softened</li> </ul>
<b>W06</b>	Warning: suspected high electrical conductivity	<ul style="list-style-type: none"> <li>High current</li> <li>Low filling frequency</li> </ul>	<ul style="list-style-type: none"> <li>Fixed alarm icon</li> <li><b>W06</b> displayed</li> <li>Automatic washing activated</li> <li><b>W06</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>Carry out maintenance</li> <li>Check the inlet water properties</li> </ul>
<b>AL07</b>	Alarm: machine service life	Hours of unit operation > <b>M10</b>	<ul style="list-style-type: none"> <li>Fixed alarm icon</li> <li><b>AL07</b> displayed</li> <li>Alarm relay ON</li> <li><b>AL07</b> recorded in the log</li> </ul>	Carry out full maintenance

Code	Description	Cause	Effects	Solution
<b>W08</b>	Warning: boiler maintenance	Hours of boiler operation > <b>M11</b>	<ul style="list-style-type: none"> <li>Fixed alarm icon</li> <li><b>W08</b> displayed</li> <li>Alarm relay ON</li> <li><b>W08</b> recorded in the log</li> </ul>	Clean the boiler
<b>AL08</b>	Alarm: boiler service life	Hours of boiler operation > <b>M12</b>	<ul style="list-style-type: none"> <li>Fixed alarm icon</li> <li><b>AL08</b> displayed</li> <li>Alarm relay ON</li> <li>Humidifier OFF</li> <li><b>AL08</b> recorded in the log</li> </ul>	Replace the boiler
<b>AL09</b>	Alarm: solenoid valve maintenance	Hours of solenoid valve operation > <b>M13</b>	<ul style="list-style-type: none"> <li>Fixed alarm icon</li> <li><b>AL09</b> displayed</li> <li>No effect on regulation</li> <li><b>AL09</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>Clean the water inlet filter</li> <li>Check for leaks</li> <li>Replace the inlet solenoid valve if necessary</li> <li>Reset the counter</li> </ul>
<b>AL10</b>	Alarm: pump maintenance	Hours of pump operation > <b>M14</b>	<ul style="list-style-type: none"> <li>Fixed alarm icon</li> <li><b>AL10</b> displayed</li> <li>No effect on regulation</li> <li><b>AL10</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>Clean the pump and the inlet and outlet manifold</li> <li>Clean the inlet/outlet circuit</li> <li>Check for leaks</li> <li>Replace the outlet pump if necessary</li> <li>Reset the counter</li> </ul>
<b>AL11</b>	Alarm: fan maintenance	Hours of fan operation > <b>M15</b>	<ul style="list-style-type: none"> <li>Fixed alarm icon</li> <li><b>AL11</b> displayed</li> <li>No effect on regulation</li> <li><b>AL11</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>Clean the fans and grilles</li> <li>Remove residues and dust incrustations</li> <li>Replace any fans that are not working</li> <li>Reset the counter</li> </ul>
<b>W12</b>	Warning: low humidity	Humidity production < <b>M5</b> for a time > <b>M7</b>	<ul style="list-style-type: none"> <li>Fixed alarm icon</li> <li><b>W12</b> displayed</li> <li>Alarm relay ON</li> <li><b>W12</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>If it occurs together with other alarms, check accordingly</li> <li>If the humidifier is underdimensioned, contact the system designer</li> <li>Check <b>R6</b> and set it &gt; 70%</li> </ul>
<b>W13</b>	Warning: high humidity	Humidity production > <b>M6</b> for a time > <b>M7</b>	<ul style="list-style-type: none"> <li>Fixed alarm icon</li> <li><b>W13</b> displayed</li> <li>Alarm relay ON</li> <li><b>W13</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>If it occurs together with other alarms, check accordingly</li> <li>If the humidifier is overdimensioned, contact the system designer</li> <li>Check <b>R6</b> and set it &lt; 70%</li> </ul>
<b>AL14</b>	Alarm: temperature sensor <b>S1</b>	<ul style="list-style-type: none"> <li>Probe not working</li> <li>Probe not connected properly</li> <li>Incorrect probe type</li> </ul>	<ul style="list-style-type: none"> <li>Fixed alarm icon</li> <li><b>AL14</b> displayed</li> <li>Humidifier OFF</li> <li><b>AL14</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>Check the sensor type</li> <li>Check the sensor wiring</li> <li>Change the sensor type</li> <li>Check for electrical noise</li> </ul>

Code	Description	Cause	Effects	Solution
<b>AL15</b>	Alarm: humidity sensor <b>S2</b>	<ul style="list-style-type: none"> <li>• Sensor not working</li> <li>• Sensor not connected correctly</li> <li>• Control board not working</li> </ul>	<ul style="list-style-type: none"> <li>• Fixed alarm icon</li> <li>• <b>AL15</b> displayed</li> <li>• Alarm relay ON</li> <li>• Humidifier OFF</li> <li>• <b>AL15</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>• Check the sensor type (<b>P2</b>)</li> <li>• Check the sensor wiring</li> <li>• Change the sensor type</li> <li>• Check for electrical noise</li> </ul>
<b>AL16</b>	Alarm: humidity limit sensor <b>S3</b>		<ul style="list-style-type: none"> <li>• Fixed alarm icon</li> <li>• <b>AL16</b> displayed</li> <li>• Alarm relay ON</li> <li>• Humidifier OFF</li> <li>• <b>AL16</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>• Check the sensor type (<b>P7</b>)</li> <li>• Check the sensor wiring</li> <li>• Change the sensor type</li> <li>• Check for electrical noise</li> </ul>
<b>AL17</b>	Alarm: proportional request from regulator		<ul style="list-style-type: none"> <li>• Fixed alarm icon</li> <li>• <b>AL17</b> displayed</li> <li>• Alarm relay ON</li> <li>• Humidifier OFF</li> <li>• <b>AL17</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>• Check the regulator wiring</li> <li>• Check the regulator type</li> </ul>
<b>AL18</b>	Alarm: current sensor <b>CT</b>		<ul style="list-style-type: none"> <li>• Fixed alarm icon</li> <li>• <b>AL18</b> displayed</li> <li>• Alarm relay ON</li> <li>• Humidifier OFF</li> <li>• <b>AL18</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>• Check for water leaks</li> <li>• Check the electrical phase wiring on the boiler and contactor</li> <li>• Check that the TA is working</li> <li>• If the control board or current sensor are not working, replace the control board</li> </ul>
<b>AL19</b>	Alarm: temperature sensor 1	<ul style="list-style-type: none"> <li>• Probe not working</li> <li>• Probe not connected properly</li> <li>• Incorrect probe type</li> </ul>	<ul style="list-style-type: none"> <li>• Fixed alarm icon</li> <li>• <b>AL19</b> displayed</li> <li>• Alarm relay ON</li> <li>• Humidifier OFF</li> <li>• <b>AL19</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>• Check the sensor type</li> <li>• Check the sensor wiring</li> <li>• Change the sensor type</li> <li>• Check for electrical noise</li> </ul>
<b>AL20</b>	Alarm: temperature sensor 2		<ul style="list-style-type: none"> <li>• Fixed alarm icon</li> <li>• <b>AL20</b> displayed</li> <li>• Alarm relay ON</li> <li>• Humidifier OFF</li> <li>• <b>AL20</b> recorded in the log</li> </ul>	
<b>AL21</b>	Alarm: hydraulic unit 2 current sensor	<ul style="list-style-type: none"> <li>• Phase via sensor disconnected</li> <li>• Control board not working</li> <li>• Current sensor not working</li> <li>• Inlet solenoid valve not working</li> <li>• Possible water leakage</li> </ul>	<ul style="list-style-type: none"> <li>• Fixed alarm icon</li> <li>• <b>AL21</b> displayed</li> <li>• Alarm relay ON</li> <li>• Humidifier OFF</li> <li>• <b>AL21</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>• Check for water leaks</li> <li>• Check the electrical phase wiring on the hydraulic unit and contactor</li> <li>• Check that <b>TA 2</b> is working</li> <li>• If the control board or current sensor are not working, replace the control board</li> </ul>
<b>AL22</b>	Alarm: high temperature in wellness room	Wellness room temperature > <b>M20</b>	<ul style="list-style-type: none"> <li>• Fixed alarm icon</li> <li>• <b>AL22</b> displayed</li> <li>• Alarm relay ON</li> <li>• Humidifier OFF</li> <li>• <b>AL22</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>• Wait until room temperature &lt; <b>M20</b> - 3 °C</li> <li>• Check and eliminate the cause of wellness room temperature &gt; <b>M20</b></li> </ul>
<b>AL23</b>	Alarm: hydraulic unit 2 expansion board offline	No communication between control board and expansion device	<ul style="list-style-type: none"> <li>• <b>AL23</b> displayed</li> <li>• Alarm relay ON</li> <li>• All regulators for the second boiler are switched off</li> <li>• <b>AL23</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>• Restore communication between control board and expansion device</li> <li>• Automatic reset</li> </ul>
<b>AL24</b>	Alarm master offline (only on slave)	No communication between slave humidifier and master humidifier when nTyP ≠ 0	<ul style="list-style-type: none"> <li>• <b>AL24</b> displayed</li> <li>• Alarm relay ON</li> <li>• All regulators related to the Master humidifier are switched off (slaves operate as stand-alone)</li> <li>• <b>AL24</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>• Restore communication between slave humidifier and master humidifier</li> <li>• Automatic reset</li> </ul>

Code	Description	Cause	Effects	Solution
<b>AL25</b>	Alarm: slave 1 offline or alarmed (only on master)	<ul style="list-style-type: none"> <li>No communication between master humidifier and slave 1 humidifier when <b>nTyP</b> ≠ 0</li> <li>Slave 1 alarmed with regulation block</li> </ul>	<ul style="list-style-type: none"> <li><b>AL25</b> displayed</li> <li>Alarm relay ON</li> <li>Slave 1 OFF, other humidifiers operate normally</li> <li><b>AL25</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>Restore communication between master humidifier and slave 1 humidifier</li> <li>Automatic reset</li> </ul>
<b>AL26</b>	Alarm: slave 2 offline or alarmed (only on master)	<ul style="list-style-type: none"> <li>No communication between master humidifier and slave 2 humidifier when <b>nTyP</b> ≠ 0</li> <li>Slave 2 alarmed with regulation block</li> </ul>	<ul style="list-style-type: none"> <li><b>AL26</b> displayed</li> <li>Alarm relay ON</li> <li>Slave 2 OFF, other humidifiers operate normally</li> <li><b>AL26</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>Restore communication between master humidifier and slave 2 humidifier</li> <li>Automatic reset</li> </ul>
<b>AL27</b>	Alarm: slave 3 offline or alarmed (only on master)	<ul style="list-style-type: none"> <li>No communication between master humidifier and slave 3 humidifier when <b>nTyP</b> ≠ 0</li> <li>Slave 3 alarmed with regulation block</li> </ul>	<ul style="list-style-type: none"> <li><b>AL27</b> displayed</li> <li>Alarm relay ON</li> <li>Slave 3 OFF, other humidifiers operate normally</li> <li><b>AL27</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>Restore communication between master humidifier and slave 3 humidifier</li> <li>Automatic reset</li> </ul>
<b>AL28</b>	Alarm: slave 4 offline or alarmed (only on master)	<ul style="list-style-type: none"> <li>No communication between master humidifier and slave 4 humidifier when <b>nTyP</b> ≠ 0</li> <li>Slave 3 alarmed with regulation block</li> </ul>	<ul style="list-style-type: none"> <li><b>AL28</b> displayed</li> <li>Alarm relay ON</li> <li>Slave 4 OFF, other humidifiers operate normally</li> <li><b>AL28</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>Restore communication between master humidifier and slave 4 humidifier</li> <li>Automatic reset</li> </ul>
<b>W29</b>	Warning: +30% overcurrent in hydraulic unit 2	<ul style="list-style-type: none"> <li>Overcurrent between the electrodes</li> <li>Electrodes not working or shorted</li> <li>Current sensor not working</li> </ul>	<ul style="list-style-type: none"> <li>Fixed alarm icon</li> <li><b>W29</b> displayed</li> <li>Partial draining</li> <li><b>W29</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>Carry out maintenance</li> <li>Replace hydraulic unit 2</li> <li>Check that the outlet pump for hydraulic unit 2 is working</li> <li>Check that the TA is working (if external)</li> <li>Check the water properties</li> </ul>
<b>AL29</b>	Alarm: +50% overcurrent in hydraulic unit 2	<ul style="list-style-type: none"> <li>Control board not working</li> <li>Boiler compromised</li> <li>High electrical conductivity</li> <li>Use softened water</li> </ul>	<ul style="list-style-type: none"> <li>Fixed alarm icon</li> <li><b>AL29</b> displayed</li> <li>Humidifier OFF</li> <li><b>AL29</b> recorded in the log</li> </ul>	
<b>W30</b>	Warning: no production from hydraulic unit 2	<ul style="list-style-type: none"> <li>Foam in hydraulic unit 2</li> <li>Water inlet flow rate too low</li> <li>Hydraulic unit 2 failing</li> </ul>	<ul style="list-style-type: none"> <li>Fixed alarm icon</li> <li><b>W30</b> displayed</li> <li>No effect on regulation</li> <li><b>W30</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>Check the water mains flow rate</li> <li>Check that the solenoid valve is working in hydraulic unit 2</li> <li>Carry out maintenance on the solenoid valve in hydraulic unit 2</li> <li>Replace the solenoid valve</li> <li>Check for foam</li> <li>Check the backpressure in the steam outlet duct</li> </ul>
<b>AL30</b>	Alarm: no production from hydraulic unit 2	<ul style="list-style-type: none"> <li>Water pipes or filter clogged</li> <li>Backpressure at the steam outlet is greater than rated value</li> <li>Very low electrical conductivity</li> <li>No production for a long time</li> </ul>	<ul style="list-style-type: none"> <li>Fixed alarm icon</li> <li><b>AL30</b> displayed</li> <li>Alarm relay ON</li> <li>Humidifier OFF if <b>AL30</b> &gt; 100 h</li> <li><b>AL30</b> recorded in the log</li> </ul>	
<b>AL31</b>	Alarm: no water in hydraulic unit 2	<ul style="list-style-type: none"> <li>Water fill time &gt; <b>c10</b></li> <li>Inlet filter clogged</li> <li>Solenoid valve not working</li> <li>Water pressure too low</li> <li>Water inlet circuit leaking</li> </ul>	<ul style="list-style-type: none"> <li>Fixed alarm icon</li> <li><b>AL31</b> displayed</li> <li>Humidifier inhibited for 15 minutes</li> <li><b>AL31</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>Check the water mains flow rate</li> <li>Check that the solenoid valve is working in hydraulic unit 2</li> <li>Carry out maintenance on the solenoid valve in hydraulic unit 2</li> <li>Replace the solenoid valve</li> <li>Check and clean the internal pipes and inlet/outlet manifold</li> <li>Clean hydraulic unit 2</li> <li>Replace hydraulic unit 2 (if there is significant limescale residue)</li> </ul>
<b>W32</b>	Warning: insufficient draining from hydraulic unit 2	<ul style="list-style-type: none"> <li>Insufficient water drained</li> <li>Water inlet/outlet clogged</li> </ul>	<ul style="list-style-type: none"> <li>Fixed alarm icon</li> <li><b>W32</b> displayed</li> <li>Alarm relay ON</li> <li><b>W32</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>Clean hydraulic unit 2</li> <li>Replace hydraulic unit 2 (if there is significant limescale residue)</li> <li>Clean the pump, outlet manifold and outlet circuit</li> <li>Replace the outlet pump if it is not working</li> </ul>

Code	Description	Cause	Effects	Solution
<b>W33</b>	Warning: foam in hydraulic unit 2	The water in hydraulic unit 2 reaches the maximum level sensor	<ul style="list-style-type: none"> <li>• Fixed alarm icon</li> <li>• <b>W33</b> displayed</li> <li>• Anti-foam washing activated</li> <li>• <b>W33</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>• Automatic reset</li> <li>• If it persists over time, disconnect the humidifier water connections and let the water drain, then wash and clean the boiler</li> <li>• Check if the filling water is softened</li> </ul>
<b>W34</b>	Warning: suspected high electrical conductivity in hydraulic unit 2	<ul style="list-style-type: none"> <li>• High current</li> <li>• Low filling frequency</li> </ul>	<ul style="list-style-type: none"> <li>• Fixed alarm icon</li> <li>• <b>W34</b> displayed</li> <li>• Automatic washing activated</li> <li>• <b>W34</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>• Carry out maintenance</li> <li>• Check the inlet water properties</li> </ul>
<b>W35</b>	Warning: hydraulic unit 2 maintenance	Hours of hydraulic unit 2 operation > <b>M11</b>	<ul style="list-style-type: none"> <li>• Fixed alarm icon</li> <li>• <b>W35</b> displayed</li> <li>• Alarm relay ON</li> <li>• <b>W35</b> recorded in the log</li> </ul>	Clean the boiler
<b>AL35</b>	Alarm: hydraulic unit 2 service life	Hours of hydraulic unit 2 operation > <b>M12</b>	<ul style="list-style-type: none"> <li>• Fixed alarm icon</li> <li>• <b>AL35</b> displayed</li> <li>• Alarm relay ON</li> <li>• Humidifier OFF</li> <li>• <b>AL35</b> recorded in the log</li> </ul>	Replace boiler 2
<b>AL36</b>	Alarm: hydraulic unit 2 solenoid valve maintenance	Hours of hydraulic unit 2 solenoid valve operation > <b>M13</b>	<ul style="list-style-type: none"> <li>• Fixed alarm icon</li> <li>• <b>AL36</b> displayed</li> <li>• No effect on regulation</li> <li>• <b>AL36</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>• Clean the water inlet filter</li> <li>• Check for leaks</li> <li>• Replace the inlet solenoid valve if necessary</li> <li>• Reset the counter</li> </ul>
<b>AL37</b>	Alarm: hydraulic unit 2 pump maintenance	Hours of hydraulic unit 2 pump operation > <b>M14</b>	<ul style="list-style-type: none"> <li>• Fixed alarm icon</li> <li>• <b>AL37</b> displayed</li> <li>• No effect on regulation</li> <li>• <b>AL37</b> recorded in the log</li> </ul>	<ul style="list-style-type: none"> <li>• Clean the pump and the inlet and outlet manifold</li> <li>• Clean the inlet/outlet circuit</li> <li>• Check for leaks</li> <li>• Replace the outlet pump if necessary</li> <li>• Reset the counter</li> </ul>

# 13. MAINTENANCE

VEH OEM series humidifiers are defined as "NOT ACCESSIBLE TO THE PUBLIC".

## DANGER

### RISK OF ELECTRIC SHOCK, EXPLOSION OR ELECTRIC ARC

- Any procedure on the humidifier, including maintenance of any type, must only be carried out while the power supply is disconnected.
- The maintenance, repair, installation and use of the equipment must only be entrusted to qualified personnel.

## WARNING

### RISK OF BURNS

Before carrying out any work on the system, place the equipment out of service and wait for the machine to cool down (< 50 °C (122 °F)).

## 13.1 Introduction

VEH series humidifiers are designed for operation with the water specifications indicated in sub-section "5.2.1 WATER SPECIFICATIONS" ON PAGE 23.

Using water with different specifications and/or with a hardness level approaching the limit of 50 °f causes maintenance to be required more frequently.

As a guideline, the hydraulic unit requires frequent maintenance and seasonal cleaning in the following conditions:

Water conductivity	Water hardness
200...600 µS/cm	10...30 °f

It is not possible to provide certain instructions to determine the maintenance frequency, as it depends heavily on the morphology of the water used, which can also vary under equal specifications (conductivity and hardness).

If using VEH series humidifiers with more critical water conditions, for example:

Water conductivity	Water hardness
700...1250 µS/cm	35...50 °f

maintenance must be carried out more frequently, several time per season (even weekly in extreme cases).

## NOTICE

### MALFUNCTIONING OF THE EQUIPMENT

Only use the humidifier with the water specifications indicated in this manual.

If frequent maintenance takes place, check the quality of the water supply.

Furthermore, the hydraulic unit should be cleaned promptly when:

- The drain water is very dark (reddish/black) and demonstrates the start of electrode corrosion (\*) caused by the highly aggressive nature of concentrated water (replace the electrodes if necessary);
- The humidifier does not work properly, triggering the high current alarm frequently.  
**NOTE:** a high concentration of salts in the water inside the boiler results in high electrical conductivity, which can cause various high current alarms and lead to frequent drain cycles;
- The hydraulic unit has reached 5 seasons or 24 months of continuous operation with maintenance performed in accordance with best practices;
- There are large amounts of limescale linked to variations in colour and surface on the outer walls of the hydraulic unit, due to overheating caused by limescale bridges between the electrical phases (replace the electrodes if necessary);  
**NOTE:** Limescale inside the boiler is normal, even in large amounts, as the boiler collects the limescale present in the water; therefore performing maintenance/cleaning on it is essential for correct operation.

## NOTICE

### MALFUNCTIONING OF THE EQUIPMENT

Only carry out boiler maintenance in accordance with the instructions provided in the Maintenance section of this manual.

(\*): The electrodes are made using AISI 316 steel with self-extinguishing engineering plastic parts.

- There are leaks due to breakages, cracks and fissures (**replace the hydraulic unit**).  
**NOTE:** the water inside the boiler is subjected to electrical voltage and therefore leaks from the boiler are dangerous.

  **DANGER**

**RISK OF ELECTRIC SHOCK OR ELECTRIC ARC**

- Any procedure on the humidifier, including maintenance of any type, must only be carried out while the power supply is disconnected.
- In the event of water leakage, disconnect the humidifier power supply immediately.

- If any adverse event not described in this documentation arises, carry out maintenance and/or replace the hydraulic unit. Plus, contact ELSTEAM customer service for the relevant guidelines and instructions;

  **DANGER**

**RISK OF ELECTRIC SHOCK, EXPLOSION OR ELECTRIC ARC**

If an adverse event occurs, disconnect the humidifier power supply immediately.

- After a period of activity and/or due to water specifications, because of the formation of limescale inside the boiler, the electrodes may come closer together and/or closer to the walls of the boiler, forming potential electrical conductors which, in the absence of water, may lead to an increase in temperature (causing the surfaces of the boiler to become black) and cause the boiler wall to melt, leading to the leakage of live water (**replace the hydraulic unit**);

  **DANGER**

**RISK OF ELECTRIC SHOCK OR ELECTRIC ARC**

- In the event of water leakage, disconnect the humidifier power supply immediately.
- Check and, if necessary, replace the hydraulic unit sealing gaskets.
- If the tank is compromised, replace the entire hydraulic unit.

**Checking the status of the humidifier**

Perform the following scheduled checks on the humidifier:

When...	What to do...
At first start-up	Make sure there are no leaks after an hour of continuous operation.
When changing parts	Make sure there are no leaks after an hour of continuous operation.
Every 5 days	<ul style="list-style-type: none"><li>• Make sure the humidifier works properly (based on the instructions provided in this manual);</li><li>• Make sure there are no leaks in the hydraulic system;</li><li>• Make sure there is no unusual operation.</li></ul>
Every 30 days	<ul style="list-style-type: none"><li>• Make sure there are no blockages in the water drain;</li><li>• Make sure the water drains effectively;</li><li>• Remove any limescale residue from inside the drain.</li></ul>
Every 60 days	<ul style="list-style-type: none"><li>• Make sure not too much limescale residue has built up inside the hydraulic unit;</li><li>• Wash the inside of the boiler with a 20% concentration of citric acid, removing limescale from the electrodes and boiler.</li><li>• If necessary, replace the electrodes and gaskets.</li></ul>
Every 2 years (*)	Replace the hydraulic unit.
Every 5 years (**)	Replace the hydraulic unit.

(\*) **NOTE:** If humidifier used continuously.

(\*\*) **NOTE:** If humidifier used seasonally.

Inadequate use and/or poor maintenance of the humidifier can damage your health.

  **WARNING**

**BIOLOGICAL RISK**

- In the event of poor maintenance/cleaning after the humidifier has been shut-down for a long time, microorganisms (including the bacteria that cause Legionellosis) may proliferate and be transferred into the air treatment system.
- The humidifier must be used properly and be maintained and cleaned properly at prescribed intervals, as described in the **MAINTENANCE** chapter.

Thoroughly remove limescale and biofilm residues from the reservoir and drain (rinse the inside of the reservoir with 20% citric acid and appropriate biocides, and clean the limescale off the surface).

## NOTICE

### MALFUNCTIONING OF THE EQUIPMENT

Replace the sealing gaskets every time the hydraulic unit is serviced.

### 13.2 Regular cleaning of the product and its components

- Drain the humidifier, following the instruction provided in section **"9.8 OPERATING HOURS" ON PAGE 49**;
- Disconnect the machine power supply using the external isolator;
- Open the AHU and approach the hydraulic unit, removing the tank covers from the unit as described in paragraph **"13.3 CLEANING THE TANK" ON PAGE 68**;
- Unscrew the manifold from the filling/discharge unit;
- Remove any pieces of limescale;
- Disconnect the inlet solenoid valve, remove the filter at the bottom and thoroughly clean it again;
- Reassemble the inlet solenoid valve;
- Re-attach the filling/discharge unit manifold.

### 13.3 Cleaning the tank

- Drain the humidifier;
- Disconnect the machine power supply using the external isolator;
- Use the 2 screws at the front to disconnect the filling/discharge manifold from the front of the hydraulic unit;
- Loosen the 4 screws on the sides of the top cover and remove the 2 covers;
- Open the top of the tank inside the AHU;
- Gently lift the hydraulic unit until any remaining water has drained out;
- Wash the hydraulic unit tank using a citric acid solution and detach any limescale from the surfaces of the electrodes using a plastic spatula.
- Fully reassemble the hydraulic unit.

### 13.4 Cleaning the optional STAINLESS STEEL discharge tank (VI accessory)

- Remove the tank connection from the drain;
- Remove the tank from the bottom of the humidifier;
- Clean the tank by removing limescale deposits and rinsing it under running water;
- Re-fit the tank correctly and reconnect the drain.

### 13.5 Replacing the electrodes

- Drain the humidifier;
- Disconnect the machine power supply using the external isolator;
- Use the 2 screws at the front to disconnect the filling/discharge manifold from the front of the hydraulic unit;
- Loosen the 4 screws on the sides of the top cover and remove the 2 covers;
- Open the top of the tank inside the AHU;
- Unscrew the nuts securing the electrodes, lift them from the part opposite the connections and slide them out of the connection slot;
- Insert the new electrodes, reversing the disassembly instructions;
- Secure the electrodes in their seat, making sure they are well fastened and that the O-RING seals are positioned correctly;
- Close the top of the tank inside the AHU;
- Reconnect the electrical cables using flanged nuts and special Nord Lock washers, making sure connection takes place in accordance with best practices and current regulations.



### LOOSE WIRING CAUSES ELECTRIC SHOCKS AND OVERHEATING

Tighten the connections in compliance with the technical specifications relating to tightening torques.

Tightening torque between nut and locknut, for the ring terminal: 4 Nm.

# 14. SPARE PARTS

## 14.1 Hydraulic unit




Fig. 51. Spare parts for VEH OEM - Hydraulic unit

Ref.	P/n	Description
1	EHKD0K01	VEH OEM water inlet/outlet manifold unit
2	EHKT0K02	VEH OEM filling solenoid valve
3	EHKT0K04	VEH OEM electric outlet pump
4	EHKD0K02	Electrode kit for VEH OEM 10XS/VHE OEM 20XS
	EHKD0K03	Electrode kit for VEH OEM 20S/VEH OEM 30S/VEH OEM 40S
	EHKD0K04	Electrode kit for VEH OEM 30M/VEH OEM 60M
	EHKD0K05	Electrode kit for VEH OEM 40L/VEH OEM 80L
5	EHKD0K06	Electrode kit for VEH OEM 60XL/VEH OEM 100XL
	EHKD0K07	VEH OEM hydraulic unit gasket kit
6	EHKD0K08	Power cable kit from electric panel to hydraulic unit for VEH OEM 10-20-30-40
	EHKD0K09	Power cable kit from electric panel to hydraulic unit for VEH OEM 60-80-100

## 14.2 Electrical part




Fig. 52. Electrical spare parts: **VEH OEM**

Ref.	P/n	Description
①	<b>EHHKT001P4</b>	Complete control unit
②	<b>EHHKX002E4</b>	Control unit expansion for dual-hydraulic unit version
③	<b>EHK TOK76</b>	Fuse kit for <b>VEH OEM 10</b> , gG10x38 16 A
	<b>EHK TOK77</b>	Fuse kit for <b>VEH OEM 20</b> , gG10x38 32 A
	<b>VEHK20</b>	Fuse kit for <b>VEH OEM 30</b> , gG14x51 40 A
	<b>EHK TOK78</b>	Fuse kit for <b>VEH OEM 40</b> , gG14x51 50 A
	<b>VEHK22</b>	Fuse kit for <b>VEH OEM 60</b> , gG22x58 80 A
	<b>EHK TOK79</b>	Fuse kit for <b>VEH OEM 80</b> , gG22x58 100 A
	<b>EHK TOK80</b>	Fuse kit for <b>VEH OEM 100</b> , gG22x58 125A
④	<b>0103349007</b>	TA current sensor
⑤	<b>EHKDOK28</b>	1 m power cable kit for <b>VEH OEM 10-20-30</b>
	<b>EHKOD29</b>	1 m power cable kit for <b>VEH OEM 40-60-80</b>
	<b>EHKOD30</b>	1 m power cable kit for <b>VEH OEM 100</b>
	<b>EHKDOK08</b>	3 m power cable kit for <b>VEH OEM 10-20-30-40</b>
	<b>EHKDOK09</b>	3 m power cable kit for <b>VEH OEM 60</b>
	<b>EHKDOK10</b>	3 m power cable kit for <b>VEH OEM 80-100</b>
	<b>EHKDOK17</b>	5 m power cable kit for <b>VEH OEM 10-20-30-40</b>
	<b>EHKDOK18</b>	5 m power cable kit for <b>VEH OEM 80-100</b>
<b>EHKDOK19</b>	5 m power cable kit for <b>VEH OEM 60</b>	
---	<b>0101014020</b>	<b>(Optional)</b> 400 Vac transformer for <b>VEH OEM</b> models
---	<b>0209310001</b>	<b>(Optional)</b> Contactor for <b>VEH OEM 10</b> models
	<b>0209310002</b>	<b>(Optional)</b> Contactor for <b>VEH OEM 20</b> models
	<b>0209310003</b>	<b>(Optional)</b> Contactor for <b>VEH OEM 30</b> models
	<b>0209310005</b>	<b>(Optional)</b> Contactor for <b>VEH OEM 40</b> models
	<b>0209310004</b>	<b>(Optional)</b> Contactor for <b>VEH OEM 60</b> models
	<b>0209710007</b>	<b>(Optional)</b> Contactor for <b>VEH OEM 80</b> models
	<b>0209310006</b>	<b>(Optional)</b> Contactor for <b>VEH OEM 100</b> models

# 15. WIRING DIAGRAMS

## 15.1 VEH OEM humidifier (4 or 7 electrodes)




Fig. 53. Wiring diagram for 4- or 7-electrode models

## 15.2 VEH OEM dual hydraulic unit humidifier




Fig. 54. Wiring diagram for dual hydraulic unit humidifier


# 16. MODEL SELECTION AND DEFINITION

## 16.1 Introduction


The **Parameters Manager**, can be used to choose the desired humidifier model and configure the machine.

## 16.2 Procedure for selecting and defining the model

1. Run **Parameters Manager**;
2. Enter the **Parameters** sheet followed by the **Maintenance Parameters** section;




3. Enter the access password (32917) in the OEM Password field. The fields needed to access, select and define the model will then be displayed (wait 5 seconds to see them appear automatically);




These fields are:

- **CloneModeOEM**: allows the OEM user to enter the mode for selecting and defining the model;
- **Model To Write**: sets the code of the model to be entered;
- **Humidifier Model code**: Displays the p/n of the selected humidifier (read-only);
- **Humidifier Model production**: Displays the production capacity (in kg/h) of the selected humidifier (read-only);
- **Humidifier Model phases**: Displays the number of power supply phases for the selected humidifier (read-only);
- **Humidifier Model power supply**: Displays the power supply type for the selected humidifier (read-only);
- **Humidifier Model type**: Displays the selected humidifier series (read-only).

4. Set the **CloneModeOEM** field to 1; the board will enter the mode for selecting and defining the model.  
**NOTE:** Some parameters may have abnormal values. Do not edit these values.




5. Set the **Model To Write** field to the numerical code of the desired model (8 in the example);




Par.	Description	MU	Range
<b>Model To Write</b>	Humidifier model.	---	0...60
	<b>0...17 = RESERVED</b> <b>18 = EHKOD10T4XS</b> <b>19 = EHKOD20T4XS</b> <b>20 = EHKOD20T4S</b> <b>21 = RESERVED</b> <b>22 = EHKOD30T4M</b> <b>23 = EHKOD40T4S</b> <b>24 = EHKOD40T4L</b> <b>25 = EHKOD60T4M</b> <b>26 = EHKOD60T4XL</b> <b>27 = EHKOD80T4L</b>		

**NOTE:** Do not enter values marked as **RESERVED** in the table above.  
 (\*) double hydraulic unit

- Set the **CloneModeOEM** field to 0 to exit from the mode for selecting and defining the model;



- The procedure takes a few seconds to complete. Please wait.  
When the procedure is complete, the description of the configured model will appear in the **Humidifier Model** field.



- Procedure finished.

This document and the solutions contained within it are the intellectual property of ELSTEAM, safeguarded by the Italian Industrial Property Code (CPI). ELSTEAM forbids the reproduction and distribution, even in part, of the contents, unless express authorisation is obtained directly from ELSTEAM.

The customer (manufacturer, installer or end user) assumes all responsibility for device configuration.

ELSTEAM does not assume any responsibility for potential errors and reserves the right to make any changes, at any time, without the basic functional and safety-related features being affected.

## **MADE IN ITALY**

### **ELSTEAM S.r.l.**

Via Enrico Fermi 496, 21042,  
Caronno Pertusella (VA) ITALY

**Telephone:** +39 02 9659890

**Fax:** +39 02 96457007

**Email:** [info@elsteam.it](mailto:info@elsteam.it)

**Web:** [www.elsteam.com](http://www.elsteam.com)

