



# Top 7 Pro Tips for Prepping Any Surface for Epoxy Application

Ready to transform your space with flawless epoxy? Before you dive in, the secret to a stunning finish is all in the prep work. This quick guide reveals our top 7 tricks for prepping any surface like a pro. Whether you're a DIY newbie or a seasoned renovator, these engaging, witty tips will have you priming, sanding, and polishing your way to epoxy perfection in no time!

## 1. Clean Like You Mean It:

Start by banishing all dust, grease, and grime—your surface should be as clean as a whistle. Think of it as giving your space a spa day before the epoxy makeover!

## 2. Scrub-a-Dub-Dub:

Grab a stiff brush and a good degreaser. A thorough scrub removes old finishes and stubborn contaminants that could stand between your surface and a flawless bond.

## 3. Sand It Up:

Lightly sand your surface to create a texture that the epoxy can actually grab

onto. Consider it giving your floor a gentle, revitalizing massage that prepares it for its star role.

4. **Dust Busters, Unite:**

After sanding, vacuum and wipe away every speck of dust. This step is crucial—dust is the enemy of a smooth, lasting finish.

5. **Patch It Like a Pro:**

Fill in cracks and holes with a quality filler. Even the best epoxy can't work magic on a damaged surface, so get it fixed up first.

6. **Prime Time:**

If recommended, apply a primer to boost adhesion and performance. Think of it as laying the perfect foundation for your epoxy masterpiece.

7. **Trial Run:**

Always test a small, inconspicuous area first. It's like a dress rehearsal—ensuring everything looks and works perfectly before the main event.

**These tips will get your surface prepped and ready for an epoxy application that not only looks amazing but stands the test of time!**

