



SCREEN – CAMERA – SENSOR PROTECTANT WIPE

SHAKE WELL BEFORE USE

Application Instructions

1. Shake well before use
2. Make sure the surface is clean and dry. Clean surface with Isopropyl alcohol or window cleaner.
3. Make sure surfaces are cool and dry. Do not apply in direct sun or if the surface is above 85°F.
4. Apply 5-6 drops of CARBYNE ARMOR on a microfiber applicator.
5. Use a high-quality microfiber cloth to remove any excess and a second microfiber to buff. CARBYNE ARMOR does not need to be left on the surface to cure, so it should be removed within one minute of application. Check with an appropriate light source to ensure you have removed any residue.
6. Any missed spots can be taken care of by applying CARBYNE ARMOR to those areas and following the directions above.
7. Recommended to allow CARBYNE ARMOR to cure 1-3 hours prior to use.