



EXTERIOR PRODUCT  
SHAKE WELL BEFORE USE

## Application Instructions

1. Test the product on an inconspicuous area before applying.
2. Make sure the surface is clean and dry. You may want to use a clay block with appropriate cleaners or light buff with polishing compound prior to applying the SS #25.
3. Make sure surfaces are cool and dry. Do not apply in direct sun or if the surface is above 85°F.
4. Apply 10-12 drops on a microfiber applicator, apply the product evenly to a door panel or an area roughly 24"x24" with complete coverage and an even layer.
5. Use a high-quality microfiber cloth to remove any excess and a second microfiber to buff. SS #25 does not need to be left on the surface to cure, so it should be removed immediately. Check with an appropriate light source to ensure you have removed any residue.
6. Any missed spots can be taken care of by applying SS #25 to those areas and following the directions above.
7. Recommended to allow the SS #25 to cure 2-4 hours prior to rain exposure.