

Volvo P1800 Calibration Dial Template

On the Volvo P1800 the Tacho the dial is not fitted until the Tacho is in its case and at this stage the calibration button is not accessible. To enable calibration of this tacho please use the calibration dial template below:

Instructions for use:

1. Print out template full size and cut out along dotted lines
2. Slip over back of blue inner dial
3. Align 0 Rpm mark with needle rest position and inner solid circle line with inner dial
4. Fix template to back of inner dial with masking tape as shown in photo below.

