



LitCarbon

Emblem Installation Guide

1. Remove the old emblems using a thin plastic tool. For extra safety, use Painters Tape around the emblem to prevent scratching the hood/trunk.



2. Once the emblem is removed, depending on the model you have, there will either be two holes with plastic inserts or plastic pins sticking out. If there are holes with plastic inserts, you will need to remove them by screwing in a screw and pulling them outwards. If it has plastic pins sticking out, you will need to use a sharp blade to cut them off completely. Once the area is flat, clean the surface with rubbing alcohol to remove any dirt or grease.



3. Once the surface is clean, please use the thin 3M tape that is provided in the package, to cover the holes on the hood/trunk.



4. When the holes are covered, take the emblem and remove the red plastic tape from the 3M tape. Carefully align the emblems without touching the surface to make sure they are arranged properly. When they are aligned, firmly press them to the hood/trunk.

*Do not wash your car for at least 24h to let the emblems stick to the hood/trunk fully.

