



MOBILE MINIMALIST
wander more with less

Travel Trailer Setup

1. Survey site for obstructions, awning location and hookup locations (water, electrical, sewer)
2. Park trailer
3. Level left to right first (wheel leveler on low side, chock other side)
4. Disconnect trailer from vehicle (WDH is a Fastway e2)
 - a. Disconnect power cord from tow vehicle
 - b. Place blocks under tongue jack (shorter extension is more stable)
 - c. Raise vehicle with tongue jack to remove tension from WD bars and remove bars
 - d. Take vehicle down with tongue jack
 - e. Remove hitch pin and release hitch at ball and raise jack
 - f. Disconnect safety chains and emergency breakaway cable
 - g. Remove hitch and put on DIY hitch docking station and lock
 - h. Cover jack and lock hitch ball
5. Level trailer front to back using tongue jack
6. Lower stabilizers onto levelers with drill using socket attachment
7. Electrical hook-up
 - a. Turn off breaker at site electrical pedestal and connect surge guard at pedestal
 - b. Turn on breaker and check power supply on surge guard
 - c. Connect electrical cord to trailer
 - d. Turn off breaker at pedestal and plug power cord into surge protector
 - e. Turn on breaker and check power in trailer using plug-in voltage meter
 - f. Coil excess cord under trailer
8. Check AC and refrigerator (set on auto)
9. Turn propane on at tank/s
10. Water hook-up
 - a. Spray disinfectant at site water pedestal
 - b. Test water pressure with gauge
 - c. Attach water pressure regulator at spigot with pliers (set to PSI @ 40)
 - d. Attach Y-splitter to regulator and attach potable water hose to one side (other side is for tank flush hose when breaking down)
 - e. Connect 90-degree elbow with filter connected at trailer city water connection
 - f. Connect hose shut-off to filter base and then hose to shut-off
 - g. Turn on water at spigot and purge air from hose at open side of Y-splitter
 - h. Turn on water at hose shut-off and 90-degree elbow
 - i. Check for leaks at spigot and trailer
 - j. Purge air out of water line by turning on cold water at sink
 - k. Turn on water heater and turn on hot water at sink until there is no air
11. Sewer hook-up (keep black and grey valves closed until ready to flush)
 - a. Put on gloves
 - b. Double check valves at trailer are closed and remove trailer drain cap
 - c. Connect flush king to trailer and sewer hose to flush king
 - d. Insert sewer adapter into site sewer connection and insert 90-degree sewer elbow into sewer adapter
12. Open awning (do not overextend or open in wind or rain)