

Instruction sheet ST001



Use PVA glue



Using glue is optional



Do not use glue

PVA Glue should be used sparingly. Beading should be avoided. Apply glue using a brush.

Give the glue 1 hour time to dry after completing step 1.



