

Voice control system

Function	Commands for user	broadcast words
To turn OFF voice control	Close voice	OK
TO turn ON voice control	open voice	OK
Wake up the desk	Hello Desk	Hello
Custom wake-up words (You can modify the voice wake-up words according to the command words and broadcast words on the right)	Changing the wake word	Please set the wake word in a quite environment
	I want to delete	Do you need to delete the learning wake up words
	Delete wake word	The wake word has been deleted for you,deletion sucecced
	Exit delete	OK.Exit deletion mode
	Quit learning	OK.Quit learning mode
	Again learning	Please set the wake word in a quite environment
Voice volume adjustment	Turn up the volume	Volume increased
	Turn down the volume	Volume reduced
Up and down the desk	Raise the table/Raise the desk/Turn the desk up	OK
	Lower the table/Lower the desk/Turn the desk down	
	Desk stop/Table stop/ Stop stop	
Adjust to a specific height	Adjust height desk	
		please tell me height
	40-150	
		OK
Memory position	Save to Position 1-4/Hold to position 1-4	OK
	Run to position 1-4/Go to position 1-4	
Lock and unlock the desk	Lock the desk/Lock the table	OK
	Unlock the desk/Unlock the table	
Metric or British display	Metric display/Set to Metric	OK
	British display/Set to British	
	Change unit/Turn the unit	
Limit	Set the high limit/Save the high limit	OK
	Set the low limit/Save the low limit	
	Cancel the high limit/Close the high limit	
	Cancel the low limit/Close the low limit	
	Cancel the limit/Close the limit	
WIFI function	Open WIFI/Connect WIFI	OK
	Close WIFI/Disconnect WIFI	
	Reset WIFI	