

AUTO TAPE DISPENSER — INSTRUCTION MANUAL

Model: T5165AB

Thank you very much for purchasing this smart tape dispenser.

To help you better understand and use the product, please read this manual carefully before use.

How to Use

1. Insert the tape into the dispenser.
2. Fully press down the handle — the tape will automatically feed out approximately 30mm.
3. Align the tape end with the sticking position (stick it firmly for better results), press the dispenser and attach the tape.
4. Release the handle — the dispenser will automatically cut the tape.

Usage Notes

1. If the handle is released immediately after being pressed, only about 30–40mm of tape will be dispensed. To get a longer length, hold down the handle and pull out the tape to the desired length before releasing.
2. This product supports tapes of different inner diameters — 12mm and 19mm — with a thickness of 0.05–0.07mm.
3. The dispenser design includes a 6mm spacing inside to prevent the tape roll from falling off.
4. When in use, please make sure to press down the handle completely (at least halfway) and then release it instantly. Otherwise, the tape may get stuck.
5. Please remove the sealing tape on the product before first use to avoid interference with tape feeding.
6. If tape jams, open the cover, remove any residual tape, and reinsert the tape correctly to resume normal operation.

Specifications

Dimensions (W × D × H): 38mm × 168mm × 94mm

Weight: 135g

Max Tape Roll Size:

Inner diameter 12mm × 20M

Inner diameter 19mm × 33M

Operating Temperature: -18°C to 49°C

Tape Installation Instructions

Step 1

Press the release button to open the upper cover.

Step 2

Insert the tape roll into the left or right holder:

19mm diameter tape core → Place on the left tape holder.

12mm diameter tape core → Place on the right tape holder.

Step 3

Pull out 30–40mm of tape and place it along the guide roller.

Step 4

Close the upper cover.

Step 5

Before first use, press down the handle to push the tape out of the outlet.

Step 6

Press the handle and release — the tape will be dispensed automatically.