

BOXSHOP



SINGLE-DISPLAY DIGITAL TIMER PRO

INSTRUCTION MANUAL

GRAPHTREES PTE LTD



GRAPHTREES PTE LTD

CUSTOMER SERVICE CONTACT INFORMATION

davidwenr@graphtrees.com

COPYRIGHT NOTICE

Unauthorized reproduction, distribution, or any other use of the materials, in whole or in part, without prior written permission from GRAPHTREES PTE LTD, is strictly prohibited and may result in legal action. All rights reserved.



01 / KEY INSTRUCTIONS

• Time Setting Instructions

- ① Turn the timer knob to set the time (time range: 1 second to 99 minutes and 55 seconds).

• Usage Instructions

- ① Short press the “Start/Stop” button to start or pause the countdown.
- ② Long press to reset to the previous set time.
- ③ After the countdown ends, the alarm will sound for 60 seconds.
- ④ After the alarm stops, the display will show the previously set time.

02 / TIMER DISPLAY

- The large display shows minutes.
- The small display shows seconds.

03 / BUTTON/PORT DESCRIPTION

- **Start/Stop Button:** Short press to start/pause, long press to reset.
- **Type-C Charging Port:** For charging the timer.



04 / NOTES

- ① The timer knob must be turned to set the time.
- ② The device has a memory function to remember the previous time set.
- ③ Ensure to charge the device regularly for continuous use.

Product Diagram


Alarm shutdown button & Timer button

Minute countdown

Hour countdown

Countdown visualization area


Flashing light prompt



TIMING OPERATION GUIDE



Product Diagram



05 / MODES




- **Precise Mode**: Suitable for fine timing tasks (e.g., laboratory work).
- **Regular Mode**: Used for casual tasks like cooking or fitness training.

TIMING OPERATION GUIDE



Status Description



06 / CHARGING



- Use a Type-C cable for charging.
- The battery should last around 3 months when fully charged, depending on usage.

TIMING OPERATION GUIDE



SECTION 1

How to Start Timing

- **Step 1:** Turn the knob to set the countdown time.
- **Step 2:** Press the “Start/Stop” button to begin timing.
- **Step 3:** When the countdown reaches zero, an alarm will sound.
- **Step 4:** After the alarm sounds, press the “Start/Stop” button to stop the alarm.

SECTION 2

Using Continuous Timing Mode

- Turn the knob to set the desired countdown time.
- After the alarm sounds, the device will automatically restart timing from the previously set time.

SECTION 3




Quick Reset Timing Mode

- Press and hold the “Start/Stop” button for two seconds to reset to the previously set time.
- Useful when you need to perform repetitive timing tasks.

TIMING OPERATION GUIDE



Status Description



NOTES

- ① The device has a memory function to remember the previous time set.
- ② The battery needs to be charged using the Type-C port.
- ③ Please avoid exposing the device to water or high temperatures.