

The Gizmo – Installation & Quick Start Guide

1. Mount the Gizmo

- Connect the 8mm pole hose to the single barb inlet and secure with a hose clamp (ensure it won't interfere with your brush adapter when mounted).
- Remove the brush adapter from the brush and discard the screws.
- Using the long screws provided, attach The Gizmo between the brush and adapter.
- Make sure the screws are down tight.
- Push PVC 6mm hose into the push-fit connector using the 4mm barbed elbow provided.
- Use the 6mm OD - 4mm ID silicone hose provided for lower barbs (no clamps required).
- Ensure all hose connections are tight to prevent leaks.

2. Using the Gizmo

- Power on the device by firmly pressing the centre of the top cap.
- The green LED flashes to indicate battery level.
- The device defaults to closed position if previously turned off open.
- Press remote to open (green LED flashes twice).
- Press remote to close (green LED flashes once).
- Turn off at the end of the work day to conserve battery.

3. Charging & Runtime

- Recharge via USB-C (approx. 4 hour charge time).
- After charging, ensure sealing caps are fully seated to maintain water protection.
- Red LED = charging, LED off = fully charged.
- Button controller battery lasts months under normal use (replaceable).
- Gizmo runtime: approximately 1 week per charge depending on usage and temperature.

4. Low Battery Warning

- When the battery is low, the valve opens and the green LED flashes quickly.
- On power-up: 4 flashes = full, 3 flashes = medium, 2 flashes = low, 1 flash = charge now.

5. Install the Remote

- Place the remote in the flexible holder and secure to the base of your pole, just above where your lower hand rests for easy index finger operation.
- Tighten the strap firmly. Once installed, control water flow without changing grip.