

The Gizmo – Installation & Quick Start Guide

1. Mount the Gizmo

Connect the 8mm pole hose to the single barb inlet and secure with a hose clamp (ensure it won't interfere when mounted). Remove the brush adapter from the brush and discard the screws. Using the long screws provided, attach The Gizmo between the brush and adapter. Push the 6mm hose into the push-fit connector using the 4mm barbed elbow provided. Use 6mm OD - 4mm ID silicone hose for lower barbs (no clamps required). Ensure all hose connections are tight to prevent leaks.

2. Using the Gizmo

Power on the device by firmly pressing the centre of the top cap. The green LED flashes to indicate battery level. The device defaults to closed position if previously turned off open. Press remote to open (green LED flashes twice). Press remote to close (green LED flashes once). Turn off at the end of the work day to conserve battery.

3. Charging & Runtime

Recharge via USB-C (approx. 2 hour charge time). After charging, ensure sealing caps are fully seated to maintain water protection. Red LED = charging, LED off = fully charged. Button controller battery lasts months under normal use (replaceable). Gizmo runtime: 3 days to 1 week per charge depending on usage and temperature.

4. Low Battery Warning

When battery is low, the green LED flashes and water flow briefly slows and speeds up. The valve will then default to open so you can continue working. On power-up: 3 flashes = full, 2 flashes = medium, 1 flash = low.

5. Install the Remote

Place the remote in the flexible holder and secure to the base of your pole, just above where your lower hand rests for easy index finger operation. Tighten the strap firmly. Once installed, control water flow without changing grip.