

The Gizmo – Remote Control Pairing Guide

1. Pair the Devices

The button controller communicates wirelessly with the valve unit using radio frequency. The Gizmo is pre-paired to the remote control. If you use multiple brushes or poles, The Gizmo works across a range of configurations. Refer to the multiple pairing section below for setup options.

2. Multiple Pairing Options

One remote can control multiple Gizmo valves (ideal when swapping brushes on the same pole). A remote can be copied to another remote (useful as a backup or when using multiple poles with one valve).

3. Pairing a Remote to a Gizmo Valve

Ensure the Gizmo valve unit is powered on.

1. Remove the top cap and take out the button insert.
2. Locate the small tactile button to the left of the main power button using a thin screwdriver.
3. Press the tactile button once. The green LED will flash rapidly to indicate pairing mode.
4. Press a button on the remote control. The green LED will flash in a different sequence to confirm successful pairing.

The valve is now paired.

4. Copying a Remote Control

Clear stored codes on the new remote by pressing and holding buttons A and B together. **While holding A**, press button B three times (codes are cleared when pressing and holding a button no longer causes the LED to flash continuously).

Hold both remotes close together. Press and hold the corresponding buttons (e.g., A and A). The new remote has learned the code when its LED flashes continuously while the button is held.