



Setup Guide for TIFOH OneTap

Congratulations on your purchase of the TIFOH OneTap! This setup guide provides a step by step overview of how to configure your OneTap device inside a meeting room and get it ready for effective video communication.

1. Unboxing

The OneTap box contains the following items

- OneTap Device
- Power Adaptor
- HDMI Cable
- Remote Control Unit
- 2 AAA size batteries for the RCU
- USB Wireless mouse
- 1 AA size battery for the mouse

You may check if you got all the above-mentioned items. If there are any discrepancies or if you face issues during set up, please reach out to us at support@tifo.com or speak to your sales representative from TIFOH for assistance.


2. Setting up the Device

2.1 Connecting & Powering On the Device

Step 1: Finalise where you want to place the device. The ideal location would be on top of the TV with the device perched on the TV using the foldable stand provided at the base of the device. Make sure that the device is sitting firmly on the TV and is unlikely to fall off unless forcibly pulled.



Step 2: Use the HDMI cable to connect the HDMI 1 port under "Display" of the device to any available port in your TV.



Step 3: Plug in the power adaptor and connect it to the OneTap in the 12V pin provided at the back of the device. Turn on the OneTap and the TV. Make sure the correct HDMI source is selected.



Step 4: Connect the USB dongle provided with the wireless mouse on one of the USB ports in the OneTap. Fit the AA size battery and check that the mouse is powered on.

