

KitchenHart

The Heart of Every Kitchen

CHOOSE YOUR CABINET STYLE
MEASURE THE KITCHEN SPACE
PLAN YOUR LAYOUT

GUIDE



CHOOSE YOUR CABINET STYLE Full Overlay



SW



SG



SB



JG



SE



CS



PW



CW



AW



AG



AM




YC

PRODUCT LIST

Cabinet sizes shown are in stock and available for immediate purchase, but are not a complete representation of all cabinets. Please see sales associate for availability of cabinets not shown.

wall




Depth: 12"

Wall Cabinet, Single Door

W0930, W1230, W1530,
W1830, W2130

W0936, W1236, W1536,
W1836, W2136

W0942, W1242, W1542,
W1842, W2142




Depth: 12"

Wall Cabinet, Split Doors

W2430, W2730, W3030
W3330, W3630, W3930

W2436, W2736, W3036
W3336, W3636, W3936


W2436, W2736, W3036
W3336, W3636, W3936



Width: 30"
Depth: 12"

Wall Cabinet, Split Doors


W3012 / W3015 / W3018
W3021 / W3024



Width: 36"
Depth: 24"

Wall Refrigerator Cabinet, Split Doors


W361224 / W361524 / W361824
W362124 / W362424



Depth: 12"

Stackable Wall Cabinet Single Doors

W1518, W1818 (Modified)
W2118




Depth: 12"

Stackable Wall Cabinet Split Doors

W2418 / W2718
(W3018/ W3318/ W3618)


wall corner



Wall Corner Angle Cabinet, Single Door

DCW2430/ DCW2436/ DCW2442


Width: 24"
Height: 30"/ 36"/ 42"
Depth: 12"



Wall Blind Corner Cabinet, Single Door

WBC2730/ WBC2736/ WBC2742


Width: 24"
Height: 30"/ 36"/ 42"
Depth: 12"



Wall 90 Degree Corner Cabinet

ERC2436/ERC2436/ERC2442

Width: 36"
Height: 30"/ 36"/ 42"
Depth: 24"




Stackable Wall Corner Angle Cabinet, Single Door

DCW2418

Width: 24"
Height: 18"
Depth: 12"


wall spl



Wall Corner Angle



Wall End Shelf



Wine Rack

PRODUCT LIST

Cabinet sizes shown are in stock and available for immediate purchase, but are not a complete representation of all cabinets. Please see sales associate for availability of cabinets not shown.

wall
spl





Plate Rack




Glass holder

Base
corner



Base Blind Corner Cabinet, Full Height Door
BBC36


Width: 27"
Height: 34 1/2"
Depth: 24"



Base Blind Corner Cabinet

BBC39 / BBC42


Width: 36" / 39"
Height: 34 1/2"
Depth: 24"



Base Full Height Corner Cabinet

BHFC36, BHFC36LS

Width: 36"
Height: 34 1/2"
Depth: 24"




Corner Sink Base Cabinet

DCSB42

Width: 42"
Height: 34 1/2"
Depth: 24"


base



Base Cabinet Single Door

B12, B15, B18, B21


Width: 9"/12"/15"/18"/21"
Height: 34 1/2"
Depth: 24"



Full Height Door Base Cabinet

**BT9, B12, B15, B18, B21, B24
B27, B30, B33, B36, B39**


Width: 9" - 42"
Height: 34 1/2"
Depth: 24"



Base Cabinet Split Doors

B24, B27, B30, B33, B36, B39, B42


Width: 24"/27"/30"/33"/36"/39"/42"
Height: 34 1/2"
Depth: 24"



Base Sink Cabinet Split Doors

SB30, SB33, SB36


Width: 30"/33"/36"
Height: 34 1/2"
Depth: 24"



Base 3-Drawer Cabinet

**3DB12, 3DB15, 3DB18, 3DB21
3DB24, 3DB27, 3DB30, 3DB33, 3DB36**

Width: 12"/15"/18"/21"/24"/27"/30"/33"/36"
Height: 34 1/2"
Depth: 24"



Base 2-Drawer Cabinet


2DB30, 2DB33, 2DB36

Width: 30"/33"/36"
Height: 34 1/2"
Depth: 24"

PRODUCT LIST

Cabinet sizes shown are in stock and available for immediate purchase, but are not a complete representation of all cabinets. Please see sales associate for availability of cabinets not shown.


tall



Pantry Cabinet, Single Doors

U188424/ U189024/ U189624


Width: 24"
Height: 84"/ 90"/ 96"
Depth: 24"



Pantry Cabinet, Split Doors

U248424/ U249024/ U249624
U308424/ U309024/ U309624

Width: 24/ 30"
Height: 84"/ 90"/ 96"
Depth: 24"




OVEN Cabinet Split Doors

U338424/ U339024/ U339624

Width: 33"
Height: 84"/ 90"/ 96"
Depth: 24"


vanity



Vanity 3-Drawer Cabinet

3VDB12/ 3VDB15 / 3VDB18
3VDB21/ 3VDB24 / 3VDB27


Width: 12", 15", 18", 21", 24", 27"
Height: 34 1/2"
Depth: 21"



Vanity Sink Cabinet, Single Door

VS18/ VS21


Width: 18" / 21"
Height: 34 1/2"
Depth: 21"



Vanity Sink Cabinet, Split Doors

VS24/ VS27/ VS30/ VS33/ VS36


Width: 24", 27", 30", 33", 36"
Height: 34 1/2"
Depth: 21"



Vanity Sink Cabinet With Drawers


VSD36/ VSD42/ VSD48

Width: 24", 27", 30", 33", 36"
Height: 34 1/2"
Depth: 21"



Vanity Sink Combo Cabinet

V3021DL/ V3621DL
Width: 30" / 36"
Height: 34 1/2"
Depth: 21"




Vanity Sink Combo Cabinet

V3021DR/ V3621DR
Width: 30" / 36"
Height: 34 1/2"
Depth: 21"

PRODUCT LIST

Cabinet sizes shown are in stock and available for immediate purchase, but are not a complete representation of all cabinets. Please see sales associate for availability of cabinets not shown.


Accessory



**Plain Refrigerator
End Panel**

REP2496


Width: 1 1/2"
Height: 96"
Depth: 24"




**Plain Dishwasher
End Panel**

DWR3


Width: 3"
Height: 34 1/2"
Depth: 24"




ACM8- 2 1/2"




CM8- 2 1/2"




DCM- 3 1/2"




ICM- 4"




COV- 5"




SCR




LRM



OCM



SHM



TKC




F342 / BF336




F642




F396



F696



CLDL




FLDL



VA48

.....Much more items than listed, please check with us!

MEASURE THE KITCHEN SPACE




It's important to take your time and make sure your measurements are correct as this will form the foundation of all your planning. To get started, you'll need a tape measure, pencil and grid paper.

1. Start from the left corner of the wall and head in a clockwise direction. Measure from one edge of the wall to the other, skipping over any windows, fixtures and appliances. Label each wall "Wall 1", "Wall 2", etc. and record the dimensions in inches.
2. Once the wall measurements have been recorded, measure all windows and doors, from one outside trim edge to the other outside trim edge and record your measurements on the floor plan.
3. Next, indicate vents, pipes or other obstructions that cannot be moved. Then, record all appliances power sources, water supply, electrical outlets and light switches. Mark the location and center point of all your permanent fixtures.
4. Write down vertical measurements, from floor to the windowsill, from windowsill to the top of the window, and from the top of the window to the ceiling. If you have a dropped ceiling or bulk heads, make sure to include those measurements as well.

Appliance Chart

	width	height	depth
Fridge			
Range			
Dishwasher			
Sink			
Microwave			

PLAN YOUR LAYOUT



1 square = 3"