

CABINETS and ACCESSORIES LIST

WALL CABINET (12" Depth)

W0930	9"x 30" Wall Cabinet
W1230	
W1530	
W1830	
W2130	
W2430	
W2730	
W3030	
W3330	
W3630	
W0936	
W1236	
W1536	
W1836	
W2136	
W2436	
W2736	
W3036	
W3336	
W3636	
W0939	
W1239	
W1539	
W1839	
W2139	
W2439	
W2739	
W3039	
W3339	
W3639	
W0942	
W1242	
W1542	
W1842	
W2142	
W2442	
W2742	
W3042	
W3342	
W3642	
W3012	
W3312	

BASE CABINET (24" Depth & 34.5" High)

<i>Spice Cabinet</i>	
BLBC9	
<i>1-Drawer and 1-Door Base</i>	
B09	9" Base Cabinet
B12	
B15	
B18	
B21	
<i>1-Drawer and 2-Doors Base</i>	
B24	
B27	
B30	
B33	
B36	
<i>3-Drawer Base</i>	
DB12	
DB15	
DB18	
DB21	
DB24	
DB27	
DB30	
DB33	
DB36	
<i>Sink Base</i>	
SB24	
SB27	
SB30	
SB33	
SB36	
<u>BLIND BASE CORNER CABINET</u>	
BBC36	
BBC39	
BBC42	
<u>LAZY SUSAN BASE CORNER CABINET</u>	
DCB33	
DCB36	

W3612	
W2415	
W3015	
W3315	
W3615	
W3018	
W3318	
W3618	
W3021	
W3321	
W3621	
W2424	
W3024	
W3324	
W3624	

Wall Cabinet 24" Depth

W301224	30"x 12"x 24" Deep Wall Cabinet
W331224	
W361224	
W301524	
W331524	
W361524	
W301824	
W331824	
W361824	
W302124	
W332124	
W362124	
W302424	
W332424	
W362424	

WALL BLIND CORNER CABINET

WBC2730	
WBC3030	
WBC2739	
WBC3039	
WBC2742	

WALL DIAGONAL CORNER CABINET

WDC2430	
WDC2439	
WDC2442	

MICROWAVE CABINET

MW2430	
MW2730	

PANTRY CABINET (24" Depth)

WP188424	
WP248424	
WP189024	
WP249024	
WP189324	
WP249324	
WP189624	
WP249624	
WP308424	
WP309024	
WP309324	
WP309624	

VANITY CABINET (21" Depth & 31.5" High)

<i>3-Drawer Vanity</i>	
VD12	
VD15	
VD18	
<i>Vanity Sink Base</i>	
VSB24	
VSB27	
VSB30	
VSB33	
VSB36	

ACCESSORIES

SCM8	Scribe Moulding 8'
CM8-A	Crown Moulding A - 8'
CM8-B	Crown Moulding B - 8'
LRM8	Light Rail Moulding 8'
ICM8	L-Shaped Crown-Light Moulding
OCM8	Outside Corner Moulding
TK8	Toe Kick 8'
WFS330	Filler 3" x 30"
WFS630	Filler 6" x 30"
WFS336	Filler 6" x 36"
WFS339	Filler 3" x 39"
WFS639	Filler 6" x 39"
WFS342	Filler 6" x 42"
WFS396	Filler 3" x 96"

MW2439	
MW2739	
MW2442	

GLASS DOOR CABINET

GD-W2430	
GD-W3030	
GD-W3630	
GD-W2436	
GD-W3036	
GD-W3636	
GD-W2439	
GD-W3039	
GD-W3639	
GD-W2442	
GD-W3042	
GD-W3642	
GD-WDC2430	
GD-WDC2436	
GD-WDC2439	

REP96	Fridge Panel
DWP24	Dishwasher Panel
WEP1230	Wall End Panel 12" x 30"
WEP1236	Wall End Panel 12" x 36"
WEP1239	Wall End Panel 12" x 39"
WEP1242	Wall End Panel 12" x 42"
VEP21	Vanity End Panel
PN4896-3/4"	Panel 4' x 8' x 3/4"

ROMAN COLUMNS

CLM-330	
CLM-339	
CLM-BASE	

ROLL-OUT TRAY (includes GLIDES)

ROT18	
ROT24	
ROT30	