

ALCOBLOC™ SAFETY DEVICE



ALCOBLOC™ QUICK START GUIDE

IMPORTANT, PLEASE READ PRIOR TO USAGE:

Congratulations on your purchase of the innovative & next generation safety device, AlcoBloc™. This Smartphone controlled device will assist you in preventing those under the influence of alcohol from accessing equipment, vehicles, storage units, anything where you can secure the flexible tamper proof cable. AlcoBloc™ includes an easy to use professional alcohol screening device, used for the detection of alcohol in the breath and a robust padlock, designed specifically to be used outdoors. These two pieces of hardware are controlled by the AlcoBloc™ Smartphone app. Positive ID is provided since photo is taken immediately upon initiation of the breath test, making it difficult if not impossible to manipulate the test.











Please read the following Quick Start Guide in its entirety to make your testing experience a user friendly as possible.

REMEMBER ALCOHOL IS A DRUG

Alcohol is the chemical (ethanol or ethyl alcohol) resulting from the fermentation of grapes or grain. Alcohol is absorbed directly into your bloodstream, affecting coordination. **DO NOT drink and drive.** AlcoBloc™ is an excellent tool to assist you in protecting your property, investments, and more importantly – lives. But the best solution to avoid such tragedy is to **not drink and drive.** YATAG SECURITY strongly recommends that no vehicle or machinery be operated after alcohol consumption. Even small quantities of alcohol can result in driving impairment. Do not use AlcoBloc™ as a tool to determine if equipment and/or vehicle operation is appropriate. YATAG SECURITY does not assume any responsibility for anyone driving or operating equipment while under the influence.

This software is to be used only with the devices sold by the company. Any other use is illegal. This software is provided only to the end user to operate the AlcoBloc™. Any modification or reverse engineering is illegal. The product cannot be resold without written consent.

ALCOBLOC™ QUICK START GUIDE

	<p style="text-align: center;">LOG IN SCREEN</p> <p>Initial screen will take you to User Name & Password screen. Once App purchased then User will be provided a login name.</p>
	<p style="text-align: center;">SCREEN FOR CONNECTING DEVICE TO PBT</p> <p>This screen will make sure the tester is properly connected. Helpful hint: A better connection usually results if the PBT is turned on once this screen appears and not before.</p>
	<p style="text-align: center;">DEVICE CONNECTED AND READY FOR TEST</p> <p>On this screen you will be directed to begin test. Make sure you have all components ready and phone positioned to take clear Selfie photo. Once START TEST is selected, End User will be taken to live photo image screen.</p>
	<p style="text-align: center;">BEGIN BREATH TEST</p> <p>Consistent extended breath flow is required. If insufficient breath flow not provided, an error will occur and new test must be initiated (restart app) in order to proceed to open lock.</p>
	<p style="text-align: center;">STOP BREATH TEST</p> <p>Once sufficient breath is provided for accurate test, you will see this icon instructing you to stop test and wait for test results.</p>
	<p style="text-align: center;">NEGATIVE TEST RESULTS/OPEN LOCK</p> <p>If results are NEG, then proceed to open lock by pushing black button in center of lock.</p>
	<p style="text-align: center;">LOCK NOW OPENED</p> <p>If all steps followed correctly, lock will open and you can proceed to remove lock to utilize vehicle, device, item that was previously blocked.</p>
	<p style="text-align: center;">POSITIVE TEST RESULTS/LOCK CLOSED</p> <p>If results are POS, alcohol is present in the system. Lock will remain closed and end user will need to consult Administrator for further instructions.</p>
	<p style="text-align: center;">LOCK TIMED OUT</p> <p>If lock is not opened within the time frame given, the lock will remain closed and new test will be needed in order to open.</p>
	<p style="text-align: center;">EXCESSIVE LEVEL OF ALCOHOL</p> <p>Excessive alcohol will damage your health, but it will also damage the fuel cell sensor of the PBT. Avoid blowing into PBT with high levels of alcohol.</p>
<p>Helpful Hints</p>	<p>If ever experiencing an issue, make sure all open apps and screens are closed, recycle phone and restart app. For best results please keep in areas with strong mobile/internet connection. (Internet if WIFI, mobile if no WIFI).</p>

DO'S AND DON'TS

Please read prior to usage

DO

- Do make sure that the Bluetooth module is turned on for proper connection. We recommend phones are set to Sleep Mode over 3 Minutes to avoid App timing out.
- Do make sure you **do not put anything in your mouth at least 20 minutes** prior to testing to avoid a false positive result.
- Make sure if using the tamper proof cable that it is securely attached vehicle or item you are wishing to protect and cannot be removed or adjusted in anyway.
- If there are connection issues, confirm all other AlcoBloc™ screens are closed and if issues persist, RESTART phone. If issues continue, contact info@yatagsecurity.com
- To save time, prepare yourself to take a consistent and extended breath for an accurate sample. If the tester does not have sufficient sample, the test will be cancelled and you will need to retake the test.
- Make sure you have a VERY CLEAR picture of yourself when doing 'selfie' for test for accurate records.
- Remember that having reliable internet connection is significant, while AlcoBloc™ is designed to work offline, it is not ideal and issues can arise.
- Remember that the portable testers need to be calibrated every 12 months or per Administrator's protocol.

DON'T

- For reasons of hygiene, do not share your portable breath tester (PBT) with anyone.
- Clean the PBT with any type of alcohol cleaning solution since this could provide false positives.
- Blow into the PBT with excessive alcohol in your mouth or in your system since this will damage the sensor, possibly permanently.
- Blow smoke, food or liquids into the PBT to avoid causing damage to sensor.
- Test in areas with strong winds, smoke or where large amounts of alcohol are being consumed since test results may become affected.
- Try to use equipment that has not been purchased from YATAG Security as it will not work properly and will not connect.