


LED Electronic Clock 108 Multi Color with WiFi Synchronization

User Manual

Please read this user manual carefully before use and keep it properly.


Product Content



Product Information

Display size	Display Size: W325 x H125mm
Product size	W330xH130xD30mm
Product weight	650g (excluding the power adapter)
Timer Range	1 second as a unit, maximum of 99 hours 59 minutes 59 seconds.
Alarm sound	25 Music Ringtones
RGB LED light color	11-color number display
Product Features	WiFi time synchronization, Date/temperature 5-second display, one-button snooze, snooze function, super long positive and negative countdown timer, countdown voice reminder, volume adjustment, 2 sets of alarms, plug-in use, can be hung or placed, memory function.

Product back side



Button Functions

SNOOZE

LED Digital Color Selection
Alarm ring: snooze function (9 minutes)
Timer Mode: Start/Pause Timing

SET

Settings: week selection,
time setting for year, month, day
Timer mode: Hour setting



+ : 12/24 hour format switching
Timer Mode: Minute Setting



- : °C/°F switching
Timer Mode: Seconds setting



25 ringtone selection keys



Alarm 1 ON/OFF



Alarm 2 ON/OFF



Enter/Exit Timer



Timer Reset



Ringtone Volume Adjustment



Turn on/off for Timer
10-second countdown
voice announcement



3 gear brightness
push button

1. Connect to Wi-Fi (Please forget your own Wi-fi network before connecting)

- Keep pressing the "SNOOZE" button on the back of the clock until you plug the power.




On your smartphone, looking for name " Marckoni " at WLAN (Wi-fi) and connect it.

- Enter 192.168.88.1 in the browser of your smartphone. Then click on the " Web-config " to process Wi-Fi match. (Please turn off all of the other browser interfaces before Wi-Fi match)



Please select your local time zone. Click on the " Submit ", the Wi-Fi connection is successful when the page displays " Success ".

- Once you see the Wi-Fi signal showing on the screen, that means it successfully connected.



If the time zone is selected incorrectly, or if you need to reconfigure or replace Wi-Fi, please repeat steps A and B.

2. Weekday language, year, date, and time settings.

- Press the "SET" button to enter the settings.



After entering, the screen flashes "ENG", press "+" or "-" to select other language for the week.

- Set the year, date, and time separately by using the "+", "-", and "SET" buttons.



- Once the setup has completed, treat "SET" button as "Confirm" button.



3. Switch display between date and temperature.

- Long press the "+" button for 2 seconds to enter the switch settings.



- Press the "+" or "-" keys to select different display modes.



DATE TEMP MONTH :Display date/temperature.
(loop every 5 seconds) (initial setup)

DATE MONTH :Display date only.

TEMP :Display temperature only.

- After selecting, press "SET" to return to the time display.



4. Setting two alarms.

- Long press the "Alarm 1" or "Alarm 2" button on the back for 2 seconds to enter the setting for "Alarm 1" or "Alarm 2" respectively.




- The "OFF" at the top of the screen is flashing. Press "+" or "-" to turn the alarm ON/OFF, then press "SET" to confirm.




- Set the alarm time by pressing "+" or "-" and then press "SET" to confirm.

Alarm ON (screen icon displayed)
Alarm OFF (screen icon not displayed)




- ④ Select the alarm working day mode setting by pressing "+" or "-", and then press "SET" to confirm.



- 1E :Every day.
2E :Weekdays (Monday to Friday)
3E :Weekend (Saturday-Sunday)

- ⑤ Press "+" or "-" to select the alarm ringtone, and then press "SET" to confirm.




(1-25 ringtone options available)

- ⑥ After making the selection, press "SET" to return to the time display.



<Stop the noise with one click>

The alarm clock goes off, and pressing any button except the "SNOOZE" button will stop the alarm. It will ring again at the same time on the next day.



<Snooze function>

The alarm clock rings, press the "SNOOZE" button, the alarm clock stops, and the snooze function is activated. It will ring again after 9 minutes.

- The alarm clock rang.
- SNOOZE
- It will ring after in 9 minutes.

5.Timer Functionality

- -T1 Timing range: 00:00:00-99:59:59.
- -Automatically save the last timing when starting up (with a memory battery).
- -While the timer is working, you can switch between the timer interface and the display time interface. When the timer starts the 10-second countdown voice announcement, the screen will automatically switch to the timer interface! (The 10-second countdown voice announcement function can be turned on and off by the buttons on the back panel.)

<Count Up setting>


- ① Press the "Timer" button to enter the timer mode.



- ② Press the "SNOOZE" button to start/stop.



- ③ Press the "Timer Reset" button to reset it to zero.



<Count Down setting>

- ① Press the "Timer" button to enter the timer mode.



- ② Press "Timer Reset" to reset to zero.




- ③ Set a corresponding time unit on each button.



- ④ Press the "SNOOZE" button to start/stop.



- ⑤ Press the "Timer Reset" button to reset it to zero.



- ⑥ After pressing the "Timer" button, the time display will return.



<Countdown voice reminder function>

- ① Press the "Timer" button to enter the timer mode.



- ② Press the voice ON/OFF button at the bottom of the back of the device, and the countdown screen will display/hide the voice icon in the top left corner.



This icon is only displayed in timer mode.

6.Ringtone Music Settings and Volume Adjustment

- ① Select ringtone music by pressing the "Music" button on the back.




After selecting a ringtone, press the "Music" button to return to the time interface.

- ② To choose a different ringtone music, you need to press the "Music" button on the back again to select the next ringtone music.



(25 ringtone music pieces)

- ③ Adjust the volume by sliding the wheel up or down on the "Volume Controller" on the back to adjust the volume to different levels.



7.Switch date display format: month/date format or date/month format

- ① Before installing the memory battery, hold down the "SET" key and insert the power supply to enter the settings.




- ② Select the date display format (month/date or date/month) by pressing "+" or "-".



- ③ After completion, turn off the clock's power supply and then turn it back on to perform other settings.

Large Digital Wall Clock with Remote Control



The (Timer ST/SP) button used as "SNOOZE" function in alarm mode; Press any other buttons to stop the alarm.