



CERAMIC SHIELD & OPTI SHIELD

Application Instructions

PROFESSIONAL USE ONLY

1. Shake Well Before Using. Test the product on an inconspicuous area before applying.
2. Make sure the surface is **clean and dry**.
3. Make sure surfaces are cool and dry. **Do not apply in direct sun or if the surface is above 85°F or below 50°F.**
4. Apply light spray directly on exterior surface or on a clean & dry microfiber applicator, apply the product evenly with complete coverage and an even layer. Use a high-quality microfiber cloth to remove any excess and a second microfiber to buff. Buff to a shine with a dry towel. CERAMIC SHIELD & OPTI SHIELD does not need to be left on the surface to cure, so it should be removed within one minute of application. Material will require a light wipe to remove any remaining residue, turning the towel frequently. Check with an appropriate light source to ensure you have removed ANY/ALL residue.